

Operating instructions

Part 2 - For the customer

for i:SY pedelecs with BOSCH Kiox 300/500 on-board computer

i:SY

Ride it! Love it!



BOSCH



E5 ZR F ADVENTURE | E5 ZR F CX | E5 ZR F CX Century | E5 ZR F CX my i:SY
N3.8 ZR CX Comfort | RE 14 ZR F | S10 Adventure | XXL E5 ZR F CX | XXL RE 14 ZR F
XXL N3.8 ZR AUTO COMFORT | XXL N3.8 ZR CX Comfort

H-01 ... H-08, J-01 ... J-04

Contents

1	About these operating instructions	
1.1	Aim of the instructions for use	8
1.2	Manufacturer	9
1.3	For your information	9
1.3.1	Warnings	9
1.3.2	Markups	9
1.4	Type number and model	10
1.5	Frame number	10
1.6	Identifying the operating instructions	10
2	Safety	
2.1	Residual risk	11
2.1.1	Risk of fire and explosion	11
2.1.2	Hot surfaces	12
2.1.3	Electric shock	12
2.1.4	Risk of a crash	12
2.1.5	Risk of amputation	12
2.2	Toxic substances	13
2.2.1	Carcinogenic substances	13
2.2.2	Toxic materials	13
2.2.3	Irritants and corrosive substances	13
2.3	Vulnerable groups	13
2.4	Requirements for the pedelec rider	13
2.5	Personal protective equipment	13
2.6	Safety guards	13
2.7	Safety markings and safety instructions	14
2.8	What to do in an emergency	14
2.8.1	Dangerous situations in road traffic	14
2.8.2	Leaked brake fluid	14
2.8.3	Battery vapour emission	15
2.8.4	Battery fire	15
2.8.5	Oil and lubricant leaks from the fork	15
2.9	Data privacy information	15
3	Description	
3.1	Proper use of city and trekking bicycles	16
3.1.1	Improper use	16
3.1.2	Area of use	17
3.2	Technical data	19
3.2.1	Complete BOSCH vehicle	19
3.2.2	Dimensions	20
3.2.3	Dimensions	21
3.2.4	Environmental requirements	22
3.3	Nameplate	23
3.3.1	Model year 24	23
3.3.2	Up to model year MY23	24
3.4	Components	25
3.4.1	Overview	25
3.5	Parts list and repair instructions	26
3.5.1	Chassis	50
3.5.2	Suspension	52
3.5.3	Wheel	63
3.5.4	Brake	68
3.5.5	Saddle	71
3.5.6	Seat post	72

3.5.7	Mechanical drive system	73
3.5.8	Electric drive system	73
3.5.9	Seat post	75
3.5.10	Mechanical drive system	76
3.5.11	Electric drive system	78
3.6	Description of controls and screens	82
3.6.1	Handlebars	82
3.6.2	Handbrake	93
3.6.3	Gear shift	94
3.6.4	Suspension and damping	97
3.6.5	Battery	100
4	Transporting and storing	
4.1	Transportation	101
4.1.1	Using the transport securing system	101
4.1.2	Transporting the pedelec	101
4.1.3	Shipping a pedelec	102
4.1.4	Transporting the battery	102
4.1.5	Shipping the battery	102
4.2	Storing	102
4.2.1	Pedelec	102
4.2.2	On-board computer, display and charger	102
4.2.3	Battery	103
4.2.4	Break in operation	103
5	Assembly instructions for online sales	
5.1	Unpacking	104
5.2	Preparing	104
5.3	Required tools	104
5.4	Straightening the handlebars	105
5.4.1	Stem with clamping lever version I	105
5.4.2	Stem with clamping lever version II	105
5.5	Stem with screw	105
5.6	Checking the stem and handlebars are in correct position	106
5.6.1	Checking the connections	106
5.6.2	Checking stem is firmly in position	106
5.6.3	Checking the bearing clearance	106
5.7	Fitting the pedals	107
6	Operation	
6.1	Risks and hazards	108
6.2	Instruction and customer service	110
6.3	Adjusting the pedelec	110
6.3.1	Preparing	110
6.3.2	Riding position	110
6.3.3	Saddle	111
6.3.4	Handlebars	113
6.3.5	Stem	113
6.3.6	Handles	115
6.3.7	Tyres	115
6.3.8	Brake	116
6.3.9	Determining the sitting position	117
6.3.10	Seat post	118
6.3.11	Saddle	118
6.3.12	Handlebars	123
6.3.13	Stem	124
6.3.14	Handles	126
6.3.15	Tyres	127

6.3.16	Brake	128
6.3.17	Control panel and gear shift	133
6.3.18	Suspension and damping	135
6.3.19	Adjusting the suspension fork sag	135
6.3.20	Adjusting the rear frame damper sag	137
6.3.21	Riding light	140
6.3.22	Adjusting Kiox 300 and Kiox 500 on-board computer	142
6.4	Accessories	146
6.4.1	Child seat	146
6.4.2	Trailers	147
6.4.3	MonkeyLoad system	148
6.4.4	Front baskets	151
6.4.5	Panniers and cargo boxes	152
6.4.6	Saddle	153
6.4.7	Seat post	154
6.4.8	Saddle tensioner	154
6.4.9	Adjustable stem	155
6.4.10	Handlebars	155
6.4.11	Leather handles	155
6.4.12	Folding pedals	155
6.4.13	Protective covers	156
6.4.14	Two-leg stand	156
6.4.15	Lock chain	157
6.4.16	Adapter	157
6.4.17	Rear mirror	157
6.4.18	ROHLOFF gear hub tool	157
6.5	Personal protective equipment and accessories for road safety	158
6.6	Before each ride	158
6.7	Using the battery	159
6.7.1	Inserting the battery	159
6.7.2	Removing the battery	159
6.7.3	Charging the battery	159
6.8	Straightening the quickly adjustable stem	161
6.9	Lowering the pedals	161
6.10	Using the pannier rack	162
6.11	Raising the kickstand	162
6.12	Using the saddle	162
6.12.1	Using the leather saddle	163
6.13	Using the pedals	163
6.14	Using the bell	163
6.15	Using the handlebars	163
6.15.1	Using multi-position handlebars	163
6.15.2	Using bar ends	164
6.15.3	Using leather handles	164
6.16	Use BOSCH electric drive system with LED Remote	165
6.16.1	Switching on the electric drive system	165
6.16.2	Switching off the electric drive system	165
6.17	Using the on-board computer	166
6.17.1	Using the diagnosis port	166
6.17.2	Charging the control panel battery	166
6.17.3	Using the riding light	167
6.17.4	Using the main beam	167
6.17.5	Using the headlamp flasher	167
6.17.6	Setting the brightness of indicators	167
6.17.7	Using the push assist system	168
6.17.8	Selecting the level of assistance	169
6.18	Using the brake	170
6.18.1	Using the handbrake	170
6.18.2	Using the back-pedal brake	170

6.19	Brakes	171
6.19.1	Using the handbrake	171
6.19.2	Using the back-pedal brake	171
6.20	Switching gears	171
6.20.1	Using the derailleur gears	171
6.20.2	Using pinion gears	172
6.20.3	Using a SHIMANO hub gear	173
6.20.4	Using a SHIMANO hub gear	174
6.20.5	Using a ROHLOFF gear shift	175
6.21	Adjusting the suspension fork	176
6.21.1	Adjusting the suspension fork suspension	176
6.22	Parking	178
6.22.1	Screwing in the quickly adjustable stem	179
6.23	Folding up the pedal	179
6.23.1	Activating the lock function	180
7	Cleaning, servicing and inspection	
7.1	Before each ride	181
7.1.1	Checking the safety guards	181
7.1.2	Checking the frame	181
7.1.3	Checking the fork	181
7.1.4	Checking the rear frame damper	182
7.1.5	Checking the pannier rack	182
7.1.6	Checking the guards	182
7.1.7	Check wheel concentricity	182
7.1.8	Checking the quick releases	182
7.1.9	Checking the suspension seat post	182
7.1.10	Checking the bell	182
7.1.11	Checking the handles	182
7.1.12	Checking the riding light	182
7.1.13	Checking the brake	183
7.2	After every ride	183
7.2.1	Cleaning the riding light and reflectors	183
7.2.2	Cleaning the brake	183
7.2.3	Cleaning the suspension fork	183
7.2.4	Cleaning the suspension seat post	183
7.2.5	Servicing the suspension fork	183
7.2.6	Cleaning the rear frame damper	183
7.2.7	Cleaning the pedals	183
7.3	Basic cleaning	183
7.3.1	Remove and clean by hand	183
7.3.2	Cleaning the stem	183
7.3.3	Cleaning the handlebars	183
7.3.4	Cleaning the handles	184
7.3.5	Cleaning the seat post	184
7.3.6	Cleaning the saddle	184
7.3.7	Cleaning the tyres	184
7.3.8	Cleaning the spokes and spoke nipples	184
7.3.9	Cleaning the hub	184
7.3.10	Cleaning the switching elements	184
7.3.11	Cleaning the SRAM AXS rear derailleur	185
7.3.12	Cleaning the cassette, chain wheels and front derailleur	185
7.3.13	Cleaning the brake	185
7.3.14	Cleaning the brake disc	185
7.3.15	Cleaning the belt	185
7.3.16	Cleaning the chain	185
7.4	Servicing	186
7.4.1	Servicing the frame	186
7.4.2	Servicing the fork	186

7.4.3	Caring for the pannier rack	186
7.4.4	Servicing the mudguard	186
7.4.5	Servicing the kickstand	186
7.4.6	Servicing the stem	186
7.4.7	Caring for handlebars	186
7.4.8	Caring for the handles	186
7.4.9	Servicing the seat post	187
7.4.10	Caring for the rims	187
7.4.11	Caring for the leather saddle	187
7.4.12	Servicing the hub	187
7.4.13	Servicing the spoke nipples	187
7.4.14	Servicing the gear shift	187
7.4.15	Servicing the pedals	188
7.4.16	Servicing the chain	188
7.4.17	Servicing the brake	188
7.5	Inspection	189
7.5.1	Checking the wheel	189
7.5.2	Checking the brake system	191
7.5.3	Check chain	192
7.5.4	Checking the chain tension	192
7.5.5	Checking the chain for wear	193
7.5.6	Checking the belt	194
7.5.7	Checking the riding light	195
7.5.8	Checking the stem	196
7.5.9	Checking the handlebars	196
7.5.10	Checking the saddle	196
7.5.11	Checking the seat post	196
7.5.12	Checking the pedal	196
7.5.13	Checking the gear shift	196
8	Inspection and maintenance	
8.1	Initial inspection	198
8.2	Carrying out the initial inspection	198
8.3	Major inspection	199
8.4	Component-specific maintenance	199
9	Troubleshooting, fault clearance and repair	
9.1	Preventing pain	202
9.1.1	Sitting discomfort	203
9.1.2	Pain in hips	203
9.1.3	Backache	203
9.1.4	Pain in shoulders and nape of neck	204
9.1.5	Numb or aching hands	204
9.1.6	Pain in upper thigh	204
9.1.7	Knee pain	205
9.1.8	Pain in the foot	205
9.2	Kiox 300 and Kiox 500 drive system	206
9.2.1	Drive system or on-board computer does not start up	206
9.2.2	Errors in assistance function	207
9.2.3	Battery errors	208
9.2.4	Display screen errors	209
9.2.5	Lighting does not work	209
9.2.6	BOSCH error message	210
9.2.7	Correcting disc brake faults	213
9.2.8	Correcting faults in the SR SUNTOUR suspension fork	214
9.2.9	Problems with the Rohloff hub gear	218
9.2.10	Problems with the Rohloff hub gear	220
9.2.11	Correcting freewheel faults	223
9.2.12	Correcting lighting faults	224

9.2.13	Correcting faults in tyres	224
9.2.14	Correcting control seat post faults	224
9.2.15	Correcting other faults and errors	225
9.3	Repairs at the specialist dealer	226
9.3.1	Original parts and lubricants	226
9.3.2	Repairing the frame	226
9.3.3	Repairing the suspension fork	226
9.3.4	Replacing the riding light	226
9.3.5	Adjusting the headlight	226
9.3.6	Checking suspension fork-tyre clearance	226
9.3.7	Replacing pedelec components if lock function is installed	227
10	Recycling and disposal	
10.1	Guidelines on removal of waste	228
11	Documents	
11.1	Operating instructions for pinion	236
12	Glossary	
13	Appendix	
I.	Translation of the original EC Declaration of Conformity	241
II.	Directive declaration of conformity with RED Directive	242
14	Keyword index	

Copyright

© i:SY GmbH Co. KG

Distribution or reproduction of these operating instructions and utilisation or communication of their content is prohibited unless expressly approved. Anyone who does not comply with these restrictions is liable for damages. All rights reserved in the event that a patent, utility model or industrial design is registered.

Subject to internal changes

The information contained in these *operating instructions* are the approved technical specifications at the time of printing. In addition to the functions described here, the software may be modified at any time to rectify errors and extend functions.

Any significant changes are included in a new published version of the operating instructions. All changes and new versions of the operating instructions are published on the following website:

www.isy.de/gb-en/

Editing

Text and images:
ZEG Zweirad-Einkaufs-Genossenschaft eG
Longericher Strasse 2
50739 Köln, Germany

Translation

ElaN Languages GmbH
Bonner Strasse 484
50968 Köln, Germany

Contact if you have any questions or problems, or wish to have a printed copy of these operating instructions:

tecdoc@zeg.de

1 About these operating instructions

1.1 Aim of the instructions for use

i:SY pedelecs are premium quality vehicles. You have made an excellent choice. Your specialist dealer will provide you with guidance and instruction and assemble your product. Your specialist dealer will also be happy to assist you in the future, whether you require maintenance, a retrofit or repair.

The instructions for use aim to provide you with the information you need to use your new pedelec effectively and safely throughout its entire lifecycle while also avoiding misuse.


The operating instructions are designed for pedelecs that are purchased directly from a specialist dealer.

Please take time to become familiar with your new pedelec. Once you have read the instructions for use, you will be able to:

- Identify and avoid dangers that the pedelec entails
- Understand the pedelec's different components
- Following an online purchase, assemble the pedelec and adjust it for the rider's size
- using the pedelec,
- Clean the pedelec
- Inspect the pedelec
- Detect simple faults on the pedelec, correct faults and prevent misuse
- Schedule maintenance
- Dispose of the pedelec in the correct manner.

Use the tips and suggestions in the operating instructions. They will help you to enjoy your pedelec for a long time to come.

Download the operating instructions onto your phone at the following link so that you can use them when you are out riding:



www.isy.de/gb-en/

1.2 Manufacturer


i:SY GmbH Co. KG
 Longericher Strasse 2
 50739 Köln, Germany


Tel. +49 5744 900 910
 Email: juergen.schreiber@fes-frankfurt.de
 Website: www.isy.de/gb-en/

1.3 For your information

1.3.1 Warnings

Warnings indicate hazardous situations and actions. You will find three categories of warnings in the operating instructions:

 **WARNING** May lead to serious or even fatal injuries if ignored. Medium-risk hazard.

 **CAUTION** May lead to minor or moderate injuries if ignored. Low-risk hazard.

Notice May lead to material damage if ignored.

1.3.2 Markups

You will find ten text markups in the operating instructions:

Stylised form	Use
<u>Underlined in blue</u>	Link
<u>Underlined in grey</u>	Cross references
✓	Requirements
▶	Instructions for actions with no specific order
3	Instructions for actions in specified order
⇒	Result of the action
LOCKED	Indicators on the display screen
•	Bulleterd lists
Only applies to pedelecs with this equipment	A notice beneath the heading indicates components which can be used as an option

Table 1: Markups

1.4 Type number and model

These operating instructions are an integral part of pedelecs with the type numbers:

Type no.	Model	Pedelec type
H-01	S10 Adventure	City and trekking bicycle
H-02	E5 ZR F CX	City and trekking bicycle
H-03	RE 14 ZR F	City and trekking bicycle
H-04	E5 ZR F CX Century	City and trekking bicycle
H-05	E5 ZR F CX my i:SY	City and trekking bicycle
H-06	N3.8 ZR CX Comfort	City and trekking bicycle
H-07	N3.8 ZR RT Comfort	City and trekking bicycle
H-08	E5 ZR F Adventure	City and trekking bicycle
J-01	XXL E5 ZR F CX	City and trekking bicycle
J-02	XXL RE 14 ZR F	City and trekking bicycle
J-03	XXL N3.8 ZR CX Comfort	City and trekking bicycle
J-04	N3.8 ZR RT Comfort	City and trekking bicycle

Table 2: Type number, model and pedelec type

1.5 Frame number

Each frame has an individual frame number stamped on it (see Figure 2). The frame number can be used to link the pedelec with the owner. The frame number is the most important identifier for verifying ownership.

1.6 Identifying the operating instructions

The operating instructions identification number is located in bottom left-hand corner of each page.

The identification number is composed of the document number, the version number and the release date.

Identification number	Part 2/3_MY23I0a - EN_1.0_19.12.2024
------------------------------	---

2 Safety

2.1 Residual risk



2.1.1 Risk of fire and explosion

Never charge if there is a critical fault

If a charger is connected to the drive system when a critical fault is reported, the battery may be damaged permanently and may catch fire.

- ▶ Connect charger to fault-free electric drive system only.

Protect against water ingress

The battery is only protected from spray water. Penetration by water can cause a short circuit. The battery may self-ignite and explode.

- ▶ Never immerse battery in water.
- ▶ Take battery out of service if you suspect water has penetrated it.

Avoid heat

Temperatures over 60 °C can also cause liquid to leak from the battery and the battery will become damaged. The battery may self-ignite and explode.

- ▶ Protect the battery against heat.
- ▶ Never store the battery next to hot objects.
- ▶ Never expose battery to continuous direct sunlight.
- ▶ Avoid wide temperature fluctuations.

Never use incorrect charger

Chargers with excessive voltage damage batteries. This may cause a fire or an explosion.

- ▶ Charge approved batteries only.

Prevent short circuit due to interconnection

Metal objects may interconnect the battery's electrical terminals. The battery may self-ignite and explode.

- ▶ Never insert paper clips, screws, coins, keys and other small parts into the battery.
- ▶ Place the battery on clean surfaces only. Prevent charging socket and contacts against contamination from dirt, sand and similar.

Handling a damaged or faulty battery

Faulty batteries are hazardous goods. These include:

- Batteries which have leaked or discharged gas
- Cells or batteries which have sustained external or physical damage.

The safety electronics may fail if the batteries are damaged or faulty. The residual voltage can cause a short circuit. The battery may self-ignite and explode.

- ▶ Only use and charge battery and accessories if they are in perfect condition.
- ▶ Never open or repair the battery.
- ▶ Batteries with external damage must be removed from service immediately.
- ▶ If a battery is dropped or struck, remove it from service and keep it under observation for at least 24 hours.
- ▶ Contact specialist dealer.

Dispose of faulty batteries.

- ▶ Take faulty battery to your specialist dealer in your pedelec as quickly as possible. Store the battery in the pedelec until it is taken away for transport.

Avoid overheating in the charger

The charger heats up when it is charging the battery. If it is not allowed to cool down sufficiently, it can cause a fire or burns to the hands.

- ▶ Never use charger on a highly flammable surface.
- ▶ Never cover the charger during charging.
- ▶ Never leave battery unattended during charging.



2.1.2 Hot surfaces

The brakes, hubs and the motor may become very hot when in operation. There is a risk of burns or fire in case of contact.

- ▶ Never touch the brakes or the motor immediately after a ride.
- ▶ Never place the pedelec on a flammable surface, such as grass or wood, directly after use.



2.1.3 Electric shock

Never use damaged network components

Damaged chargers, cables and plug connectors increase the risk of electric shock.

- ▶ Check the charger, cable and plug connector before each use. Never use a damaged charger.

Avoid water ingress

If water penetrates into the charger, there is a risk of electric shock.

- ▶ Use the charger indoors only.

Dealing with condensate

Condensation may form in the charger and battery when the temperature changes from cold to hot, causing a short circuit.

- ▶ Wait until both charger and battery are at room temperature before connecting them.



2.1.4 Risk of a crash

Adjusting quick release correctly

Excessively high clamping force will damage the quick release and cause it to lose its function. Insufficient clamping force will result in unfavourable transmission of force. This can cause components to break. This will result in a crash with injuries.

- ▶ Only use the clamping lever with the specified set clamping force.
- ▶ Contact specialist dealer if the quick release has lost clamping force.



2.1.5 Risk of amputation

The brake disc in disc brakes is so sharp that it can cause serious injuries to fingers if they are inserted into the brake disc openings.

The chain wheels and belt sprockets can draw in fingers, thus causing serious injuries to fingers.

- ▶ Always keep fingers well away from rotating brake discs and the chain or belt drive.

2.2 Toxic substances



2.2.1 Carcinogenic substances

Suspension oil

If you come into contact with the suspension oil in the fork or the rear frame damper, it will irritate the respiratory tract and can cause cancer, sterility and changes to the genetic make-up of germ cells oil cause.

- ▶ Never dismantle the rear frame damper or the suspension fork.



2.2.2 Toxic materials

Brake fluid

Brake fluid may leak out after an accident or due to material fatigue. Brake fluid can be fatal if swallowed or inhaled.

- ▶ Never dismantle the brake system.

Suspension oil

The suspension oil in the fork and the rear frame damper is toxic to the touch.

- ▶ Never dismantle the rear frame damper or the suspension fork.



2.2.3 Irritants and corrosive substances

Defective battery

Liquids and vapours may leak from damaged or faulty batteries. Excessively high temperatures may also cause liquids and vapours to leak from the battery. Such liquids and vapours can irritate the airways and cause burns.

- ▶ Never dismantle the battery.
- ▶ Never inhale vapours.

2.3 Vulnerable groups

- ▶ Keep batteries and the charger away from children and people with reduced physical, sensory or mental capacities or lacking in experience and knowledge.
- ▶ Children and young people must be provided with comprehensive instructions by a legal guardian.

2.4 Requirements for the pedelec rider

The pedelec rider must have adequate physical, motor and mental abilities to ride on public roads. A minimum age of 14 years is recommended. The area of use is labelled on the nameplate. Experience as defined in EN 17406 is also required.

2.5 Personal protective equipment

- ▶ Wear sturdy shoes.
- ▶ Wear tight-fitting clothes only. Wear clothing which is as bright or retroreflective as possible.
- ▶ Wear a suitable helmet.
- ▶ Wear gloves.
- ▶ Wear well-fitting glasses.

2.6 Safety guards

Three safety guards on the pedelec protect pedelec riders against heat, dirt or moving parts:

- the motor cover
- the battery cover
- the chain guard.
- ▶ Never remove the safety guards.
- ▶ Check the safety guards on a regular basis.
- ▶ Take pedelec out of service if a guard is damaged or missing. Contact specialist dealer.

2.7 Safety markings and safety instructions

Pedelec and battery nameplates contain the following safety markings and safety instructions:






Symbol	Explanation
	General warning signs
	Warning of explosive substances
	Warning of hot surfaces
	Adhere to the instructions for use
	No naked flames

Table 3: Safety markings




Symbol	Explanation
	Collect ordinary batteries and rechargeable batteries separately.
	It is forbidden to open any type of battery.
	Protect from temperatures above 50 °C and direct sunlight

Table 4: Safety instructions

2.8 What to do in an emergency

2.8.1 Dangerous situations in road traffic

- ▶ If you encounter any hazards or dangers in road traffic, apply the brake until the pedelec comes to a halt.

2.8.2 Leaked brake fluid

- ▶ Avoid contact with skin and eyes. Wear gloves and safety gloves as protective equipment. Remove any clothing contaminated with brake fluid immediately.
- ▶ Take care with leaked brake fluid as it poses a slip hazard.
- ▶ Keep leaked brake fluid away from naked flames, hot surfaces and sources of ignition.

After skin contact

- 1 Wash affected skin with soap and water and rinse well.
- 2 Remove contaminated clothing.
- 3 Consult doctor in the event of pain or discomfort.

After contact with eyes

- 1 Rinse eyes under flowing water for at least ten minutes with the lids open; also rinse under lids.
- 2 Immediately consult a doctor in case of any pain or discomfort.

Environmental protection measures

- ▶ Never allow brake fluid to flow into sewage, water courses or groundwater.
- ▶ Notify the relevant authorities if fluid penetrates the ground, water courses or the sewage system.
- ▶ Dispose of leaking brake fluid in an environmentally responsible way in accordance with statutory regulations.
- ▶ The brake system must be repaired immediately if brake fluid leaks out. Contact specialist dealer.

2.8.3 Battery vapour emission

Vapours may be emitted if the battery is damaged or used improperly. The vapours may cause respiratory tract irritation.

- 1 Get into fresh air.
- 2 Consult doctor in the event of pain or discomfort.

After contact with eyes

- 1 Carefully rinse eyes with plenty of water for at least 15 minutes. Protect unaffected eye.
- 2 Seek medical advice immediately.

After skin contact

- 1 Remove any solid particles immediately.
- 2 Remove contaminated clothing immediately.
- 3 Rinse the affected area with plenty of water for at least 15 minutes.
- 4 Then dab the affected skin gently. Do not rub dry.
- 5 Immediately consult a doctor if there is any redness, pain or discomfort.

2.8.4 Battery fire

The safety electronics may fail if the battery is damaged or faulty. The residual voltage can cause a short circuit. The battery may self-ignite and explode.

- 1 Keep your distance if the battery becomes deformed or starts to emit smoke.
 - 2 If charging, remove the plug connector from the socket.
 - 3 Contact the fire service immediately.
- ▶ Use Class D fire extinguishers to put out the fire.
 - ▶ Never extinguish damaged batteries with water or allow them to come into contact with water.

Inhaling vapours can cause intoxication.

- ▶ Stand on the side of the fire where the wind is blowing from.
- ▶ Use breathing apparatus if possible.

2.8.5 Oil and lubricant leaks from the fork

- ▶ Dispose of leaked oils and lubricants in an environmentally responsible way as per statutory regulations (see Section [10.1](#)).
- ▶ Contact specialist dealer.

2.9 Data privacy information

When the pedelec is connected to the diagnosis tool at the specialist dealer's, data is transferred to BOSCH eBike Systems (Robert Bosch GmbH) on the use of the Bosch drive unit, including its energy consumption and temperature, to help improve the product.

You will find more information on the Bosch eBike website:

- ▶ www.bosch-ebike.com.

3 Description

3.1 Proper use of city and trekking bicycles

All checklists and instructions for actions in these operating instructions must be observed. Specialist staff are permitted to install approved accessories.

Use the pedelec when it is in perfect, proper working order only. National requirements may apply to the pedelec which the standard equipment may not meet. Different regulations apply across the country to the riding light, reflectors and other components when riding on public roads. The general laws and the regulations on accident prevention and environmental protection in the respective country of use must be observed.

The rechargeable batteries are designed to supply power to the pedelec motor only. Never use the batteries for other purposes. Pedelec type

Each pedelec is assigned a pedelec type, which determines its proper use, function and area of use.

City and trekking bicycle



City and trekking bicycles are designed for comfortable, daily use and are suitable for riding on public roads.

Table 5: Proper use

3.1.1 Improper use

Failure to adhere to the pedelec's proper use poses a risk of personal injury and material damage. It is prohibited to use the pedelec in the following ways:

- When the electrical drive system has been manipulated
- Changing, eliminating or effacing frame numbers, nameplates or component serial numbers, or manipulating them in any other way
- Riding with a damaged or incomplete pedelec
- Riding over steps
- Riding through deep water
- Charging with an incorrect charger
- Lending the pedelec to untrained pedelec riders
- Carrying other people on the pedelec
- Riding with excessive baggage

- Riding with no hands
- Riding on ice and snow
- Improper servicing
- Improper repair
- Tough areas of use, such as professional competitions
- Acrobatics, riding up ramps, stunt riding or flying stunts.

City and trekking bicycle



City and trekking bicycles are not sports bicycles. If used for sports, the rider can expect reduced riding stability and diminished comfort.

Table 6: Improper use

3.1.2 Area of use

3.1.2.1 From model year 2024 onwards as per EN 17406







	Area of use	Average speed [km/h]	Unsuitability
 EN 17406	Use on normal, paved surfaces where the tyres should maintain contact with the ground at average speed with occasional jumps.	15 ... 25	<ul style="list-style-type: none"> • Never ride off road. • Never perform jumps over 15 cm.
 EN 17406	The area of use specified in Condition 1 applies. The vehicle can also be used on unpaved roads and gravel paths with moderate upward and downward slopes. Under these conditions, the bike may come into contact with uneven terrain and tyres may lose contact with the ground repeatedly.	15 ... 25	<ul style="list-style-type: none"> • Never ride off road. • Never perform jumps over 15 cm.
 EN 17406	The area of use specified in Condition 2 applies. The vehicle can also be used on rough paths, bumpy roads, difficult terrain and undeveloped tracks. Practice and technical skill is required for such rides.	Not relevant	<ul style="list-style-type: none"> • Never perform jumps over 60 cm. • Never use vehicle without practice. • Never use vehicle if you have no technical skills.
 EN 17406	The area of use specified in Condition 3 applies. The vehicle can also be used on descents on unpaved tracks at speeds up to 40 km/h.	Not relevant	<ul style="list-style-type: none"> • Never perform jumps over 120 cm. • Never use vehicle without practice. • Never use vehicle if you have no technical skills and are unable to handle a bike.
 EN 17406	The area of use specified in Condition 4 applies. The vehicle can also be used for extreme jumps or descents on unpaved tracks at speeds of more than 40 km/h or for a combination of the two.	Not relevant	<ul style="list-style-type: none"> • Never use vehicle without practice. • Never use vehicle if you have no extreme technical skills and are unable to handle the bike.
 EN 17406	The area of use specified in Condition 1 applies. The vehicle can also be used in competitions or for other purposes at speeds of more than 50 km/h (e.g. descents or sprints).	30 ... 55	<ul style="list-style-type: none"> • Never ride off road. • Never perform jumps over 15 cm. • Never use vehicle without practice. • Never use vehicle if you have no technical skills.

Table 7: Area of use, average speed and unsuitability

3.1.2.2 Up to model year 2023





	Area of use	Unsuitable terrain
 1	Suitable for tarmacked and paved roads.	Never ride off road or perform jumps.
 2	Suitable for tarmacked roads, cycle paths, firm gravel tracks and longer sections with moderate slopes and jumps up to 15 cm.	Never ride off road or perform jumps over 15 cm.
 3	Suitable for tarmacked roads, cycle paths and easy to demanding off-road riding, sections with moderate slopes and jumps up to 61 cm.	Never ride downhill or perform jumps over 61 cm.
 4	Suitable for tarmacked roads, cycle paths and easy to demanding off-road riding, limited downhill use and jumps up to 122 cm.	Never traverse extremely difficult off-road terrain or perform jumps over 122 cm.

Table 8: Area of use

3.2 Technical data

3.2.1 Complete BOSCH vehicle

Power output/system	250 W (0.25 kW)
Shut-off speed	25 km/h
Service life	7 years
Weight	See Section 3.1.3
PTW	See Section 3.1.4

Table 9: Technical data for pedelec

3.2.1.1 Emissions

The safety requirements as per Electromagnetic Compatibility Directive 2014/30/EU have been met. The pedelec and the charger can be used in residential areas without restriction.

A-weighted emission sound pressure level	<70 dB(A)
Total vibration level for the hands and arms	<2.5 m/s ²
Highest effective value of weighted acceleration for the entire body	<0.5 m/s ²

Table 10: Emissions from the pedelec

3.2.1.2 Environmental requirements

You can ride the pedelec within a temperature range between -5 °C and +40 °C. The electric drive system is limited in its performance outside this temperature range.

Operating temperature	-5 ... +40 °C
-----------------------	---------------

During winter use, especially at temperatures below 0 °C, we recommend that you don't insert a battery charged and stored at room temperature into the pedelec until just before setting off. We recommend using thermal protection sleeves when riding longer distances at low temperatures.

Temperatures under -10 °C and over +60 °C must be avoided as a general rule. Never put the battery in a car in summer or store it in direct sunlight.

You must also keep within the following temperature ranges.

Transportation temperature	+10 ... +40 °C
Storage temperature	+10 ... +40 °C
Work environment temperature	+15 ... +25 °C
Charging temperature	+10 ... +40 °C

The nameplate contains symbols for the pedelec's area of use.

- Check what tracks and roads you may ride on before setting off for the first time.

3.2.2 Dimensions

The pedelec may only be loaded to its *maximum permitted total weight* (PTW).

The maximum permitted total weight is

- the weight of the fully assembled pedelec
- plus body weight
- plus baggage.

Type no.	Model	PTW [kg]	Ready-to-use weight [kg]	Max. rider weight [kg]
H-01	S10 Adventure	150	24.9	120
H-02	E5 ZR F CX	150	24.4	120
H-03	RE 14 ZR F	140	#	#
H-04	E5 ZR F CX Century	150	24.4	120
H-05	E5 ZR F CX my i:SY	150	24.3	120
H-06	N3.8 ZR CX Comfort	150	25.2	120
J-01	XXL E5 ZR F CX	180	24.3	#
J-02	XXL RE 14 ZR F	180	#	#
J-03	XXL N3.8 ZR CX Comfort	180	26.4	150

Table 11: Type number, model, PTW and maximum body weight

3.2.3 Dimensions

The pedelec may only be loaded to its *maximum permitted total weight* (PTW).

The maximum permitted total weight is

- the weight of the fully assembled pedelec
- plus body weight
- plus baggage.

Type no.	Model	PTW [kg]	Ready-to-use weight [kg]	Max. rider weight [kg]
H-01	S10 Adventure	150	24.9	120
H-02	E5 ZR F CX	150	24.4	120
H-03	RE 14 ZR F	140	#	#
H-04	E5 ZR F CX Century	150	24.4	120
H-05	E5 ZR F CX my i:SY	150	24.3	120
H-06	N3.8 ZR CX Comfort	150	25.2	120
H-07	N3.8 ZR RT Comfort	#	#	#
H-08	E5 ZR F Adventure	#	#	#
J-01	XXL E5 ZR F CX	180	24.3	#
J-02	XXL RE 14 ZR F	180	#	#
J-03	XXL N3.8 ZR CX Comfort	180	26.4	150
J-04	N3.8 ZR RT Comfort	#	#	#

Table 12: Type number, model, PTW and maximum body weight

3.2.4 Environmental requirements

3.2.4.1 BOSCH

You can ride the pedelec within a temperature range between -5 °C and +40 °C. The electric drive system is limited in its performance outside this temperature range.

Operating temperature	-5 ... +40 °C
------------------------------	---------------

During winter use, especially at temperatures below 0 °C, we recommend that you don't insert a battery charged and stored at room temperature into the pedelec until just before setting off. We recommend using thermal protection sleeves when riding longer distances at low temperatures.

Temperatures under -10 °C and over +60 °C must be avoided as a general rule. Never put the battery in a car in summer or store it in direct sunlight.

You must also keep within the following temperature ranges.

Transportation temperature	+10 ... +40 °C
Storage temperature	+10 ... +40 °C
Work environment temperature	+15 ... +25 °C
Charging temperature	+10 ... +40 °C

The nameplate contains symbols for the pedelec's area of use.

- ▶ Check what tracks and roads you may ride on before setting off for the first time.

3.3 Nameplate

3.3.1 Model year 24

The nameplate is situated on the frame. The precise position of the nameplate is shown in Figure 3.

The nameplate contains up to twelve pieces of information.




Figure 1: Example of ZEG nameplate

No.	Designation	Description	More information
1	Type number	All pedelec models have an eight-digit type number, which is used to specify the design model year, the type of pedelec and the version.	Section 1.9
2	Manufacturer	You can contact the manufacturer at the address indicated.	Section 1.1
3	CE marking	The manufacturer uses the CE marking to declare that the pedelec complies with applicable requirements.	Section 13
4	Safety markings Caution	The safety markings warn of hazards.	Section 0.40
5	Read operating instructions	Read operating instructions	...
6	Pedelec type	Each pedelec is assigned a pedelec type, which determines its proper use, function and area of use.	Section 3.1.1
7	Disposal instructions	Follow the guidelines on waste disposal when disposing of the pedelec.	Section 10.1
8	Area of use	Ride pedelec in permitted locations only.	Section 3.1.4
9	Weight of the ready-to-ride pedelec (optional; only for pedelecs 25 kg or more)	The weight of the ready-to-ride pedelec is specified as a weight of 25 kg or above and refers to its weight at the time of purchase. Any extra accessories need to be added to the weight.	Section 4.1
10	Year of manufacture	The year of manufacture is the year in which the pedelec was manufactured.	...
11	Maximum permitted total weight (PTW)	The maximum permitted total weight is the weight of the fully assembled pedelec with the body weight plus the baggage.	Section 0.0.1
12	Shut-off speed	The speed that the pedelec reaches at the moment when the current has dropped to zero or to the no-load current value.	...
13	Maximum continuous power rating	The maximum continuous power rating is the greatest possible power for the electric motor output shaft over 30 minutes.	...

Table 13: Explanation of information on the nameplate

3.3.2 Up to model year MY23

The nameplate is situated on the frame. The precise position of the nameplate is shown in Figure 3.

The nameplate contains up to twelve pieces of information.




Figure 2: Example of i:SY nameplate

No.	Designation	Description	More information
1	CE marking	The manufacturer uses the CE marking to declare that the pedelec complies with applicable requirements.	Section 13
2	Manufacturer	You can contact the manufacturer at the address indicated.	Section 1.1
3	Type number	All pedelec models have a three-digit type number, which is used to specify the design model year, the type of pedelec and the version.	Section 1.6
4	Maximum continuous power rating	The maximum continuous power rating is the greatest possible power for the electric motor output shaft over 30 minutes.	
5	Maximum permitted total weight (PTW)	The maximum permitted total weight is the weight of the fully assembled pedelec with the body weight plus the baggage.	Section 0.0.1
6	Year of manufacture	The year of manufacture is the year in which the pedelec was manufactured.	
7	Pedelec type	Each pedelec is assigned a pedelec type, which determines its proper use, function and area of use.	Section
8	Safety markings	Safety markings warn of hazards.	Section 0.40
9	Disposal instructions	Follow the guidelines on waste disposal when disposing of the pedelec.	Section 13.1
10	Area of use for city and trekking bicycle	Ride pedelec in permitted locations only.	Section 3.1.5
11	Weight of the ready-to-ride pedelec (optional; only for pedelecs 25 kg or more)	The weight of the ready-to-ride pedelec is specified as a weight of 25 kg or above and refers to its weight at the time of purchase. Any extra accessories need to be added to the weight.	Section 5.1
12	Shut-off speed	The speed that the pedelec reaches at the moment when the current has dropped to zero or to the no-load current value.	

Table 14: Explanation of information on the nameplate

3.4 Components

3.4.1 Overview




Figure 3: Pedelec viewed from right

1	Wheel	11	Nameplate	20	Disc brake
2	Hub	12	Seat post	21	Belt
3	Fork	13	Saddle	22	Battery
4	Guard	14	Pannier rack	23	Chain guard
5	Front light	15	Rear light	24	Motor
6	Steering headset	16	Guard	25	Folding pedal
7	Handlebar extension	17	Wheel	26	Frame number
8	Handlebars	18	Kickstand	27	Disc brake
9	Stem	19	Hub		
10	Frame				

3.5 Parts list and repair instructions

H-01

Frame	HAOJIE, S10 ADVENTURE	
Tyres	SCHWALBE, Smart Sam	Size: ETRTO 60-406 (20 × 2.35 inches) Version: Performance; see Section #
Tube	SCHWALBE, AV7 (20")	Valve: AV; valve length: 40 mm; size: ETRTO 40/62-406 Version: Standard
Rim band variant	HERRMANS, HPM	Size: 18-406; thickness: 9 mm
	TAPIR, 6781	Size: 8 mm × 2000 mm; thickness: 0.30 mm; colour: Yellow
Rim	RYDE, Andra 40	14G, 32H
Spoke variant	MACH1, #	
	MACH1, Plus	14G, Ø: 2 mm; length: 179 mm; see Section #
	SAPIM, GNLE14	# Stainless steel 14G, 2 × 277 mm; see Section #
Spoke nipple variant	MACH1, 8CCBZ2014	Inside Ø: 14G; length: 20 mm
	SAPIM, Polyax	Inside Ø: 14G; length: 14 mm
Front wheel hub variant	SHIMANO, HB-MT400-B	32H; see Section #
	SHIMANO, HB-TC500-15-B	32H; see Section #
Rear wheel hub	SHIMANO, DEORE FH-M6000	Freewheel hub, 32H; see Section #
Steering headset	HAOJIE, GH-236	# ZS56/31.8/ 40
Stem	BY.SCHULZ, Speedlisfter Twist Pro SDS	# Height-adjustable stem; #extension height: 170 mm (T17) #Stem length: 55 mm; see Section #
	SATORI, All-Up 2.0 (SR-55)	for 1.5" stem
Handlebars	SATORI, Noir	# Length: 660 mm; #height: 35 mm; Ø: 31.8 mm; #backsweep: 20°; see Section #
Handles/tapered	ERGON, GP1-GFK-S	#
Fork	SR SUNTOUR, Mobie34 BOOST DS LO 15AH2-110 20"	Suspension fork
Saddle	VELO CYCLE, ZECURE VL-6483 L	# Size: L
Seat post	SATORI, Camber (SP-387)	Patented seat post, Ø: 34.9 mm; length: 415 mm; see Section #
Saddle clamp	HAOJIE	...
Pedal variant	i:SY, folding pedal	Folding pedal; see Section #
	VP COMP, VP-F55	Folding pedal; see Section #
Crank set	#, Magan 4 (110058)	Crank length: 160 mm; for BOSCH Gen4, ISIS
Chain/belt variant	SHIMANO, CN-HG54	Chain, # links; see Section #
	SHIMANO, CN-LG500	Chain, # links; see Section #
Chain wheel/belt sprocket variant	MIRANDA, CF3D/CL59	Chain wheel: 48T/Spider; see Section #
	MIRANDA, CL59	# Chain wheel: 42T/Spider; see Section #
	SAMOX, EMS05-BHV04-NS42T-C50	#Chain wheel, 42T; chainline: 50 mm
Chain guard variant	HORN, Catena A08/38	Plastic, #129203
	HORN, Catena A08/GR50	Plastic, #
Rear derailleur variant	SHIMANO, DEORE RD-M6000-GS	See Section #
	SHIMANO, TIAGRA RD-4700-GS	See Section #
Sprocket/belt sprocket/freewheel variant	SHIMANO, CS-HG500-10 (12-28T)	Cassette, 10-speed, 12-13-14-15-17-19-21-23-25-28T (12-28T); see Section #
	SHIMANO, CS-HG50-10 (11-36T)	Cassette, 10-speed, 11-13-15-17-19-21-24-28-32-36T (bk); see Section # (11-36T); see Section #
Shifter	SHIMANO, CUES SL-U6000-10R	Shifter with indicator, 10-speed
	SHIMANO, DEORE SL-T6000-R	Shifter with indicator, 10-speed
	SHIMANO, TIAGRA SL-4700	Shifter with indicator, 10-speed
Motor	BOSCH, Performance Line CX/Cargo [BDU3740](EB11.100.001)	See Section 3.5.06.1
On-board computer	BOSCH, LED Remote [BRC3600] (EB13.100.00E)	See Section #
Display	BOSCH, Kiox 300 [BHU3600] (EB13.100.003)	See Section #
Battery variant	BOSCH, PowerPack 600 [BBP3560] (EB12.100.00M)	#
	BOSCH, PowerPack Frame 545 [BBP3550] (EB12.100.02J)	#
Charger	BOSCH, 4A charger [BPC3400] (EB12.110.001)	Charging current (max.): 4 A, 220-240 V; see charger instructions

Brake variant 1	SHIMANO, BL-MT402-3A/BR-MT410	3-finger brake lever/length: 1700 mm/ Hydraulic disc brake, 2-piston
		3-finger brake lever/length: 1100 mm/ Hydraulic disc brake, 2-piston
		3-finger brake lever/length: 1200 mm/ Hydraulic disc brake, 2-piston
Brake variant 2	TEKTRO, # HD-T532	# 3-finger brake lever Length: 1200 mm/ Hydraulic disc brake, 2-piston
		# 3-finger brake lever Length: 1800 mm/ Hydraulic disc brake, 2-piston
Brake disc variant 1	SHIMANO, RT-EM300	Ø: 160 mm
	SHIMANO, SM-RT54	Ø: 160 mm
Brake disc variant 2	TEKTRO, TR-45	Ø: 180 mm
	TEKTRO, TR-45	Ø: 160 mm
Headlight variant	FUXON, FF-100 EB-HB	Light cable length: 1300 mm; remote control cable: 1200 mm; see Section #
	FUXON, FF-100 HB/FFB-70	Light cable length: 1100 mm; remote control cable: 850 mm; see Section #
Rear light	FUXON, R-Glow	Bolt distance: 50 mm; see Section #
Reflectors, rear	COMUS, FZR-006	#
Reflectors, side	BUSCH&MÜLLER, 309	Spoke reflectors
Pannier rack, rear	HAOJIE, HJ11CA12-21-03(QC-A186AA)	Drawing: HJ11CA12-21-03(QC-A186AA)
Mudguard, variant	SKS, PET A65 R275 20"	Drawing: 6744-790
	SKS, PET A65 R275 20"	Drawing: 6774-7907
Stand	PLETSCHER, Comp 40	Kickstand
Bell/horn variant	NUVO ENTERPRISE, n+1 B508AP	Bell, aluminium with plastic base. Bell cover diameter: 42 mm
	WIDEK, e-bike	Bell
Battery lock variant	ABUS, BLO	...
	ABUS, DT3	...

...not available

Information not available when document was produced

3.5.0.1 Components and repair parts for E5 ZR F CX

H02

Frame	HAOJIE, i:SY E5 ZR F Century	Aluminium, 47 cm
Tyres	SCHWALBE, SCHWALBE Pick-Up	Size: ETRTO 60-406 (20 × 2.35 inches) Version: Super Defense; see Section #
Tube	SCHWALBE, AV7 (20")	Valve: AV; valve length: 40 mm Size: ETRTO 40/62-406; version: Standard
Rim band variant	HERRMANS, HPM	Size: 18-406; thickness: 9 mm
	TAPIR, 6781	Size: 8 mm × 2000 mm; thickness: 0.30 mm Colour: Yellow
Rim	RYDE, Andra 40	14G, 32H
Spoke	MACH1, Plus	14G, Ø: 2 mm; length: 179 mm; see Section #
		14G, Ø: 2 mm; length: 152 mm; see Section #
Spoke nipple variant	MACH1, 8CCBZ2014	Inside Ø: 14G; length: 20 mm
	SAPIM, Polyax	Inside Ø: 14G; length: 14 mm
Front wheel hub	SHIMANO, DEORE HB-M6000	32H; see Section #
Rear wheel hub	SHIMANO, NEXUS SG-C7000-5D	Mechanical gear hub, 5-speed, 32H
Steering headset	HAOJIE, GH-236	# ZS56/31.8 / 40
Stem	BY.SCHULZ, Speedlifter Twist	# Stem extension, #extension height: 220 mm (T22), shaft Ø: # mm; reducing sleeve height: # mm; see Section #
Stem	SATORI, TDS-D507G-8FOV	# Ø: 31.8 mm; extension: 70 mm; see Section #
Handlebars	SATORI, Roxetta	Length: 660, see Section #
Handles/tapered	Ergon, GC1	Winged grips, NEXUS
Fork	i:SY	Rigid fork, shaft length: 300 mm
Saddle	VELO CYCLE, ZECURE VL-6483 L	# Size: L
Seat post	SATORI, Camber (SP-387)	Patented seat post, Ø: 34.9 mm; length: 415 mm; see Section #
Saddle clamp	HAOJIE	...
Pedal	i:SY, folding pedal	Folding pedal; see Section #
	VP COMP, VP-F55	Folding pedal; see Section #
Crank set	#, Magan 4 (110058)	Crank length: 160 mm, ISIS
Chain/belt	GATES®, CDX-B-118 (11M-118T-12CT)	# Belt, polyurethane/carbon; pitch: 11, number of teeth: 118; width: 12 mm; length: 1298 mm
Chain wheel/belt sprocket	GATES®, BOSCH GEN4 Spider Unit CDX	Belt sprocket, 46T
Chain guard	HORN, Catena A08/38	Plastic, #129203
Sprocket/belt sprocket/freewheel	GATES®, SHIMANO Inter-5E SF 6L combined (CT1128YMN-U)	Belt sprocket, 28T
Shifter	SHIMANO, NEXUS SL-C7000-5	Twist grip shifter with indicator, 5-speed; see Section #
Motor	BOSCH, Performance Line CX/Cargo [BDU3740](EB11.100.001)	See Section 3.5.06.1
On-board computer	BOSCH, LED Remote [BRC3600] (EB13.100.00E)	See Section #
Display variant	BOSCH, Kiox 300 [BHU3600] (EB13.100.003)	See Section #
	BOSCH, Kiox 500 [BHU3700] (EB13.100.004)	See Section #

Control panel	SHIMANO, SW-E7000-R	See Section 3.5.2
Battery variant	BOSCH, PowerPack 600 [BBP3560] (EB12.100.00M)	#
	BOSCH, PowerPack Frame 545 [BBP3550] (EB12.100.02J)	#
Charger	BOSCH, 4A charger [BPC3400] (EB12.110.001)	Charging current (max.): 4 A, 220-240 V; see charger instructions
Brake, front, variant 1	SHIMANO, BL-MT402-3A/BR-MT420	3-finger brake lever/length: 1100 mm/ Hydraulic disc brake, 2-piston
Brake, rear, variant 1		3-finger brake lever/length: 1200 mm/ Hydraulic disc brake, 2-piston
Brake, front, variant 2	TEKTRO, # HD-T532	# 3-finger brake lever Length: 1200 mm/ Hydraulic disc brake, 2-piston
Brake, rear, variant 2		# 3-finger brake lever Length: 1800 mm/ Hydraulic disc brake, 2-piston
Brake disc, front, variant 1	SHIMANO, RT-EM300	Ø: 160 mm
Brake disc, rear, variant 1	SHIMANO, SM-RT54	Ø: 160 mm
Brake disc, front, variant 2	TEKTRO, TR-45	Ø: 180 mm
Brake disc, rear, variant 2	TEKTRO, TR-45	Ø: 160 mm
Headlight	FUXON, FF-100 EB-HB	Light cable length: 1300 mm; remote control cable: 1200 mm; see Section #
Rear light	FUXON, R-Glow	Bolt distance: 50 mm; see Section #
Reflectors, rear	COMUS, FZR-006	#
Pannier rack, rear	HAOJIE, HJ11CA12-21-03(QC-A186AA)	Drawing: HJ11CA12-21-03(QC-A186AA)
Motor cover guard	BOSCH, EB11.200.00Y	Design motor cover for Performance Line CX Left (BDU374Y); see Section #
Mudguard, rear	SKS, PET A65 R275 20"	Drawing: 6744-790
Mudguard, front	SKS, PET A65 R275 20"	Drawing: 6774-7907
Stand	PLETSCHER, Comp 40	Kickstand
Bell/horn variant	NUVO ENTERPRISE, n+1 B508AP	Bell, aluminium with plastic base. Bell cover diameter: 42 mm
	WIDEK, e-bike	Bell
Battery lock variant	ABUS, BLO	...
	ABUS, DT2	...
	ABUS, DT3	...

...not available

Information not available when document was produced

3.5.0.2 Components and repair parts for RE 14 ZR F

H-03

Frame	Original i:SY Compact, 47 cm, unisex	Aluminium, 47 cm
Rear frame damper
Tyres Front Rear	SCHWALBE, Pick up	Size: 60-406 (20"); see Section 3.5.11
Tube Front Rear	SCHWALBE, AV7	40/62-406 See Section 3.5.12
Wheel
Rim Front Rear	RYDE, Andra 40 Disc	32H
Spoke Front Rear	Stainless steel	32 units, 2.0 mm
Spoke nipples Front Rear	#	#
Front wheel hub	SHIMANO, DEORE HB-M6000-QR	Front wheel hub, 36H; see Section 3.5.10
Rear wheel hub	ROHLOFF Speedhub 500/14	Gear hub, 14-speed; see Section 3.5.10
Steering headset	i:SY headset	#
Stem	ZECURE, All-Up 2.0	90 mm
Handlebars	i:SY, handlebars	30°, 630 mm
Handles/tapered Left hand Right hand	ERGON, GP10	Winged grips
Fork	i:SY fork	Rigid fork, aluminium (AL6066/CR-MO) Head tube: 1 1/2" - 1 1/4" x 450 mm Crown, diameter: 62 mm Fork clearance: 295 mm
Fork remote control
Saddle	VELO ENTERPRISE, #	ZECURE, #
Seat post	#	i:SY seat post
Saddle clamp	#	#
Pedal	i:SY anti-slip folding pedal	...
Crank set	i:SY e-bike crank	Length: 160 mm
Chain/belt	GATES, CDX	Toothed belt
Chain wheel/belt sprocket	#	#
Chain guard	HORN, Catena	...
Chain guide
Motor	BOSCH™, Performance Line CX (BDU3740)	See Section 3.6.7
On-board computer	BOSCH™, LED Remote (BRC3600)	See Section 3.6.5
Display	BOSCH™, Kiox300 (BHU3600) Display mount (BDS3YYY)	See Section 3.6.6 See Section 3.6.7
Control panel
Battery	BOSCH™, PowerPack 545 (#)	See Section 3.6.8
Charger	BOSCH™, 4A Charger (BPC3400)	Charger, charging current (max.): 4 A

Brake lever Front Rear	TEKTRO, HD-T532	3-finger lever
Brake Front Rear	TEKTRO, HD-T532	Hydraulic disc brake 4 pistons 2 pistons
Brake disc Front Rear	TEKTRO, TR180 TEKTRO, TR160	Steel, Ø 180 mm Ø 160 mm
ABS
Shifter	ROHLOFF, Speedhub 500/14 shifter	Twist grip gear, 14 speed
Rear derailleur
Front derailleur
Sprocket
Spoke guard	#	#
Headlight	FUXON, FF-100HB	With main beam function; see Section 3.5.9
Rear light	FUXON, R-GLOW	LED 6-12 V DC With Z-reflector
Reflectors Front Rear Side	On front light On rear light Wheel	...
Pannier rack, front
Pannier rack, rear	i:SY Carrier	Pannier rack, MonkeyLoad ready
Guard Front Rear	SKS, Bluemels	20 Inch, 65 mm wide
Kickstand	Pletscher Comp40 Flex	Kickstand
Bell/horn	#	#
Mirror
Battery lock	ABUS, 4750L NR	Frame lock
Chain lock
Bottle holder

...not available

Information not available when document was produced

3.5.0.3 Components and repair parts for E5 ZR F Century

H-04

Frame	Original i:SY Compact, 47 cm, unisex	Aluminium, 47 cm
Tyres	SCHWALBE, Super Moto-X	# Size: ETRTO 62-406 (#) Version: GreenGuard
Tube	SCHWALBE, AV7 (20")	Valve: AV; valve length: 40 mm Size: ETRTO 40/62-406; version: Standard
Rim band	TAPIR, 6781	Size: 8 mm × 2000 mm; thickness: 0.30 mm Colour: Yellow
Rim	RYDE, Andra 40	14G, 32H
Spoke	MACH1, Plus	14G, Ø: 2 mm; length: 179 mm; see Section #
		14G, Ø: 2 mm; length: 152 mm; see Section #
Spoke nipples	SAPIM, Polyax	Inside Ø: 14G; length: 14 mm
Front wheel hub	SHIMANO, DEORE HB-M6000	32H; see Section #
Rear wheel hub	SHIMANO, NEXUS SG-C7000-5D	Mechanical gear hub, 5-speed, 32H
Steering headset	HAOJIE, GH-236	# ZS56/31.8/ 40
Stem	BY.SCHULZ, Speedlifter Twist	# Stem extension, #extension height: 220 mm (T22), shaft Ø: # mm; reducing sleeve height: # mm; see Section #
	SATORI, TDS-D507G-8FOV	# Ø: 31.8 mm; extension: 70 mm; see Section #
Handlebars	SATORI, Roxetta	Length: 660, see Section #
Handles/tapered	VELO ENTERPRISE, #	#
Fork	i:SY	Rigid fork, shaft length: 300 mm
Saddle	BROOKS, B17	See Section #
Seat post	SATORI, Camber (SP-387)	Patented seat post, Ø: 34.9 mm; length: 415 mm; see Section #
Saddle clamp	HAOJIE	...
Pedal	i:SY, folding pedal	Folding pedal; see Section #
Crank set	#, Magan 4 (110058)	Crank length: 160 mm, ISIS
Chain/belt	GATES®, 118T CDX (11M-118T-12CT)	# Belt, polyurethane/carbon; pitch: 11, number of teeth: 118; width: 12 mm; length: # mm
Chain wheel/belt sprocket	GATES®, BOSCH GEN4 Spider Unit CDX	Belt sprocket, 46T
Chain guard	HORN, Catena A08/38	Plastic, #129203
Sprocket/belt sprocket/freewheel	GATES®, SHIMANO Inter-5E SF 6L combined (CT1128YMN-U)	Belt sprocket, 28T
Shifter	SHIMANO, NEXUS SL-C7000-5	Twist grip shifter with indicator, 5-speed; see Section #
Motor	BOSCH, Performance Line CX/Cargo [BDU3740](EB11.100.001)	See Section 3.5.06.1
On-board computer	BOSCH, LED Remote [BRC3600] (EB13.100.00E)	See Section #
Display	BOSCH, Kiox 500 [BHU3700] (EB13.100.004)	See Section #
Battery	BOSCH, PowerPack Frame 545 [BBP3550] (EB12.100.02J)	#
Charger	BOSCH, 4A charger [BPC3400] (EB12.110.001)	Charging current (max.): 4 A, 220-240 V; see charger instructions
Front brake	TEKTRO, # HD-T532	# 3-finger brake lever Length: 1200 mm/ Hydraulic disc brake, 2-piston

Rear brake	TEKTRO, # HD-T532	# 3-finger brake lever Length: 1800 mm/ Hydraulic disc brake, 2-piston
Front brake disc	TEKTRO, TR-45	Ø: 180 mm
Rear brake disc	TEKTRO, TR-45	Ø: 160 mm
Headlight	FUXON, FF-100 EB-HB	Light cable length: 1300 mm; remote control cable: 1200 mm; see Section #
Rear light	FUXON, R-Glow	Bolt distance: 50 mm; see Section #
Reflectors, rear	COMUS, FZR-006	#
Pannier rack, front	STECO, R30.358.00	Drawing: R30.358.00, with KlickFix
Pannier rack, rear	HAOJIE, HJ11CA12-21-03(QC-A186AA)	Drawing: HJ11CA12-21-03(QC-A186AA)
Mudguard, rear	SKS, PET A65 R275 20"	Drawing: 6744-790
Mudguard, front	SKS, PET A65 R275 20"	Drawing: 6774-7907
Stand	PLETSCHER, Comp 40	Kickstand
Bell/horn	WIDEK, e-bike	Bell
Battery lock	ABUS, BLO	...

...not available

Information not available when document was produced

3.5.0.4 Components and repair parts for E5 ZR F CX MY i:SY

H-05

Frame	HAOJIE, i:SY E5 ZR F Century	Aluminium, 47 cm
Tyres	SCHWALBE, SCHWALBE Pick-Up	Size: ETRTO 60-406 (20 × 2.35 inches) Version: Super Defense; see Section #
Tube	SCHWALBE, AV7 (20")	Valve: AV; valve length: 40 mm Size: ETRTO 40/62-406; version: Standard
Rim band	TAPIR, 6781	Size: 8 mm × 2000 mm; thickness: 0.30 mm Colour: Yellow
Rim	RYDE, Andra 40	14G, 32H
Spoke	MACH1, Plus	14G, Ø: 2 mm; length: 179 mm; see Section #
		14G, Ø: 2 mm; length: 152 mm; see Section #
Spoke nipples	SAPIM, Polyax	Inside Ø: 14G; length: 14 mm
Front wheel hub	SHIMANO, DEORE HB-M6000	32H; see Section #
Rear wheel hub	SHIMANO, NEXUS SG-C7000-5D	Mechanical gear hub, 5-speed, 32H
Steering headset	HAOJIE, GH-236	# ZS56/31.8/ 40
Stem	BY.SCHULZ, Speedlifter Twist	# Stem extension, #extension height: 220 mm (T22), shaft Ø: # mm; reducing sleeve height: # mm; see Section #
	SATORI, TDS-D507G-8FOV	# Ø: 31.8 mm; extension: 70 mm; see Section #
Handlebars	SATORI, Roxetta	Length: 660, see Section #
Handles/tapered	Ergon, GC1	Winged grips, NEXUS
Fork	i:SY	Rigid fork, shaft length: 300 mm
Saddle	VELO CYCLE, ZECURE VL-6483 L	# Size: L
Seat post	SATORI, Camber (SP-387)	Patented seat post, Ø: 34.9 mm; length: 415 mm; see Section #
Saddle clamp	HAOJIE	...
Pedal	i:SY, folding pedal	Folding pedal; see Section #
Crank set	#, Magan 4 (110058)	Crank length: 160 mm, ISIS
Chain/belt	GATES®, 118T CDX (11M-118T-12CT)	# Belt, polyurethane/carbon; pitch: 11, number of teeth: 118; width: 12 mm; length: # mm
Chain wheel/belt sprocket	GATES®, BOSCH GEN4 Spider Unit CDX	Belt sprocket, 46T
Chain guard	HORN, Catena A08/38	Plastic, #129203
Sprocket/belt sprocket/freewheel	GATES®, SHIMANO Inter-5E SF 6L combined (CT1128YMN-U)	Belt sprocket, 28T
Shifter	SHIMANO, NEXUS SL-C7000-5	Twist grip shifter with indicator, 5-speed; see Section #
Motor	BOSCH, Performance Line CX/Cargo [BDU3740](EB11.100.001)	See Section 3.5.06.1
On-board computer	BOSCH, LED Remote [BRC3600] (EB13.100.00E)	See Section #
Display	BOSCH, Kiox 500 [BHU3700] (EB13.100.004)	See Section #
Battery	BOSCH, PowerPack Frame 545 [BBP3550] (EB12.100.02J)	#
Charger	BOSCH, 4A charger [BPC3400] (EB12.110.001)	Charging current (max.): 4 A, 220-240 V; see charger instructions
Front brake	TEKTRO, # HD-T532	# 3-finger brake lever Length: 1200 mm/ Hydraulic disc brake, 2-piston

Rear brake	TEKTRO, # HD-T532	# 3-finger brake lever Length: 1800 mm/ Hydraulic disc brake, 2-piston
Front brake disc	TEKTRO, TR-45	Ø: 180 mm
Rear brake disc	TEKTRO, TR-45	Ø: 160 mm
Headlight	FUXON, FF-100 EB-HB	Light cable length: 1300 mm; remote control cable: 1200 mm; see Section #
Rear light	FUXON, R-Glow	Bolt distance: 50 mm; see Section #
Reflectors, rear	COMUS, FZR-006	#
Pannier rack, front	STECO, R30.358.00	Drawing: R30.358.00, with KlickFix
Pannier rack, rear	HAOJIE, HJ11CA12-21-03(QC-A186AA)	Drawing: HJ11CA12-21-03(QC-A186AA)
Motor cover guard	BOSCH, EB11.200.00Y	Design motor cover for Performance Line CX Left (BDU374Y); see Section #
Mudguard, rear	SKS, PET A65 R275 20"	Drawing: 6744-790
Mudguard, front	SKS, PET A65 R275 20"	Drawing: 6774-7907
Stand	PLETSCHER, Comp 40	Kickstand
Bell/horn	WIDEK, e-bike	Bell
Battery lock	ABUS, BLO	...

...not available

Information not available when document was produced

3.5.0.5 Components and repair parts for N3.8 ZR CX COMFORT

H-06

Frame	HAOJIE, i:SY E5 ZR F Century	Aluminium, 47 cm
Tyres	SCHWALBE, SCHWALBE Pick-Up	# Size: ETRTO 65-406 (#) Version: Super Defense
Tube variants	SCHWALBE, AV7 + AP	Valve: AV; valve length: 40 mm Size: ETRTO 47/75-470; version: Downhill
	SCHWALBE, AV7D Downhill (20")	Valve: AV; valve length: 40 mm Size: ETRTO 54/75-406; version: Downhill
Rim band	TAPIR, 6781	Size: 8 mm × 2000 mm; thickness: 0.30 mm Colour: Yellow
Rim	RYDE, Andra 40	14G, 32H
Spoke	MACH1, Plus	14G, Ø: 2 mm; length: 179 mm; see Section #
		14G, Ø: 2 mm; length: 138 mm; see Section #
Spoke nipples	SAPIM, Polyax	Inside Ø: 14G; length: 14 mm
Front wheel hub	SHIMANO, DEORE HB-M6000	32H; see Section #
Rear wheel hub	ENVILOLO, CVP-TR-32-DC	Gear hub, continuously variable, 36H; see Section #
Steering headset	HAOJIE, GH-236	# ZS56/31.8/ 40
Stem	BY.SCHULZ, Speedlisfter Twist Pro SDS	# Height-adjustable stem; #extension height: 170 mm (T17); #stem length: 55 mm; see Section #
Handlebars	SATORI, Noirette	Length: 630; rise: 40 mm; backsweep: 45°; see Section #
Handles/tapered	Ergon, GC1	Winged grips, NEXUS
Fork	i:SY	Rigid fork, shaft length: 300 mm
Saddle	VELO CYCLE, ZECURE VL-6546 XL COMF	# Size: XL COMF
Seat post	BY.SCHULZ, G.2 ST	Parallelogram seat post, Ø: 34.9 mm Length: 400 mm; see Section #
Saddle clamp	HAOJIE	...
Pedal	i:SY, folding pedal	Folding pedal; see Section #
Crank set	#, Magan 4 (110058)	Crank length: 160 mm, ISIS
Chain/belt	GATES®, 120T CDX (11M-120T-12C)	# Belt, polyurethane/carbon; pitch: 11, number of teeth: 120; width: 12 mm; length: 1320 mm
Chain wheel/belt sprocket	GATES®, BOSCH GEN4 Spider Unit CDX	Belt sprocket, 55T
Chain guard	HORN, Catena A08/38	Plastic, #129203
Sprocket/belt sprocket/ freewheel variant	GATES®, 22T ENVILOLO CDX (CT1122VMN)	Belt sprocket, 22T
	GATES®, 22T Enviolo CDX (XF1122E9MN)	Belt sprocket, 22T
Shifter	ENVILOLO, Twist Display Pro (MC-TWIST-DISP-PRO)	Twist grip shifter with indicator; see Section #
Motor	BOSCH, Performance Line CX/Cargo [BDU3740](EB11.100.001)	See Section 3.5.06.1
On-board computer	BOSCH, LED Remote [BRC3600] (EB13.100.00E)	See Section #
Display	BOSCH, Kiox 500 [BHU3700] (EB13.100.004)	See Section #
Battery	BOSCH, PowerPack Frame 545 [BBP3550] (EB12.100.02J)	#
Charger	BOSCH, 4A charger [BPC3400] (EB12.110.001)	Charging current (max.): 4 A, 220-240 V; see charger instructions

Front brake	TEKTRO, # HD-T532	# 3-finger brake lever Length: 1200 mm/ Hydraulic disc brake, 2-piston
Rear brake	TEKTRO, # HD-T532	# 3-finger brake lever Length: 1800 mm/ Hydraulic disc brake, 2-piston
Rear brake disc	TEKTRO, TR-17	Ø: 160 mm
Front brake disc	TEKTRO, TR-45	Ø: 180 mm
Headlight	FUXON, FF-100 EB-HB	Light cable length: 1300 mm; remote control cable: 1200 mm; see Section #
Rear light	FUXON, R-Glow	Bolt distance: 50 mm; see Section #
Reflectors, rear	COMUS, FZR-006	#
Pannier rack, rear	HAOJIE, HJ11CA12-21-03(QC-A186AA)	Drawing: HJ11CA12-21-03(QC-A186AA)
Mudguard, variant	SKS, #	Drawing: 6774-1206
	SKS, #	Drawing: 6744-7908
Stand	PLETSCHER, Comp 40	Kickstand
Bell/horn	WIDEK, e-bike	Bell
Battery lock	ABUS, BLO	...

...not available

Information not available when document was produced

3.5.0.6 Components and repair parts for N3.8 ZR Auto Comfort


H-07





3.5.0.7 Components and repair parts for E5 ZR F Adventure

H-08





3.5.0.8 Components and repair parts for XXL E5 ZR F CX

J-03

Frame	HAOJIE, i:SY XXL	Aluminium; size: 50.6 cm
Tyres	SCHWALBE, SCHWALBE Pick-Up	Size: ETRTO 60-406 (20 × 2.35 inches) Version: Super Defense; see Section #
Tube	SCHWALBE, AV7 (20")	Valve: AV; valve length: 40 mm Size: ETRTO 40/62-406; version: Standard
Rim band	HERRMANS, HPM	Size: 18-406; thickness: 9 mm
Rim band	TAPIR, 6781	Size: 8 mm × 2000 mm; thickness: 0.30 mm Colour: Yellow
Rim	RYDE, Andra 40	14G, 32H
Spoke	MACH1, Plus	14G, Ø: 2 mm; length: 179 mm; see Section #
		14G, Ø: 2 mm; length: 152 mm; see Section #
Spoke nipple variants	MACH1, 8CCBZ2014	Inside Ø: 14G; length: 20 mm
	SAPIM, Polyax	Inside Ø: 14G; length: 14 mm
Front wheel hub	SHIMANO, DEORE HB-M6000	32H; see Section #
Rear wheel hub	SHIMANO, NEXUS SG-C7000-5D	Mechanical gear hub, 5-speed, 32H
Steering headset	HAOJIE, GH-236	# ZS56/31.8 40
Stem	BY.SCHULZ, Speedlifter Twist	# Stem extension, #extension height: 220 mm (T22), shaft Ø: # mm; reducing sleeve height: # mm; see Section #
	SATORI, TDS-D507G-8FOV	# Ø: 31.8 mm; extension: 70 mm; see Section #
Handlebars	SATORI, Roxetta	Length: 660, see Section #
Handles/tapered	Ergon, GC1	Winged grips, NEXUS
Fork	i:SY	Rigid fork, shaft length: 450 mm
Saddle	VELO CYCLE, ZECURE VL-6483 L	# Size: L
Seat post	SATORI, Camber (SP-387)	Patented seat post, Ø: 34.9 mm; length: 415 mm; see Section #
Saddle clamp	HAOJIE	...
Pedal	i:SY, folding pedal	Folding pedal; see Section #
	VP COMP, VP-F55	Folding pedal; see Section #
Crank set	#, Magan 3 (110017)	Crank length: 170 mm; for BOSCH Gen3, ISIS
Chain/belt	GATES®, 125T CDX (11M-125T-12CT)	# Belt, polyurethane/carbon; pitch: 11, number of teeth: 125; width: 12 mm; length: # mm
Chain wheel/belt sprocket	GATES®, BOSCH GEN4 Spider Unit CDX	Belt sprocket, 48T
Chain guard	HORN, Catena A08/GR50	Plastic, #
Sprocket/belt sprocket/freewheel	GATES®, SHIMANO Inter-5E SF 6L combined (CT1128YMN-U)	Belt sprocket, 28T
Shifter	SHIMANO, NEXUS SL-C7000-5	Twist grip shifter with indicator, 5-speed; see Section #
Motor	BOSCH, Performance Line CX/Cargo [BDU3740](EB11.100.001)	See Section 3.5.06.1
On-board computer	BOSCH, LED Remote [BRC3600] (EB13.100.00E)	See Section #
Display	BOSCH, Kiox 300 [BHU3600] (EB13.100.003)	See Section #
Display	BOSCH, Kiox 500 [BHU3700] (EB13.100.004)	See Section #

Control panel	SHIMANO, SW-E7000-R	See Section 3.5.2
Battery	BOSCH, PowerPack 600 [BBP3560] (EB12.100.00M)	#
Battery	BOSCH, PowerPack Frame 545 [BBP3550] (EB12.100.02J)	#
Charger	BOSCH, 4A charger [BPC3400] (EB12.110.001)	Charging current (max.): 4 A, 220-240 V; see charger instructions
Brake, rear, variant 1	SHIMANO, BL-MT402-3A/BR-MT410	3-finger brake lever/length: 1800 mm/ Hydraulic disc brake, 2-piston
Brake, front, variant 1	SHIMANO, BL-MT402-3A/BR-MT420	3-finger brake lever/length: 1200 mm/ Hydraulic disc brake, 2-piston
Brake, front, variant 2	TEKTRO, # HD-T532	# 3-finger brake lever Length: 1200 mm/ Hydraulic disc brake, 2-piston
Brake, rear, variant 2	TEKTRO, # HD-T532	# 3-finger brake lever Length: 1800 mm/ Hydraulic disc brake, 2-piston
Brake disc variant 1	SHIMANO, RT-EM300	Ø: 160 mm
	SHIMANO, SM-RT54	Ø: 160 mm
Brake disc, front, variant 2	TEKTRO, TR-45	Ø: 180 mm
Brake disc, rear, variant 2	TEKTRO, TR-45	Ø: 160 mm
Headlight	FUXON, FF-100 EB-HB	Light cable length: 1300 mm; remote control cable: 1200 mm; see Section #
Rear light	FUXON, R-Glow	Bolt distance: 50 mm; see Section #
Reflectors, rear	COMUS, FZR-006	#
Pannier rack, front	STECO, R30.358.00	Drawing: R30.358.00, with KlickFix
Pannier rack, rear	HAOJIE, HJ11CA12-21-03(QC-A186AA)	Drawing: HJ11CA12-21-03(QC-A186AA)
Motor cover guard	BOSCH, EB11.200.00Y	Design motor cover for Performance Line CX Left (BDU374Y); see Section #
Mudguard, rear	SKS, PET A65 R275 20"	Drawing: 6744-790
Mudguard, front		Drawing: 6774-7907
Stand	PLETSCHER, Comp 40	Kickstand
Bell/horn variant	NUVO ENTERPRISE, n+1 B508AP	Bell, aluminium with plastic base. Bell cover diameter: 42 mm
	WIDEK, e-bike	Bell
Battery lock variant	ABUS, BLO	...
	ABUS, DT2	...
	ABUS, DT3	...

...not available

Information not available when document was produced

3.5.0.9 Components and repair parts for XXL RE 14 ZR F

J-02

Frame	Original i:SY Compact, 47 cm, unisex	Aluminium, 47 cm
Rear frame damper
Tyres Front Rear	SCHWALBE, Pick up	Size: 60-406 (20") See Section 3.5.11
Tube Front Rear	SCHWALBE, AV7	40/62-406 See Section 3.5.12
Wheel
Rim Front Rear	RYDE, Andra 40 Disc	32H
Spoke Front Rear	Stainless steel	32 units, 2.0 mm
Spoke nipples Front Rear	#	#
Front wheel hub	SHIMANO, DEORE HB-M6000-QR	Front wheel hub, 36H; see Section 3.5.10
Rear wheel hub	ROHLOFF Speedhub 500/14	Gear hub, 14-speed; see Section 3.5.10
Steering headset	i:SY headset	#
Stem	i:SY, stem BY.SCHULZ, Speedlifter Twist	70 mm Tool-free handlebar height adjustment Twist function: Twist \pm 90° Handlebar clamp: \varnothing 31.8 mm T22
Handlebars	i:SY, handlebars	30°, 630 mm
Handles/tapered Left hand Right hand	ERGON, GP10	Winged grips
Fork	i:SY fork	Rigid fork, aluminium (AL6066/CR-MO) Head tube: 1 1/2" - 1 1/4" x 450 mm Crown, diameter: 62 mm Fork clearance: 295 mm
Fork remote control
Saddle	VELO ENTERPRISE, #	ZECURE, #
Seat post	#	i:SY seat post
Saddle clamp	#	#
Pedal	i:SY anti-slip folding pedal	...
Crank set	i:SY e-bike crank	Length: 170 mm
Chain/belt	GATES, CDX	Toothed belt
Chain wheel/belt sprocket	#	#
Chain guard	HORN, Catena	...
Chain guide
Motor	BOSCH™, Performance Line CX (BDU3740)	See Section 3.6.7
On-board computer	BOSCH™, LED Remote (BRC3600)	See Section 3.6.5
Display	BOSCH™, Kiox300 (BHU3600) Display mount (BDS3YYY)	See Section 3.6.6 See Section 3.6.7
Control panel

Battery	BOSCH™, PowerPack 545 (#)	See Section 3.6.8
Charger	BOSCH™, 4A Charger (BPC3400)	Charger, charging current (max.): 4 A
Brake lever Front Rear	TEKTRO, HD-T532	3-finger lever
Brake Front Rear	TEKTRO, HD-T532	Hydraulic disc brake 4 pistons 2 pistons
Brake disc Front Rear	TEKTRO, TR180 TEKTRO, TR160	Steel, Ø 180 mm Ø 160 mm
ABS
Shifter	ROHLOFF, Speedhub 500/14 shifter	Twist grip gear, 14 speed
Rear derailleur
Front derailleur
Sprocket
Spoke guard	#	#
Headlight	FUXON, FF-100HB	With main beam function; see Section 3.5.9
Rear light	FUXON, R-GLOW	LED 6-12 V DC With Z-reflector
Reflectors Front Rear Side	On front light On rear light Wheel	...
Pannier rack, front
Pannier rack, rear	i:SY Carrier	Pannier rack, MonkeyLoad ready
Guard Front Rear	SKS, Bluemels	20 Inch, 65 mm wide
Kickstand	Pletscher Comp40 Flex	Kickstand
Bell/horn	#	#
Mirror
Battery lock	ABUS, 4750L NR	Frame lock
Chain lock
Bottle holder

...not available

Information not available when document was produced

3.5.0.10 Components and repair parts for XXL E5 ZR F CX

J-03

Frame	HAOJIE, i:SY XXL	Size: 50.6 cm
Tyres	SCHWALBE, SCHWALBE Pick-Up	# Size: ETRTO 65-406 (#) Version: Super Defense
Tube variants	SCHWALBE, AV7 + AP	Valve: AV; valve length: 40 mm Size: ETRTO 47/75-470; version: Downhill
	SCHWALBE, AV7D Downhill (20")	Valve: AV; valve length: 40 mm Size: ETRTO 54/75-406; version: Downhill
Rim band	TAPIR, 6781	Size: 8 mm × 2000 mm; thickness: 0.30 mm Colour: Yellow
Rim	RYDE, Andra 40	14G, 32H
Spoke	MACH1, Plus	14G, Ø: 2 mm; length: 179 mm; see Section #
		14G, Ø: 2 mm; length: 138 mm; see Section #
Spoke nipples	SAPIM, Polyax	Inside Ø: 14G; length: 14 mm
Front wheel hub	SHIMANO, DEORE HB-M6000	32H; see Section #
Rear wheel hub	ENVILOLO, CVP-HD-SA-32-DC	Gear hub, continuously variable, 36H; see Section #
Steering headset	HAOJIE, GH-236	# ZS56/31.8 / 40
Stem	BY.SCHULZ, Speedlifter Twist Pro SDS	# Height-adjustable stem; #extension height: 170 mm (T17); #stem length: 55 mm; see Section #
Handlebars	SATORI, Noirette	Length: 630; rise: 40 mm; backsweep: 45°; see Section #
Handles/tapered	Ergon, GC1	Winged grips, NEXUS
Fork	i:SY	Rigid fork, shaft length: 450 mm
Saddle	VELO CYCLE, ZECURE VL-6546 XL COMF	# Size: XL COMF
Seat post	BY.SCHULZ, G.2 LT	Patented seat post, Ø: 34.9 mm; length: 480 mm; see Section #
Saddle clamp	HAOJIE	...
Pedal	i:SY, folding pedal	Folding pedal; see Section #
Crank set	#, Magan 3 (110017)	Crank length: 170 mm; for BOSCH Gen3, ISIS
Chain/belt	GATES®, 125T CDX (11M-125T-12CT)	# Belt, polyurethane/carbon; pitch: 11, number of teeth: 125; width: 12 mm; length: # mm
Chain wheel/belt sprocket	GATES®, BOSCH GEN4 Spider Unit CDX	Belt sprocket, 55T
Chain guard	HORN, Catena A08	Plastic, #
Sprocket/belt sprocket/freewheel	GATES®, 22T ENVILOLO CDX (CT1122VMN)	Belt sprocket, 22T
Sprocket/belt sprocket/freewheel	GATES®, 22T Enviolo CDX XF1122E9MN)	Belt sprocket, 22T
Shifter	ENVILOLO, Twist Display Pro (MC-TWIST-DISP-PRO)	Twist grip shifter with indicator; see Section #
Motor	BOSCH, Performance Line CX/Cargo [BDU3740](EB11.100.001)	See Section 3.5.06.1
On-board computer	BOSCH, LED Remote [BRC3600] (EB13.100.00E)	See Section #
Display	BOSCH, Kiox 500 [BHU3700] (EB13.100.004)	See Section #
Battery	BOSCH, PowerPack Frame 545 [BBP3550] (EB12.100.02J)	#


Charger	BOSCH, 4A charger [BPC3400] (EB12.110.001)	Charging current (max.): 4 A, 220-240 V; see charger instructions
Front brake	TEKTRO, # HD-T532	# 3-finger brake lever Length: 1200 mm/ Hydraulic disc brake, 2-piston
Rear brake	TEKTRO, # HD-T532	# 3-finger brake lever Length: 1800 mm/ Hydraulic disc brake, 2-piston
Rear brake disc	TEKTRO, TR-17	Ø: 160 mm
Front brake disc	TEKTRO, TR-45	Ø: 180 mm
Headlight	FUXON, FF-100 EB-HB	Light cable length: 1300 mm; remote control cable: 1200 mm; see Section #
Rear light	FUXON, R-Glow	Bolt distance: 50 mm; see Section #
Reflectors, rear	COMUS, FZR-006	#
Pannier rack, front	STECO, R30.358.00	Drawing: R30.358.00, with KlickFix
Pannier rack, rear	HAOJIE, HJ11CA12-21-03(QC-A186AA)	Drawing: HJ11CA12-21-03(QC-A186AA)
Guard	SKS, #	Drawing: 6774-1206
Guard	SKS, #	Drawing: 6744-7908
Stand	PLETSCHER, Comp 40	Kickstand
Bell/horn	WIDEK, e-bike	Bell
Battery lock	ABUS, BLO	...

...not available

Information not available when document was produced

3.5.0.11 Components and repair parts for XXL E5 ZR F CX

J-04





3.5.1 Chassis

The chassis comprises two components:

- frame
- steering system.

3.5.1.1 Frame

The frame absorbs all forces which act on the pedelec from the rider's body weight, pedalling and the ground. The frame also acts as a support for most components.

The frame geometry determines the pedelec's ride performance. A frame comprises the following elements:




Figure 4: Frame elements

- | | |
|---|----------------------|
| 1 | Head tube |
| 2 | Top tube |
| 3 | Rear frame seat stay |
| 4 | Rear frame fork end |
| 5 | Chain stay |
| 6 | seat tube |
| 7 | Down tube |

3.5.1.2 Steering system

The steering system components are:

- Steering headset,
- Stem,
- Handlebars and
- Fork.

3.5.1.3 Steering headset

The steering headset (also known as a bike headset or simply a headset) is the fork bearing system in the frame. A distinction is made between two different types:

- Conventional steering headsets for fork steerers with thread
- Steering headsets for threadless fork steerers or what are known as headsets.

3.5.1.4 Stem

The stem connects the handlebars to the fork steerer tube. The stem is used to adjust the handlebars to the rider's body size. The stem is used to adjust the handlebar height and the gap between the handlebars and saddle (see Section 6.5.6).

Quickly adjustable stems

Quickly adjustable stems are an extension to the fork steerer. You can change the height and angle of quickly adjustable stems without any tools. Up to 3 settings can be adjusted, depending on the model:

- | | |
|---|-------------------------|
| 1 | Adjust handlebar height |
| 2 | Adjust twist function |
| 3 | Adjust stem angle. |




Figure 5: Example – BY.SCHULZ seat Speedlifter Twist Pro SDS

Adjusting the height and stem angle enhances ride comfort by allowing varied riding positions on longer tours. The twist function saves space when parking.




Figure 6: Twist function, using BY.SCHULZ as an example

3.5.1.5 Handlebars

The pedelec is steered using the handlebars. The handlebars are used to support the upper body and is the mount for operating and display components (see Section 3.5.1).




Figure 7: Handlebar dimensions

The main dimensions of handlebars are:

- 1 Rise
- 2 Width
- 3 Backsweep

3.5.1.6 Fork

The stem and handlebars are attached to the top end of the fork steerer. The axle is fastened to the fork ends. The wheel is fastened to the axle.




Figure 8: Overview of rigid fork

- 1 Fork steerer
- 2 Side reflectors (optional)
- 3 Fork end
- 4 Fork leg

Rigid forks are fitted in this model series.

Rigid forks

Rigid forks transfer the used muscle and motor power to the road to optimum effect. Pedelecs with rigid forks consume less energy on steep roads and have a greater range than pedelecs with adjusted suspension.

3.5.2 Suspension

The suspension system in the pedelec comprises 2 components:

- the tyres and
- the optional suspension seat post.



Figure 9: Oscillating system

- 1 Optional suspension seat post (see Section 3.3.6.2)
- 2 Tyre suspension

3.5.2.1 Suspension seat post

Suspension seat posts can reduce impact after one-time, hard impacts. Ride comfort can be improved significantly thanks to the brief cushioning.

See Section 3.3.6.2 for more information.

All types of suspension seat posts feature small, heavy-duty slide bearings, guides and articulated joints. If they are not lubricated on a regular basis, the sensitive response behaviour diminishes considerably, causing excessive wear.

Clean and service suspension seat posts on a regular basis (see Section 7.7.6 and Section 7.9.9.1).

3.5.2.2 Tyre suspension

Tyre pressure has a significant effect on ride comfort. Tyres with a high tyre pressure transmit more impacts from uneven roads to the frame and handlebars than tyres with low air pressure.

Soft tyres do not deflect; they absorb smaller bumps in the road thanks to the tyre's sag and ability to deform. Small obstacles therefore have no impact.

It is therefore recommended to use as low a tyre pressure as possible to ensure greater ride comfort (see Section 6.5.8).

3.5.2.3 Suspension fork

The stem and handlebars are attached to the top end of the fork steerer. The axle is fastened to the fork ends. The wheel is fastened to the axle.

Unlike rigid forks, suspension forks improve contact with the ground, thus enhancing comfort using two functions:

- Suspension and
- Damping (optional function).

Suspension

A suspension fork deflects when a steel spring, air suspension or both suspension types act on it.

A pedelec's suspension prevents an impact, such as one caused by a stone lying in the pedelec's path, from being channelled directly into the rider's body via the suspension fork. The impact is absorbed by the suspension system instead. This causes the suspension fork to compress.




Figure 10: Without suspension (1) and with suspension (2)

Damping

After compressing, the suspension fork returns to its original position. If there is a damper, it will decelerate movement, preventing the suspension system from springing back in an uncontrolled manner and stopping the suspension fork from vibrating up and down. A distinction is made between two types of dampers:

- Rebound dampers,
- Compression dampers.

Rebound dampers and compression dampers can be optionally divided into two different sections:

- High-speed compression dampers,
- Low-speed compression dampers.

Parts of a suspension fork




Figure 11: Parts of a suspension fork

- | | |
|----|--|
| 1 | Fork steerer |
| 2 | Sag adjuster (without damper) or
Lockout or
Push button |
| 3 | Fork crown |
| 4 | Deflection (suspension fork) |
| 5 | Damper side (optional) |
| 6 | Quick release |
| 7 | Fitting gap (L.O.R) |
| 8 | Fork end (suspension fork) |
| 9 | Quick release axle |
| 10 | Air suspension-side (optional) |
| 11 | Stanchion |
| 12 | Fork bridge |
| 13 | Stanchion |
| 14 | Air valve (for air suspension systems) or
sag adjuster (steel spring) |

Tyre clearance

- | | |
|----|--------------------|
| 15 | Tyre height |
| 16 | Tyre passage width |

Side view

- | | |
|----|---------------------|
| 17 | Installation height |
| 18 | Offset |

Suspension fork assembly groups

A suspension fork can feature up to three different assembly groups:

- Compression damper (blue)
- Rebound damper (red)
- Air suspension or steel spring (orange)




Figure 12: Internal structure of an air suspension fork

- | | |
|---|------------------------------------|
| 1 | Air valve (suspension fork) |
| 1 | Dual air suspension system |
| 2 | Air valve cover |
| 3 | Damping adjuster |
| 4 | Compression dampers |
| 5 | Rebound dampers |
| 6 | Rebound adjuster (suspension fork) |
| 7 | Air suspension |




Figure 13: Internal structure of a steel suspension fork

- | | |
|---|------------------------------------|
| 1 | Sag setting wheel |
| 2 | Damping adjuster |
| 3 | Compression dampers |
| 4 | Rebound dampers |
| 5 | Rebound adjuster (suspension fork) |
| 6 | Steel spring |

Cartridges

Dampers may be housed in closed structural elements, known as cartridges. These cartridges are fitted into the suspension fork. Different cartridges can be fitted into forks. This has no effect on the suspension fork's total bearing capacity.

Lockout

The compression can be disabled in any suspension fork. A suspension fork will then behave like a rigid fork.

A suspension system is designed to cushion and compensate for unevenness on a surface whether the user is riding on bumpy cycle paths, dirt roads or off road. A suspension system absorbs great deal of motor and muscle power during rides uphill

or on optimally tarmacked roads. This increases energy consumption and reduces propulsion. It thus makes sense to lock the suspension on tarmacked roads and when riding uphill.

Some suspension forks thus feature a *lockout* on the fork crown or a *remote lockout* activated on the handlebars.

Negative deflection (sag)

The negative deflection (*sag*) is the percentage of entire deflection that is compressed by the rider's body weight, including equipment (such as a backpack), their seating position and frame geometry. Sag occurs whether you are actually riding or not.

The pedelec rebounds at a controlled speed if it is optimally adjusted. The wheel stays in contact with the ground when passing over bumps (blue line). The fork head, handlebars and body follow terrain (green line) when riding over bumps. The suspension motion is predictable and controlled.



Figure 14: Optimum suspension fork ride performance

When optimally adjusted, the suspension fork counteracts deflection on hilly terrain and remains higher in its deflection range.

This allows the rider to maintain the same speed more easily on hilly terrain.



Figure 15: Optimum suspension fork ride performance on hilly terrain

The suspension fork also deflects quickly and unhindered when hitting bumps and cushions the bump when placed at an optimum setting. Traction is retained (blue line).

The suspension fork responds instantly to the impact. The headset and handlebars rise slightly when absorbing a bump (green line).



Figure 16: Optimum suspension fork ride performance over bumps

Rebound dampers

Rebound dampers damp rebound movements, i.e. rebound stress loads.

The rebound damper determines the speed at which the suspension rebounds after being exposed to load. Rebound damping controls the suspension fork extension and rebound speed, which, in turn, has an impact on traction and control.

The damper rebounds at a controlled speed if the suspension fork is optimally adjusted. The wheel stays in contact with the ground when passing over bumps (blue line). The fork head, handlebars and body follow terrain (green line) when riding over bumps. The suspension motion is predictable and controlled.



Figure 17: Optimum suspension fork ride performance

High-speed and low-speed rebound dampers

Rebound dampers may have high-speed or low-speed adjustment or both settings. SettingsBoth settings refer to the deflection used and are unrelated to the riding speed or the speed of impact.

The more deflection is used, the greater the counterforce from the spring is and the faster the rebound movement is.

The low-speed setting changes the rebound speed during low to medium deflection.

The high-speed setting, on the other hand, changes the rebound speed during large to full deflection.

Compression dampers

Compression dampers damp deflection movements, i.e. compression loads.

The compression damper controls the compression stroke speed or the extent to which the suspension fork deflects during slow impacts.

When optimally adjusted, the suspension fork counteracts deflection on hilly terrain, stays

higher in its deflection range and helps to maintain speed when riding on hilly terrain.

The suspension fork deflects instantly unhindered and absorbs bumps when the bike hits one. Traction is retained (blue line).




Figure 18: Optimum ride performance on hilly terrain

High-speed compression dampers

The high-speed compression damper (also abbreviated to HSC from *high-speed compression*) is a specialised compression damper.

A high deflection speed is generated in the suspension fork on a mogul slope or on landing after a jump.

The high-speed damper controls the suspension fork's behaviour positively in such riding situations.




Figure 19: High-speed movements

Low-speed compression dampers

The low-speed compression damper (also abbreviated to LSC from *low-speed compression*) is a specialised compression damper.

A slow deflection speed is generated in the suspension fork when riding over bumps. The low-speed damper controls the suspension fork's behaviour positively in such riding situations.





Figure 20: Low-speed movements

3.5.2.4 SR SUNTOUR, MOBIE34-CGO BOOST DS LO 15AH2-110 20"

Maximum rider weight for SR SUNTOUR steel suspension fork

SR SUNTOUR steel suspension forks are available in three different hardness types for different body weights:

Coil spring model	Soft	Medium Fitted as standard	Hard/rigid
Max. bodyweight [kg]	50-75	70-95	90-120



Suspension		
1	Steel spring	Steel spring with adjustable pre-tensioning
8	Stanchion distance	145 mm
Damping		
6	Cartridges	LO
General information		
4	Deflection	Parts list (see Section 11.3)
5	Quick release axle	Ø15-110 15QLC32-110
4	Offset	42 mm
6	Length	Parts list (see Section 11.3)
5	With mudguard	Yes

Figure 21: SR SUNTOUR, ZERON35-Boost LOR DS 15QLC32-110

Design of SR SUNTOUR LO cartridge



Figure 22: LO operating elements

The SR Suntour LO cartridge features a

- a compression damper
- a rebound damper

Before riding, use the **rebound adjuster (fork)** (1) to adjust the system to the surface you will ride on.

You can use the **compression adjuster (2.2)** remote control to open and close the damping.

If the pressure in the fork is too high, the blow-off feature opens a valve to release air. This prevents any damage due to positive pressure.

		Function available
	Lockout remote control	...
	Fork head lockout	x
Compression damping	High-speed	...
	Low-speed	...
	Fixed	x
Rebound damping	High-speed	...
	Low-speed	...
	Fixed	x
	Blow-off feature	x
	PCS	...

Table 15: An overview of SR SUNTOUR LO functions

3.5.3 Wheel




Figure 23: Visible wheel components

1	Tyres
2	Rim
3	Spoke
4	Spoke nipples
5	Hub
6	Tube

The wheel comprises a tyre, an inner tube with a valve and the wheel itself.

3.5.3.1 Tyres

The tyre forms the outer section of the wheel. The tyre is pulled onto the rim. Tyres differ in design, profile and width, depending on their intended use.



Figure 24: Example: Information on tyres

Tyre size

The tyre size is indicated on the side of the tyre.

Tyre pressure

The permitted pressure range is indicated on the side of the tyre. It is indicated in psi or bars. The tyre is only able to support the pedelec if there is adequate tyre pressure. The tyre pressure must be adjusted to the rider's body weight and then checked on a regular basis.

Tyre design types

There are five different tyre design types:

- Tube-type tyres,
- Tubeless tyres (*also tubeless ready*),
- Tubular tyres, *Tubular or single tube* tyres,
- Solid tyres *Solid* tyres
- Mixed types.

3.5.3.2 Tube-type tyre

A distinction is made between different *types of tube-type tyres*, also known as clinchers:

- Clinchers with steel wire reinforcement in bead core
- Folding tyres with aramid fibre reinforcement in bead core
- Beaded edge tyres without reinforcement in the bead core but with pronounced beads that hook under the rim edge and overlap in the rim well.



Figure 25: Structure of tube-type tyres

1	Rim
2	Tread with profile
3	Puncture protection belt (optional)
4	Carcass
5	Bead core

Carcass

The carcass *is the tyre's* supporting structure. There are usually three carcass plies beneath the tread. The carcass comprises a webbing with threads, usually made of polyamide (nylon). The webbing is coated with rubber on both sides and cut at an angle of 45°. The carcass gives the tyre stability thanks to this cut at an angle to the direction of travel. The carcass plies are woven with different densities, depending on the quality of the tyres. The density of the carcass fabric is indicated by the number of threads per inch, in EPI (*ends per inch*) or TPI (*threads per inch*). There are tyres with between 20 and 127 EPI carcasses.

If the EPI value is higher, the diameter of the threads used is lower. Carcass plies with a higher EPI value have threads with a smaller diameter. The higher the EPI value,

- the less rubber is needed to encase the threads,
- the lighter the tyres are and
- the more flexible the tyres are and they consequently have less rolling resistance.
- The webbing is denser so that it is more difficult for foreign bodies to penetrate. This increases puncture resistance.

In carcasses with 127 EPI, each individual thread is just 0.2 mm thick and, consequently, more susceptible to damage. This means that a 127 EPI tyre offers low puncture protection. 67 EPI offers the optimum compromise between weight and robustness.

Besides the webbing, the tyre's rubber compound is also important. The rubber compound comprises numerous parts:

40 - 60%	Natural and synthetic rubber
15 - 30%	Fillers, e.g. carbon black, silicic acid or silica gel
20 - 35%	<ul style="list-style-type: none"> • Anti-ageing agent • Vulcanisation agent, e.g. sulphur • Vulcanisation accelerator, e.g. zinc oxide • Pigments and dyes

Table 16: Rubber compound in carcasses

Tread with profile

A rubber tread is attached to the exterior of the carcass.

The tread has little influence on riding characteristics on a smooth road. The grip between the road and tyre is mainly provided by the rolling friction between the rubber and the road surface.

Slicks and road tyres

Unlike cars, a pedelec will not aquaplane. The tread contact is small and the contact pressure high. Thanks to the small contact surface on narrow and treadless tyres, the tyre interlocks with the road surface finish. Theoretically, the tyre will not aquaplane until speeds of 200 km/h are reached.

On a clean road, whether dry or wet, slick tyres will grip more effectively than treaded tyres because the contact surface is larger. The rolling resistance of slick tyres is also lower.

Off-road tyres

The tread is highly important on terrain. In this case, the tread creates an interlock with the ground, thus enabling driving, braking and steering forces to be transmitted. The MTB tread can also help improve control on dirty roads or farm tracks.

Tread blocks on MTB tyres deform as they meet the contact surface. The energy used for this is partly converted into heat. Another part is stored and converted into the tread block's sliding movement when it leaves the contact surface, which contributes to the tyre's wear.

If a tyre with a deep tread is used on asphalt, this may make an unpleasant noise. If a pedelec with an MTB tyre is mainly ridden on the road, it is thus best to change the tyre for a pair of tyres with as little tread as possible to reduce wear and save energy. In such a case, the specialist dealer needs to replace the tyre with a new one with a shallow tread.

Bead core

Tyre carcasses are wrapped around bead cores. Wrapping the carcass around both sides creates three carcass plies.

To ensure that tyres do not slip when inflated on the rim and have an effective grip, the bead cores are stabilised in two different ways:




Figure 26: Steel bead core (1) and Kevlar bead core (2)

- with a steel wire. These tyres are called *clinchers*.
- with aramid fibres (Kevlar®). These tyres are called folding tyres. Folding tyres are about 50-90 g lighter than clinchers. It can also be folded into a smaller pack size.

Puncture protection belt (optional)

There may be a puncture protection belt between the carcass and the tread.



Figure 27: Effect of puncture protection belt

Each tyre manufacturer has its own puncture protection classes, which cannot be directly compared with one another.

3.5.3.3 Rim

The rim is the metal profile on a wheel which holds the tyre, tube and rim band together. The rim is joined to the hub with spokes.

In rim brakes, the outer surface of the rim is used to brake.

3.5.3.4 Tube

Each tube-type tyre has a valve. Air is pumped into the tube via the valve. There is a valve cap on each valve.

The screw-on valve cap keeps out dust and dirt.

The pedelec has either a:

- Dunlop valve
- Presta valve
- Schrader valve

Dunlop valve

The Dunlop valve, also known as a Blitz valve or Woods valve, is the most widely used valve. The valve insert can be replaced easily and air can be let out very quickly.




Figure 28: Dunlop valve

Presta valve

The Presta valve, also known as the Sclaverand valve or French valve, is the narrowest variant of all valves. The Presta valve requires a smaller hole in the rim, which is why it is especially suitable for the narrow rims on racing bicycles. It is about 4 to 5 g lighter than a Dunlop or Schrader valve.




Figure 29: Presta valve

Schrader valve

Tyres with a Schrader valve can be inflated at filling stations. Older, simple bicycle air pumps are unsuitable for Schrader valves.




Figure 30: Schrader valve

3.5.3.5 Spoke

A spoke is a rod that connects the hub to the rim. The bent end of the spoke which is hooked into the hub is called the spoke head. A screw thread between 10 mm and 15 mm is attached to the other end of the spoke.

3.5.3.6 Spoke nipples

Spoke nipples are screw elements with an internal thread which fits onto the spoke thread. Fitted spokes are tensioned by tightening the spoke nipples. This straightens the wheel uniformly.

3.5.3.7 Hub

The hub is located in the centre of the wheel. The hub is connected to the rim and tyre with the spokes. An axle runs through the hub, connecting the hub with the fork at the front and with the frame at the rear.

The hub's main task is to transfer the pedelec's force of weight to the tyres. Special hubs on the rear wheel perform additional functions. There is a distinction between five types of hub:

- Hubs without additional features
- Brake hub (see back-pedal brake)
- Gear hub, also known as a hub gear
- Generator hub (for bicycles only)
- Motor hubs (for front- and rear-driven pedelecs only).

Hub without additional features

The front wheel hubs on pedelecs with central or rear motors are normally hubs without additional features.




Figure 31: Example of front wheel hub: SHIMANO

- | | |
|---|---------------|
| 1 | Hub axle |
| 2 | Quick release |
| 3 | Hub body |
| 4 | Ball bearings |

3.5.4 Brake

A pedelec's brake system is primarily operated using the brake lever on the handlebars.

- If the left brake lever is pulled, the brake on the front wheel is applied.
- If the right brake lever is pulled, the brake on the rear wheel is applied.

The brakes are used to regulate speed and make an emergency stop. Applying the brakes will bring the pedelec to a safe, rapid halt in an emergency.

The brake is applied using the brake lever either

- with the brake lever and brake cable (mechanical brake) or
- with the brake lever and hydraulic brake cable (hydraulic brake).

3.5.4.1 Mechanical brake

The brake lever is connected to the brake via a wire inside the shift cable (also known as a Bowden cable).



Figure 32: Structure of a Bowden cable

3.5.4.2 Hydraulic brake

The brake fluid is contained in a closed tube system. If the brake lever is pulled, the brake fluid transfers pressure to the brake on the wheel.




Figure 33: Components of a brake cable

- | | |
|---|-------------|
| 1 | Brake cable |
| 2 | Cable clip |
| 3 | Union nut |
| 4 | Cover cap |
| 5 | Knob |
| 6 | Insert pin |

3.5.4.3 Disc brake




Figure 34: Brake system with disc brake – example

- 1 Brake lining
- 2 Brake adapter
- 3 Brake disc
- 4 Brake lever

On a pedelec with a disc brake, the brake disc is permanently screwed to the hub.

You increase brake pressure by pulling the brake lever. The brake fluid is used to transfer pressure through the brake cables to the cylinders in the brake calliper.

The braking force is boosted by a speed reduction and applied to the brake linings. These apply the brake disc mechanically. If the brake lever is pulled, the brake linings are pressed against the brake disc and the wheel movement is decelerated until it comes to a stop.

3.5.4.4 Back-pedal brake



Figure 35: Brake system with a back-pedal brake – example

- 1 Rear wheel rim brake
- 2 Handlebars with brake lever
- 3 Front wheel rim brake
- 4 Pedal
- 5 Back-pedal brake

The back-pedal brake is an extra brake. The back-pedal brake stops the rear wheel from moving by pushing the pedals in the opposite direction to the direction of travel.

3.5.5 Saddle

The purpose of the saddle is to absorb body weight, provide support and allow different riding positions. The shape of the saddle thus depends on the intended use of the pedelec and the rider's physique and posture.

When riding, the rider's body weight is distributed between the pedals, the saddle and the handlebars. When the rider is in an upright position, the relatively small saddle area bears about 75% of their body weight.




Figure 36: Saddle dimensions

- 1 Saddle length
- 2 Saddle width (narrow version)
- 3 Saddle width (wide version)
- 4 Saddle nose

The seat area is one of the most sensitive regions of the body. The saddle should allow the rider sit free of pain and fatigue. The saddle shape must suit each individual's anatomy. Solutions for sitting discomfort are listed in Section 9.1.

Saddles are provided in different sizes. The width of the pelvis and the gap between the sitting bones is crucial when selecting a saddle. Different saddle variants thus differ in their width.

You will find two methods to calculate the minimum saddle width in Section 6.3.11.3.

3.5.5.1 Ladies' saddle

The distance between the ischial tubercles and the pubic symphysis is on average a quarter less in women than in men. This is why painful pressure points can occur on men's saddles through the saddle nose since saddles that are too narrow or too soft press on the genitals or coccyx.



Figure 37: Female pelvis on saddles

For anatomical reasons, the pubic symphysis (front cartilage connection between the two halves of the pelvis) is, on average, a quarter lower than in the male pelvis. The angle between the pubic bones is wider.

The pelvis is more mobile in women than it is in men. Consequently, the pelvis often tilts forward more on the saddle. This causes high pressure in the genital area.




Figure 38: Pressure points on a saddle, female anatomy

3.5.5.2 Men's saddle

In contrast to the female anatomy, men's pubic bones are at a much steeper angle to one another. The pubic symphysis is much higher.



Figure 39: Male pelvis on saddles

The male pelvis is less flexible than women's. Men sit more upright on the saddle and put greater strain on the sitting bones. This means that the transition area

between the saddle rear and nose can be kept narrow (-Y-shape). This gives more space to pedal.

Numbness when riding a pedelec is often caused by high pressure in the sensitive perineal area. If the saddle is adjusted incorrectly, too narrow or too hard, the nose of the saddle presses directly onto the genitals. Blood circulation deteriorates. The genitals on the outside are seldom the cause of discomfort since they can move out of the way and are not compressed by bone structures.




Figure 40: Pressure points on a saddle, male anatomy

3.5.6 Seat post

Seat posts are not only designed to fasten the saddle but also to adjust exactly to the optimum sitting position. The seat post can:

- adjust the seat height in the seat tube
- adjust the saddle horizontally with a clamping mechanism
- adjust the saddle angle by swivelling the entire saddle clamping mechanism.

Retractable seat posts feature a remote control on the handlebars, which can be used to lower the seat post at traffic lights, for example, and then raise it again.

3.5.6.1 Patented seat post

Patented seat posts have a rigid link between the saddle and the post. Patented seat posts which are angled more markedly towards the rear are offset seat posts. Offset seat posts provide a greater distance between the saddle and the handlebars.

In patented seat posts, the saddle is attached to the head with one or two seat clamp screws. It is recommended to lubricate the thread in these screws to ensure sufficient tension when tightening the screw.

Patented seat posts are fastened into the seat tube with either a quick release or a screwable clamp.




Figure 41: Example of a quick release

3.5.6.2 Suspension seat post

Suspension seat posts can reduce shock after one-time hard impacts, thus improving ride comfort significantly. However, suspension seat posts are not able to compensate for bumps in the road.

If the seat post is the only suspension element, the entire pedelec is a non-suspended mass. This has an unfavourable effect on loaded touring bikes or pedelecs with child trailers.

Suspension seat posts feature small, heavy-duty slide bearings, guides and articulated joints. If they are not lubricated on a regular basis, the sensitive response behaviour diminishes considerably, causing excessive wear.

3.5.7 Mechanical drive system

The pedelec is driven by muscle power, just like a bicycle.

The force which is applied by pedalling in the direction of travel drives the front chain wheel. The chain or belt transmits the force onto the rear chain wheel and then onto the rear wheel.

The pedelec is equipped with either a chain or belt drive.

3.5.7.1 Parts of a chain drive



Figure 42: Diagram of chain drive with derailleur gears

- 1 Front derailleur
- 2 Cassette/Cassette sprocket
- 3 Rear derailleur
- 4 Chain
- 5 Chain wheel

The chain drive is compatible with a

- Back-pedal brake,
- Hub gear
- Derailleur gears.

3.5.7.2 Parts of a belt drive



Figure 43: Diagram of a belt drive

- 1 Front belt sprocket
- 2 Rear belt sprocket
- 3 Belt

A belt drive is compatible with

- Back-pedal brake and
- Hub gear.

A belt drive is not compatible with derailleur gears.

3.5.8 Electric drive system

Component	Designation	Manual
Motor	BOSCH, Performance Line [BDU3360] (EB11.100.00A)	See Section 10.1.003
Motor	BOSCH, Performance Line CX/ Cargo [BDU3740](EB11.100.001)	See Section 10.1.002
Motor	BOSCH, Performance Line CX [BDU3840] (EB11.100.00E)	See Section 10.1.007, embargo until 30.09.2024
Motor	BOSCH, Performance Line CX [BDU3843] (EB11.100.01C)	See Section #0, embargo until 30.09.2024
Motor	BOSCH, Performance Line SX [BDU3144] (EB11.100.00V)	See Section 10.1.004
Motor	BROSE, MY24 [#] (#)	See Section #0
Motor	FIT, BAFANG H600 (501187)	#0
Motor	FIT, Brose Drive-P (501376)	#0
Motor	FIT, Brose S-MAG (501366)	#0
Motor	FIT, Brose S-MAG FIT (500956)	See Section 10.01.009, CE06.5.00013
Motor	FIT, Pinion E1.12 (501070)	See Section 10.1.010, CE06.5.00004

Component	Designation	Manual
Motor	FIT, Pinion E1.12 SPEED PEDELEC (501109)	See Section 10.1.010, CE06.5.00004
Motor	FIT, Pinion E1.9 (501069)	See Section 10.1.010, CE06.5.00004
Motor	FIT/MAXON, #	See Section #0
On-board computer	BOSCH, LED Remote [BRC3600] (EB13.100.00E)	See Section 10.2.002
On-board computer	BOSCH, Purion 200 [BRC 3800] (EB13.200.03V)	See Section 10.2.003
On-board computer	BOSCH, SystemController [#] (EB13.200.03B)	#0
On-board computer	BOSCH, SystemController [BRC3100] (EB13.100.000)	See Section 10.2.004
On-board computer	FIT, LCD Remote (RD2.1) (501263)	See Section 10.2.016, CE06.5.00015
On-board computer	FIT, LCD Remote (RD2.2) (#501264)	See Section 10.2.016, CE06.5.00015
On-board computer	FIT, Master Node Basic (501301)	See Section 10.02.018
On-board computer	FIT, Remote Basic (501262)	See Section 10.2.005
Display	BOSCH, Intuvia 100 [BHU3200] (EB13.100.00F)	See Section 10.3.001
Display	BOSCH, Kiox 300 [BHU3600] (EB13.100.003)	See Section 10.3.002
Display	BOSCH, Kiox 500 [BHU3700] (EB13.100.004)	See Section 10.3.002
Display	FIT, Compact (500085)	See Section 10.3.003, CE06.5.00004
Control panel	BOSCH, Mini-Remote [BRC3300] (EB13.100.001)	See Section 10.4.001
Battery	BOSCH, CompactTube 400 Wh (BBP3242) (EB12.100.020)	See Section 10.5.002
Battery	BOSCH, PowerPack Frame 545 [BBP3550] (EB12.100.02J)	See Section 10.5.008
Battery	FIT, Supertube 275 (501167)	#0, 275 Wh
Battery	FIT, Supertube 400 (#)	#0, 400 Wh
Battery	FIT, Supertube 550 (501168)	#0, 550 Wh
Battery	SHIMANO, BT-DN320	#0
Charger	BOSCH, 2A Charger [BPC3200] (EB12.110.016)	Charging current (max.): 2 A, 220-240 V; see Section 10.6.001

Component	Designation	Manual
Charger	BOSCH, 4A charger [BPC3400] (EB12.110.001)	Charging current (max.): 4 A, 220-240 V; see Section 10.6.001
Charger	FIT, FIT Standard Charger (500950)	See Section 10.6.004, CE06.5.00002
Charger	FIT, FIT Standard Charger (500951)	See Section 10.6.003, CE06.5.00002
Charger	SHIMANO, EC-DN100	#0
Charger	SRAM AXS	#0

3.5.9 Seat post

Seat posts are not only designed to fasten the saddle but also to adjust exactly to the optimum sitting position. The seat post can:

- adjust the seat height in the seat tube
- adjust the saddle horizontally with a clamping mechanism
- adjust the saddle angle by swivelling the entire saddle clamping mechanism.

Retractable seat posts feature a remote control on the handlebars, which can be used to lower the seat post at traffic lights, for example, and then raise it again.

3.5.9.1 Patented seat post



Figure 44: Example of ergotec patent seat post with either one or two seat clamp screws

Patented seat posts have a rigid link between the saddle and the post. Patented seat posts which are angled more markedly towards the rear are offset seat posts. Offset seat posts provide a greater distance between the saddle and the handlebars.

In patented seat posts, the saddle is attached to the head with one or two seat clamp screws. It is recommended to lubricate the thread in these screws to ensure sufficient tension when tightening the screw.

Patented seat posts are fastened into the seat tube with either a quick release or a screwable clamp.




Figure 45: Example of a quick release

3.5.9.2 Suspension seat post

Suspension seat posts can reduce shock after one-time hard impacts, thus improving ride comfort significantly. However, suspension seat posts are not able to compensate for bumps in the road.

If the seat post is the only suspension element, the entire pedelec is a non-suspended mass. This has an unfavourable effect on loaded touring bikes or pedelecs with child trailers.

Suspension seat posts feature small, heavy-duty slide bearings, guides and articulated joints. If they are not lubricated on a regular basis, the sensitive response behaviour diminishes considerably, causing excessive wear.

The pre-tensioning in non-damped suspension seat posts must be adjusted in such a way that the suspension seat post does not deflect with just body weight. This prevents the suspension seat post from deflecting and bobbing intermittently at higher pedalling frequencies or if the rider pedals irregularly.

The spring stiffness can be set lower with damped suspension seat posts, thus making use of the negative deflection.

3.5.10 Mechanical drive system

The pedelec is driven by muscle power, just like a bicycle.

The force which is applied by pedalling in the direction of travel drives the front chain wheel. The chain or belt transmits the force onto the rear chain wheel and then onto the rear wheel.




Figure 46: Diagram of mechanical drive system

- | | |
|---|----------------------------------|
| 1 | Direction of travel |
| 2 | Chain or belt |
| 3 | Rear chainring or belt sprocket |
| 4 | Front chainring or belt sprocket |
| 5 | Pedal |

The pedelec is equipped with either a chain or belt drive.

3.5.10.1 Parts of a chain drive



Figure 47: Diagram of chain drive with derailleur gears

- | | |
|---|----------------------------|
| 1 | Front derailleur |
| 2 | Cassette/Cassette sprocket |
| 3 | Rear derailleur |
| 4 | Chain |
| 5 | Chain wheel |

The chain drive is compatible with a

- Back-pedal brake,
- Hub gear
- Derailleur gears.

3.5.10.2 Parts of a belt drive



Figure 48: Diagram of a belt drive

- | | |
|---|---------------------|
| 1 | Front belt sprocket |
| 2 | Rear belt sprocket |
| 3 | Belt |

A belt drive is compatible with

- Back-pedal brake and
- Hub gear.

A belt drive is not compatible with derailleur gears.

3.5.10.3 Folding pedal

Only feet can be used on the folding pedal. The rider applies physical force to the mechanical drive system with their feet, driving the vehicle forward.

The folding pedal can be folded in. As it is folded up at the side, the folding pedal is nearer to the crank. The vehicle can be carried more easily with the pedals folded away and takes up less space when parked or placed in storage.




Figure 49: i:SY folding pedal with pedal fold latch (1)

The folding pedal has an unlocking system featuring a pedal folding latch (1) and a concealed internal spring for easy folding.

The left pedal has a left-handed thread and the right crank has a right-handed thread to prevent them from coming loose. The folding pedal features a standard 9/16" × 20 thread.

3.5.11 Electric drive system

The pedelec has an electric drive system in addition to a mechanical one.




Figure 50: Diagram of an electric drive system with electric components

- | | |
|---|--|
| 1 | Front lamp |
| 2 | On-board computer |
| 3 | PowerPack battery |
| 4 | Rear light |
| 5 | Electric gear shift (optional) |
| 6 | Motor |
| 7 | A charger which is designed for the battery (not shown). |

3.5.11.1 Charger

Each pedelec is supplied with a charger. The following BOSCH charger may be used:

- the 4 A Charger BPC3400.

Observe the operating instructions in Section 11.4 Documents.

3.5.11.2 Motor

As soon as the muscle power required for pedalling passes a certain level, the motor is activated gently and assists the pedalling motion. The motor power always depends on the power used to pedal: Motor assistance is lower when little muscle power is used than when greater muscle power is used. This happens regardless of the level of assistance.

The motor switches off automatically as soon as the rider no longer pedals, the temperature is outside the permitted range, there is an overload or the shut-off speed of 25 km/h has been reached.

A push assist system can be activated. The speed depends on the selected gear. The motor continues to drive the pedelec at walking speed as long as the rider presses the push assist button on the handlebars. The speed can be a maximum of 6 km/h in this case. The electric drive system stops when the push assist button is released. The pedelec does not have a separate emergency shut-off button. In the event of an emergency, the motor can be stopped by removing the on-board computer. The mechanical brakes are used as an emergency stop system and bring the bicycle to a quick halt safely in the event of an emergency.

3.5.11.3 Battery

BOSCH batteries are lithium ion batteries which are developed and manufactured to the latest technical standards. Each battery cell is protected by a steel cup and encased in a plastic battery housing. Applicable safety regulations are complied with.

- The battery has an interior electronic protection circuit, which is specifically designed for the charger and the pedelec.
- The battery temperature is monitored at all times.
- The battery is protected against deep discharge, overcharging, overheating and short circuits by Electronic Cell Protection (ECP).

In the event of a hazard, a protective circuit switches the battery off automatically.

The battery has a high energy content when charged. The code of practice for their safe handling is found in Section 2 Safety and Section 6.9 Rechargeable battery in the operating instructions. If the electric drive system is not used for 10 minutes and no button has been pressed on the on-board computer or the control panel, the electric drive system and the battery are automatically switched off to save energy.

The type and duration of operating conditions have a significant effect on the battery life. Just like any other lithium-ion battery, the battery will age naturally if it is not being used. The battery's service life can be extended if the battery is well maintained and stored at the correct temperature. The charging capacity will decrease with age, even if the battery is maintained properly. If the operating time is significantly shortened after charging, this is a sign that the battery has reached the end of its useful life.

Battery performance is reduced when the temperature drops since this increases electrical resistance. You should expect the range to be less than normal at low temperatures in winter. We recommend using thermal protection sleeves when riding longer distances at low temperatures.

Each battery has its own lock.

The following battery can be built into the pedelec:




Figure 51: Overview of battery variants




Figure 52: PowerPack details

- | | |
|----|-----------------------------------|
| 1 | Battery level indicator (battery) |
| 1 | Securing hook |
| 2 | On-off button (battery) |
| 3 | Battery housing |
| 4 | Top mount |
| 5 | Battery lock |
| 6 | Battery key |
| 7 | Retainer guard |
| 8 | Charging socket cover |
| 9 | Socket for charger plug |
| 10 | Lower mount |

3.5.11.4 On-board computer

The on-board computer on the handlebars is used as a control panel. It controls the system and all indicators on the display screen using six buttons.



Figure 53: BOSCH LED Remote on-board computer

The eBike Flow app can be accessed via Bluetooth®.

The control panel has an internal lithium ion battery. The pedelec battery powers the control panel. If a sufficiently charged battery is inserted into the pedelec and the drive system switched on, the internal battery is charged.

3.5.11.5 Kiox 300 and Kiox 500 displays

The display shows the main drive system functions and the ride data.



Figure 54: BOSCH Kiox 300 and Kiox 500 displays

The display switches off automatically if it is removed from its mount.

3.5.11.6 Lighting

Lighting includes:

- The front light (also known as the headlight or front lamp)
- The rear light (also known as the rear lamp)

The headlight and the rear light are also on whenever the riding light is activated.

3.5.11.7 FUXON front light, FS-100 EB main beam with main beam switch

The FUXON front light, FS-100 EB main beam features a reflector and a main beam switch.



Figure 55: Parts of FUXON, FS-100 EB main beam

- | | |
|---|------------------|
| 1 | Headlight |
| 2 | Main beam switch |
| 3 | Reflector |

In normal mode, the headlight illuminates the road ahead with around 100 lux. The LED in the main beam switch lights up green in normal mode.

You can turn on the main beam by pressing the main beam switch briefly. Press on it again briefly to turn the headlight back to normal mode.

The LED in the main beam switch lights up blue in main beam mode.

The provisions in road traffic regulations apply to main beam operation.

- The main beam must not be activated in built-up areas or on roads with consistently adequate lighting at any time.
- The main beam must not be used the moment it may dazzle other road users.

3.6 Description of controls and screens

3.6.1 Handlebars




Figure 56: Detailed view of handlebars with BOSCH Kiox 300, example

1, 7	Ha	7	Front wheel handbrake (behind handlebars)
2	Rear wheel handbrake (behind handlebars)	8	Bell
3	Main beam switch	9	Twist shifter
4	Display Kiox 300		
5	LED Remote control panel		

3.6.1.1 BOSCH LED Remote on-board computer

The on-board computer on the handlebars is used as a control panel. It controls the system and all indicators on the display screen using six buttons.




Figure 57: Overview of BOSCH LED Remote on-board computer

1	Selected level of assistance indicator	8	<	Decrease brightness button/ back button
2	ABS indicator (optional)	9	+	Plus button/ light button
3	Battery level indicator (on-board computer)	10	-	Minus button/ push assist button
4	Select button	11		Diagnosis connection (for maintenance purposes only)
5	On-off button (on-board computer)	12		Mount
6	Ambient light sensor			
7	Increase brightness button/ forward button		>	

3.6.1.2 Selected level of assistance indicator

The higher the selected level of assistance, the more the drive system assists with pedalling.

eMTB mode is available for Performance Line CX drives. In eMTB mode, the assistance factor and the torque are dynamically adjusted depending on the pedalling force applied to the pedals.

Level of assistance	Colour	Use
OFF	No	When the drive system is switched on, the motor assistance is switched off. Use the pedelec like a normal pedelec by simply pedalling
ECO	Green	Limited assistance with maximum efficiency for maximum range
TOUR	blue	Constant assistance, for long-range tours
eMTB/SPORT	Purple	Powerful assistance, for sporty start-up, optimal assistance on all types of terrain
TURBO	Red	Maximum assistance up to high pedalling frequencies, for sport riding

Table 17: Overview of level of assistance

3.6.1.3 ABS indicator (optional)

The ABS indicator lights up on pedelecs with an ABS system when they start up.

The ABS will switch off if the pedelec reaches a speed of 6 km/h.

If there is a fault, the ABS indicator lights up together with the indicator of the selected level of assistance, which will flash orange.

Press the **select button** to acknowledge the fault and the flashing indicator for the selected level of assistance will go out. The ABS indicator remains lit to indicate that the ABS system is not in operation.

3.6.1.4 Battery level indicator (on-board computer)

The battery level indicator (on-board computer) shows the battery charge level. You can also see the battery charge level on the LEDs on the battery itself.

Each blue bar on the indicator signals 20% capacity and each white bar 10% capacity. The top bar indicates maximum capacity. The two lower indicators will change colour if the capacity is low:

Flash sequence	Capacity
	90 ... 100%
	80 ... 89%
	70 ... 79%

Flash sequence	Capacity	Flash sequence	Capacity
	60 ... 69%		10 - 19%
	50 ... 59%		0 - 9%
	40 ... 49%		Red LED is flashing: 0%
	30 ... 39%	The uppermost bar will flash if the battery is charging.	
	20 ... 29%	<p>3.6.1.5 System message</p> <p>The on-board computer indicates whether a critical or less critical error has arisen in the drive system.</p> <p>The error messages generated by the drive system can be read in the eBike Flow app and by the specialist dealer.</p> <p>The rider can use a link in the eBike Flow app to display all information on errors and assistance on eliminating errors.</p> <p>You will find more information and a table containing all system messages in Section 6.2.</p>	

3.6.1.6 Software updates

Software updates are automatically transferred to the on-board computer in the background of the BOSCH eBike Flow smartphone app as soon as the app is connected to the on-board computer.

The battery level indicator will flash green during updates to show how the update is progressing.

Flash sequence	Meaning
	<p>Green LED is flashing: Update</p>

Once an update has been completely transferred, this is displayed three times when the on-board computer is restarted.

Alternatively, the user can check whether an update is pending under **SETTINGS <My eBike>** <Components>.

3.6.1.7 Activity tracking

User recognition is required on a PC or smartphone to record activities.

The rider needs to agree to location data being saved on the portal or the app to record activities. Only then will all activities be displayed on the portal or app.

Your location will only be logged if the on-board computer is connected to the eBike Connect app.

Activities will be displayed after synchronisation in the app and on the portal.

3.6.1.8 Lock function

When the lock function is used, the on-board computer acts in a similar way to a key for the drive system. Once the lock function is switched on, the e-bike drive unit assistance is deactivated by removing the on-board computer. The rider can continue to use the mechanical drive system.

It can then only be activated using the on-board computer belonging to the pedelec. The lock function is linked to the eBike Connect app user account.

The lock function does not provide anti-theft protection; it is more a supplement to a mechanical lock. The lock function does not provide mechanical blocking of the pedelec or similar. It only deactivates assistance from the drive unit.

If third parties are to have temporary or permanent access to the pedelec, the lock function must be deactivated in the eBike Connect app.

The drive system emits audible lock signals when activating and deactivating the lock function. The audible feedback signal is activated by default. The feedback signal can be deactivated under Settings <My eBike>.

3.6.1.9 BOSCH Kiox 300 and Kiox 500 displays

The display is controlled using the control panel.



Figure 58: BOSCH Kiox 300 and Kiox 500 displays

The following screens are shown on the display screen:

- START SCREEN; see Section 3.4.8.1
- STATUS SCREEN; see Section 3.6.1.11
- SETTINGS, see Section 3.4.8.5

3.6.1.10 START SCREEN

If no other page was selected before the last time display was switched off, the START SCREEN is displayed.




Figure 59: Overview of start screen, screen 1

- 1 Unit of speed
- 2 Selected level of assistance indicator
- 3 Riding light symbol
- 4 Battery level indicator (display screen)
- 5 Title screen
- 6 Own power indicator
- 7 Motor power indicator
- 8 Speed indicator

Indicators 2 to 4 form the status bar and are displayed on every screen.

You open the second START SCREEN by pressing the **select button**.




Figure 60: Overview of start screen, screen 2

- 1 Unit of speed
- 2 Selected level of assistance indicator
- 3 Riding light symbol
- 4 Battery level indicator (display screen)
- 5 Maximum speed indicator
- 6 Average speed indicator

1. Unit of speed

The unit of speed is displayed either in km/h or mph.

2. Selected level of assistance indicator

The higher the selected level of assistance, the more the drive system assists with pedalling.

eMTB mode is available for Performance Line CX drives. In eMTB mode, the assistance factor and the torque are dynamically adjusted depending on the pedalling force applied to the pedals.


Level of assistance	Use
OFF	When the drive system is switched on, the motor assistance is switched off. The pedelec can be used like a normal bicycle by simply pedalling.
ECO	Limited assistance with maximum efficiency for maximum range
TOUR	Constant assistance, for long-range tours

Table 18: Overview of levels of assistance

Level of assistance	Use
eMTB/SPORT	Powerful assistance, for sporty start-up, optimal assistance on all types of terrain
TURBO	Maximum assistance up to high pedaling frequencies, for sport riding

Table 18: Overview of levels of assistance

3. Riding light symbol

 The riding light symbol is shown when the riding light is on.

4. Battery level indicator (display screen)

If the on-board computer is removed from its mount, the last battery level message is saved. The battery level indicator (display screen) can be viewed on the STATUS SCREEN and in the status bar.

5. Title screen

The title screen indicates the page name and the displayed function.

6. Own power indicator

The power that is currently being applied to the pedals is displayed as a semi-circle.

7. Motor power indicator

The motor power used is displayed as a bar. The maximum motor power depends on the selected level for assistance.

10. Speed indicator

The speed is displayed either in km/h or mph.

3.6.1.11 STATUS SCREEN

You open the STATUS SCREEN by pressing the **<- button** on the start screen. You can open the settings on this screen.




Figure 61: Overview of STATUS SCREEN

- 1 Clock indicator
- 2 Selected level of assistance indicator
- 3 Riding light symbol
- 4 Battery level indicator (display screen)
- 5 Connections indicator
- 6 Symbol showing connection to smartphone
- 7 Settings
- 8 Connection status

3.6.1.12 TRIP SCREEN

You open the TRIP SCREEN by pressing the **>- button** on the start screen.




Figure 62: Overview of TRIP SCREEN, screen 1

- 1 Trip distance indicator
- 2 Selected level of assistance indicator
- 3 Riding light symbol
- 4 Battery level indicator (display screen)
- 5 Speed indicator
- 6 Trip time indicator

You open the second TRIP SCREEN by pressing the **select button**.




Figure 63: Overview of TRIP SCREEN, screen 2

- 1 Total distance screen
- 2 Selected level of assistance indicator
- 3 Riding light symbol
- 4 Battery level indicator (display screen)
- 5 Energy consumption indicator

3.6.1.13 RANGE SCREEN

You open the RANGE SCREEN by pressing the **>- button** on the START SCREEN.




Figure 64: Overview of RANGE SCREEN, screen 1

- 1 Range indicator
- 2 Selected level of assistance indicator
- 3 Riding light symbol
- 4 Battery level indicator (display screen)
- 5 Battery level indicator 2 (display screen)

You open the second RANGE SCREEN by pressing the **select button**.




Figure 65: Overview of RANGE SCREEN, screen 2

- 1 Indicator of range in relation to the level of assistance
- 2 Selected level of assistance indicator
- 3 Riding light symbol
- 4 Battery level indicator (display screen)

3.6.1.14 FITNESS SCREEN

You open the Fitness screen by pressing the **>- button** on the start screen.




Figure 66: Overview of FITNESS SCREEN, screen 1

- 1 Own power indicator
- 2 Selected level of assistance indicator
- 3 Riding light symbol
- 4 Battery level indicator (display screen)
- 5 Destination indicator (below average)
- 6 Pedalling frequency indicator
- 7 Destination indicator (below average)

You open the second FITNESS SCREEN by pressing the **select button**.




Figure 67: Overview of FITNESS SCREEN, screen 2

- 1 Indicator for Average Power in watts
- 2 Selected level of assistance indicator
- 3 Riding light symbol
- 4 Battery level indicator (display screen)
- 5 Indicator for Average Cadence in revolutions per minute

3.6.1.15 ABS-SIDE

Only applies to pedelecs with this equipment

You open the ABS screen by pressing the **>- button** on the start screen.




Figure 68: Overview of ABS SCREEN

- 1 Braking Time indicator
- 2 Selected level of assistance indicator
- 3 Riding light symbol
- 4 Battery level indicator (display screen)
- 5 Braking Distance indicator

3.6.1.16 SETTINGS

All system and service-relevant values can be read and changed in the settings. The settings menu structure is customised and may change when components or services are added.

Menu	Sub-menu
My eBike	
	→ <Range reset>
	→ <Auto trip reset>
	→ <Wheel circum.>
	→ <Service>
	→ <Components>
My Kiox	
	→ <Status bar>
	→ <Language>
	→ <Units>
	→ <Time>
	→ <Time Format>
	→ <Brightness>
	→ <Settings reset>
Information	
	→ <Contact>
	→ <Certificates>°

Table 19: Kiox 300 basic menu and sub-menu structure

3.6.2 Handbrake

There is a handbrake on the left and right of the handlebars.




Figure 69: Rear wheel (1) and front wheel (2) brake levers – SHIMANO brake used as an example

The left handbrake (2) controls the front wheel brake.

The right handbrake (1) controls the rear wheel brake.

3.6.3 Gear shift

3.6.3.1 SHIMANO SL-T6000 derailleur gears

Only applies to vehicles with this equipment

The gear shift unit is on the left of the handlebars. The gear shift unit features two switches and an indicator.



Figure 70: SHIMANO SL-T6000 gear shift

- 1 Gear indicator
- 2 Lever A (gear shift)
- 3 Lever B (gear shift)

3.6.3.2 SHIMANO NEXUS SL-C7000-5 twist grip shifter

Only applies to vehicles with this equipment

SHIMANO hub gears feature a NEXUS SL-C7000-5 twist grip shifter with an indicator on the right of the handlebars.



Figure 71: SHIMANO NEXUS SL-C7000-5 twist grip shifter

- 1 Twist grip shifter
- 2 Gear indicator

You change gears by turning the twist grip shifter.

The Gear indicator shows the selected gear.

3.6.3.3 ROHLOFF 500/14 hub gear

Only applies to vehicles with this equipment

You can switch gears individually after one another or skipping over several speeds on the ROHLOFF Speedhub 500/14 gear hub using a twist shifter.



Figure 72: ROHLOFF gear shift

- 1 Twist shifter
- 2 Gear indicator

The mark on the twist shifter casing next to the gear numbers informs the user of which gear has been selected.





With the ROHLOFF Speedhub 500/14 gear hub, the gear changes simultaneously as you turn the twist shifter. The gear has been changed to the selected position the moment you feel the detent engage in the twist shifter. This ensures that you change gears quickly and flawlessly when stationary and while in all riding situations.

When you change gears, coupling elements inside the hub move as they are subject to force when you push the pedals. The grip shifter can be easily turned from detent to detent when the bike is stationary or low force is applied to the pedals. The manual force required to turn the shift lever increases as the pedal force intensifies.




3.6.4 Suspension and damping

Only applies to vehicles with this equipment

3.6.4.1 SR SUNTOUR air valve (air suspension) and sag setting wheel (steel fork)

Model	AIR EQ	AIR	COIL Adjustable	COIL
	Air valve (suspension fork) Dual air suspension system	Air valve (suspension fork) Standard air suspension system	Sag setting wheel Steel spring with adjustable pre-tensioning	Sag setting wheel
Suspension	Air suspension	Air suspension	Steel spring	Steel spring
				
Aion	x			
Axon	x	x		
CR85			x	
Durolux	x			
GVX		x		
M3010			x	x
Mobie34/25	x	x	x	
Mobie35	x			
MobieA32			x	
NCX32/NCX		x	x	
NEX			x	
NVX			x	
NRX		x	x	
NX1/TR-HSI				
Raidon	x	x		
Rux	x	x		
X1				
XCE			x	
XCM		x	x	
XCR		x	x	
XCT		x	x	
Zeron35	x		x	

3.6.4.2 SR SUNTOUR suspension lock


Model	LO	NLO	HLO
Suspension fork			
CR85	x		
Mobie34CGO	x		
MobieA32	x	x	
NCX32/NCX	x		x
NEX		x	x
NRX	x		
NVX		x	
NX1/TR-HSI	x		x
X1	x		
XCM	x	x	x
XCR	x		
XCT		x	x

x = featured O = featured in PCS piston

Explanation

NLO	Hydraulic lock with recoil
HLO	Hydraulic lock without recoil

3.6.4.3 SR SUNTOUR suspension lock with remote control

Model	RL
Suspension fork	
MobieA32	x
NCX32/NCX	x
NVX	x
NX1/TR-HSI	x
X1	x
XCR	x

x = featured O = featured in PCS piston

Explanation

RL	Lock with fixed recoil and remote control
----	---

3.6.5 Battery

3.6.5.1 Battery level indicator

Each battery has its own level indicator.




Figure 73: Position of battery level indicator on seat tube battery

- 1 On/off button (battery)
- 2 Battery level indicator (battery)

The five green LEDs on the battery level indicator show the charge level when the battery is switched on. Each LED represents 20% of battery capacity.

LED 1,2,3,4,5	Battery level
● ● ● ● ●	100...80%
● ● ● ● ○	79...60%
● ● ● ○ ○	59...40%
● ● ○ ○ ○	39...20%
● ○ ○ ○ ○	19...15%
○ ○ ○ ○ ○	5...0%

Figure 74: Battery level indicator

Symbols:

- LED on
- LED off

All five LEDs will light up when the battery is fully charged. The charge level for the activated battery is also shown on the on-board computer.

If the battery level falls below 5%, all the LEDs on the operating status and battery level indicator will go out.

The battery level is still shown on the on-board computer.

4 Transporting and storing

4.1 Transportation

⚠ CAUTION Crash caused by unintentional activation

There is a risk of injury if the drive system is activated unintentionally.

- ▶ Remove the battery.

4.1.1 Using the transport securing system

Applicable to pedelec disc brakes only

⚠ CAUTION Oil leak if no transport securing device

The brake securing device prevents the brakes from being applied accidentally during transportation or shipment. Accidental braking could cause irreparable damage to the brake system or an oil leak, which would harm the environment.

- ▶ Never push the brake lever when the wheel has been dismantled.
 - ▶ Always use the transport securing system between the brake linings when transporting or shipping.
- ⇒ Transport securing device is squeezed between the two linings and prevents undesired, sustained braking which can cause brake fluid to leak out.




Figure 75: Fastening the transport securing device

4.1.2 Transporting the pedelec

4.1.2.1 By car

Bicycle rack systems which use the handlebars or frame to hold the pedelec in an upside-down position exert inadmissible forces on its components during transportation. This can cause the supporting parts to break.

- ▶ Remove battery (see Section 6.16.1.1 or 6.16.2.1).
- ▶ Remove all detachable components (display screen, bicycle pump, water bottle and similar) from the pedelec.
- ▶ Transport the battery in a clean, dry position where it is protected from direct sunlight.
- ▶ Never use bicycle rack systems which use the pedelec's handlebars or frame to hold the pedelec in an upside-down position. The specialist dealer will give a consultation on correct selection and safe use of a rack system.
- ▶ Take into account the weight of the ready-to-use pedelec when transporting it.

4.1.2.2 By train

Pedelecs can usually be transported in trains with a bicycle compartment.

- ✓ If you want to take your pedelec with you on the train, you should take into account that access to platforms are not always barrier-free. You should thus allow enough time to get on and off the train.

- 1 Buy a bicycle ticket for the pedelec.
- 2 Fasten the pedelec securely in the compartment.
- 3 Take a seat in the passenger carriage.

It is possible to take a pedelec on certain high-speed train routes. The battery must remain firmly mounted during the journey and must not be charged.

4.1.2.3 By local transport

You can normally take pedelecs on local public transport, e.g. by bus or suburban rail, if you purchase a bike ticket. There may be times when this is not permitted. Local transport companies can give you further information on carriage of bicycles.

4.1.2.4 By long-distance bus

Pedelecs can usually be taken on the long-distance bus for an extra charge, although places are limited. It is best to book early. However, not every bus line accepts pedelecs. You should check with the long-distance bus provider concerned before travelling.

4.1.2.5 On flights

It is forbidden to transport rechargeable batteries on passenger planes. Most airlines won't even carry pedelecs without batteries on passenger planes either.

It is a good idea to find out about pedelec leasing at your destination in advance if you wish to use a pedelec while on holiday. This way, you won't need to forgo pedelec riding fun during your holidays.

4.1.3 Shipping a pedelec

- ▶ When shipping the pedelec, we recommend that you have the specialist dealer place it in proper packaging.

4.1.4 Transporting the battery

Batteries are subject to hazardous goods regulations. Undamaged batteries may be transported by private persons in road traffic.

4.1.5 Shipping the battery

The battery is considered a hazardous good and only trained persons may pack and ship a battery. Contact specialist dealer.

4.2 Storing

- ▶ Always store pedelec, battery, on-board computer, display and charger separately.

Storage temperature	+10 ... +40 °C
Humidity	30%...85%
Ideal storage temperature	+10 ... +20 °C
Optimum air humidity	30%...60%

Table 20: Ambient conditions for storage

- ▶ Temperatures under -5 °C or over +40 °C and air humidity over 85% must generally be avoided.
- ▶ Store pedelec, on-board computer, battery and charger in a place which is
 - dry
 - clean
 - protected from direct sunlight
 - well-ventilated
 - Never store in the open air.

4.2.1 Pedelec

Store pedelec in a garage or a dry basement.

4.2.2 On-board computer, display and charger

Store on-board computer, display and charger in a dry environment at room temperature.

4.2.3 Battery

- ▶ Storage at about 10 °C to 20 °C for a long battery life.
- ▶ Store batteries in rooms with smoke detectors. A protection box with an electrical connection is an optimal solution.
- ▶ Never store batteries near to inflammable or easily combustible objects.
- ▶ Never store batteries near sources of heat.

4.2.4 Break in operation

Notice Batteries discharge if they are not used. If the battery is stored for a longer period of time when empty, it can become damaged and its storage capacity can be greatly reduced.

- ▶ Store battery with at least 30% charge.
- ▶ Charge battery every six months.

Charge LED on the Remote or System Controller via the USB diagnostic interface for about an hour every three months.

Notice The battery may become damaged if it is connected permanently to the charger.

- ▶ Never connect the battery to the charger permanently.
- ▶ Remove the on-board computer and battery from their mount if the pedelec is not going to be used for up to four weeks.
- ▶ If the pedelec is removed from service for longer than four weeks, you need to prepare it for a break in operation.

4.2.4.1 Preparing for a break in operation

- 1 The pedelec needs to be cleaned with a damp cloth and preserved with wax spray. Never wax the friction surfaces of the brake.
- 2 Have the specialist dealer carry out maintenance and basic cleaning and apply preservative agent before longer periods without use.
- 3 Remove battery (see Section 6.16.1.1 or 6.16.2.1).
- 4 Charge battery between 30% and 60% so that two or three LEDs light up on the battery level indicator.

4.2.4.2 Initiating a break in operation

- 1 Store the pedelec, battery and charger in a dry, clean environment. We recommend storing them in uninhabited rooms with smoke alarms. Dry locations with an ambient temperature between 10 °C and 20 °C are ideal.
- 2 Check the battery level after 6 months. If only one LED on the battery level indicator lights up, recharge the battery to around 30%–60%.

5 Assembly instructions for online sales

⚠ CAUTION Crash caused by incorrectly configured tightening torque

If a screw is fastened too tightly, it may break. If a screw is not fastened enough, it may loosen. This will result in a crash with injuries.

- ▶ Always observe the indicated tightening torques on the screw, the component and in the operating instructions.

Prior knowledge is required for assembly. If you don't have any prior knowledge, contact specialist dealer.

⚠ CAUTION Crash and crushing hazard caused by unintentional activation

There is a risk of injury if the drive system is activated unintentionally.

- ▶ Remove the battery.

Your specialist dealer will complete assembly and commissioning for this pedelec. The pedals were unscrewed and the handlebars repositioned before transportation. You need these instructions to get your pedelec roadworthy and ready for use after transportation.

5.1 Unpacking

- ▶ The packaging material consists of cardboard. Dispose of the packaging in accordance with the regulatory requirements.

Scope of delivery

<input type="checkbox"/>	1 pedelec with battery
<input type="checkbox"/>	2 pedals (already greased)
<input type="checkbox"/>	1 charger
<input type="checkbox"/>	1 set of operating instructions on CD

5.2 Preparing

- ▶ Assemble the pedelec in a clean, dry environment. The work environment temperature should be between 15 °C and 25 °C.
- ▶ Secure the pedelec in a fitting stand. The fitting stand used must be approved for a maximum weight of least 30 kg. Alternatively, you can get another person to hold the pedelec.
- ▶ Read the operating instructions for your pedelec.

5.3 Required tools

The following tools are required to assemble the pedelec:




	Screw wrench 15 mm
	Torque wrench Working range: 5- 40 Nm
	By.Schulz handlebars: Torx bits: 4 mm, 5 mm and 6 mm If not: Hex key bits: 4 mm, 5 mm and 6 mm

Table 21: Tools required for assembly

5.4 Straightening the handlebars

The handlebars must be turned so that they are parallel to the frame and tyres for transportation.

- 1 Turn handlebars clockwise until they are vertically aligned with the wheel and frame.
The way the handlebars are secured depends on the stem.

5.4.1 Stem with clamping lever version I

Only applies to pedelecs with this equipment

- 1 Open the clamping lever on the stem quick release.
- 2 Pull the locking lever on the stem upwards and simultaneously pivot handlebars 90° to the left.
⇒ You feel the handlebars click into place.
- 3 Push in the handlebars.
- 4 Close the clamping lever on the stem quick release.



Figure 76: Opened clamping lever on the stem quick release (3) on the stem (2), version I, with locking lever on the stem (1)

5.4.2 Stem with clamping lever version II

Only applies to pedelecs with this equipment

- 1 Open the clamping lever on the stem quick release.
- 2 Push the *unlocking knob*.
- 3 Pivot the *handlebars* 90° to the right or left.
⇒ You feel the *handlebars* click into place.
- 4 Close the *clamping lever on the stem quick release*.



Figure 77: Stem, version II with clamping lever on the stem quick release (1) and unlocking knob (2)

5.5 Stem with screw

Only applies to pedelecs with this equipment

- 1 Remove the safety cap from the stem.
- 2 Undo the screw using a 4 mm, 5 mm, or 6 mm Torx or hex key, depending on the type of screw.
- 3 Turn the handlebars into the required position.
- 4 Fasten the screw using a 4 mm, 5 mm, or 6 mm Torx or hex key, depending on the type of screw.
- 5 Refasten the safety cap on the stem.

5.6 Checking the stem and handlebars are in correct position

5.6.1 Checking the connections

- 1 Stand in front of the pedelec. Clamp the front wheel between your legs. Grasp the handlebar grips.
- 2 Try to twist the handlebars against the direction of the front wheel.
 - ⇒ The stem must not move or twist.
- 3 If the stem can be twisted, check fastening.
 - ⇒ If the stem cannot be fastened, contact your specialist dealer.

5.6.2 Checking stem is firmly in position

- 1 Press full body weight on the handlebars.
 - ⇒ The handlebars must not move downwards in the fork.

Stem with clamping lever version I

- 2 If the handlebars should move, increase the lever tension in the clamping lever.
- 3 Turn knurled nut in a clockwise direction with the clamping lever open.
- 4 Close clamping lever and check stem is firmly in position again.
- 5 If the handlebars cannot be fastened, contact your specialist dealer.

Stem with clamping lever version II and stem with screw

- ▶ If the handlebars cannot be fastened, contact your specialist dealer.

5.6.3 Checking the bearing clearance

- 1 Place the fingers of one hand on the upper headset cup. Pull the front wheel brake with the other hand and try to push the pedelec backwards and forwards.
 - Keep in mind that there may be noticeable backlash due to worn-out bearing bushes or brake lining backlash in suspension forks and disc brakes.
 - ⇒ The headset cup halves must not move towards one another.
- 2 Set bearing clearance as per the stem repair manual as quickly as possible as otherwise the bearing will become damaged. Contact specialist dealer.

5.7 Fitting the pedals

The pedals have two different threads to ensure they don't come loose while the rider is pedalling.

- The pedal on the left facing the direction of travel has a left-hand thread and is marked L.
- The pedal on the right facing the direction of travel has a right-hand thread and is marked R.

The mark is either on the top end, the axle or the pedal body.



Figure 78: Example of markings on pedals

- 1 Coat threads in both pedals with waterproof grease.
- 2 Turn the pedal marked L anti-clockwise by hand into the crank arm on the left as seen when facing the direction of travel.



Figure 79: L pedal in the left-hand crank arm

- 3 Turn the pedal marked R anti-clockwise by hand into the crank arm on the right as seen when facing the direction of travel.



Figure 80: R pedal in the right-hand crank arm

- 4 Use a 15 mm spanner to fasten the left-hand pedal thread in an anti-clockwise direction and the right-hand pedal in a clockwise direction with a torque between 33 and 35 Nm.

6 Operation

6.1 Risks and hazards

WARNING Injuries and death caused by blind spots

Other road users, trucks, cars and pedestrians often underestimate the speed of pedelecs. Likewise, other road users frequently do not see pedelecs. This may lead to an accident with serious injuries or even death.

- ▶ Wear a helmet. The helmet must have a reflective strip or a light in a clearly visible colour.
- ▶ Clothing should be retroreflective or as light as possible. Fluorescent materials are also suitable. High-visibility jackets and straps on your upper body ensure even greater safety.
- ▶ Always take a defensive approach to riding.
- ▶ Avoid the blind spots of vehicles turning off the road. Reduce speed as a precaution when other road users turn right.

WARNING Injuries and death caused by riding incorrectly

Misjudging speeds and mistakes made while riding quickly lead to hazardous situations, which can cause an accident with serious or fatal injuries.

- ▶ Get used to road traffic and speed little by little before riding, especially if you have not ridden a bicycle for some time.
- ▶ Practice braking hard on a regular basis.
- ▶ Take and complete a riding safety course.

WARNING Injuries and death caused by distraction

A lack of concentration while riding increases the risk of an accident. This may cause a crash with serious injuries.

- ▶ Never allow yourself to be distracted by the smartphone.

CAUTION Crash caused by loose clothing

Laces, scarves and other loose items may become entangled in the spokes on the *wheels* and the *chain drive*. This may cause a crash with injuries.

- ▶ Wear sturdy footwear and close-fitting clothing.

CAUTION Crash caused by difficult-to-spot damage

If the pedelec topples over or you have a fall or an accident, there may be difficult-to-spot damage to components such as the brake system, quick releases or *frame*. This may cause a crash with injuries.

- ▶ Take pedelec out of service. Contact specialist dealer.

CAUTION Crash caused by dirt

Heavy dirt can impair pedelec functions, such as braking. This may cause a crash with injuries.

- ▶ Remove coarse dirt before riding.

CAUTION Crash caused by material fatigue

Intensive use can cause material fatigue. A component may suddenly fail in case of material fatigue. This may cause a crash with injuries.

- ▶ Remove the pedelec from service immediately if there are any signs of material fatigue. Have your specialist dealer inspect the component.
- ▶ Arrange the mandatory full inspections with your specialist dealer on a regular basis. During the full inspection, the specialist dealer will check the pedelec for any signs of material fatigue on the frame, fork, suspension element mountings (if there are any) and components made of composite materials.

Carbon becomes brittle when exposed to heat radiation such as heating. This can cause the carbon component to break, leading to a crash with injuries.

- ▶ Never expose carbon components on the pedelec to strong sources of heat.

CAUTION Crash caused by poor road conditions

Loose objects, such as branches and twigs, may become caught in the wheels and cause a crash with injuries.

- ▶ Be aware of the road conditions.
- ▶ Ride slowly and brake in good time.

The *tyres* may slip on wet roads. You must also account for a longer braking distance in wet conditions. The brake response will feel different to normal. This can cause loss of control or a crash, which may result in injuries.

- ▶ Ride slowly and brake in good time when it is raining.

Notice Off-road riding subjects arm joints to severe strain.

- ▶ Take a break from riding every 30 to 90 minutes, depending on the road surface conditions and your physical fitness.

Notice Heat or direct sunlight can cause the *tyre pressure* to increase above the permitted maximum pressure level. This can destroy the *tyres*.

- ▶ Park pedelec in the shade.
- ▶ On hot days, check the *tyre pressure* regularly and adjust it as necessary.

Notice Moisture penetrating at cold temperatures may impair individual functions due to the open structural design.

- ▶ Always keep the pedelec dry and free from frost.
- ▶ If the pedelec is used at temperatures below 3 °C, the specialist dealer must perform a full inspection beforehand and prepare it for winter use.

6.2 Instruction and customer service

The supplying specialist dealer will provide customer service. Contact details can be found on the pedelec pass for these operating instructions. The supplying specialist dealer will also perform all inspection, modifications and repairs in the future.

6.3 Adjusting the pedelec

⚠ CAUTION Crash caused by incorrectly adjusted tightening torques

If a screw is fastened too tightly, it may break. If a screw is not fastened enough, it may loosen. This will result in a crash with injuries.

- ▶ Always observe the tightening torque indicated on the screw and in the *operating instructions*.

Only a correctly adjusted pedelec will guarantee the desired ride comfort and health-promoting activity.

All settings must be re-configured if the body weight or maximum baggage weight changes.

6.3.1 Preparing

The following tools are required to adjust the pedelec:







	Tape measure
	Scales
	Spirit level
	Ring spanners 8 mm, 9 mm, 10 mm, 13 mm, 14 mm and 15 mm
	Torque wrench Working range 5-40 Nm
	Hex key 2 mm, 2.5 mm, 3 mm, 4 mm, 5 mm, 6 mm and 8 mm

Table 22: Tools required for assembly



	Cross-recess screwdriver
	Slotted-head screwdriver

Table 22: Tools required for assembly

6.3.2 Riding position

The starting point for a comfortable posture is the correct position of the pelvis. If the pelvis is in the wrong position, it can cause different types of pain, e.g. in the shoulder or back.




Figure 81: The pelvis is in the right position (green) or incorrect position (red)

The pelvis is in the right position if the spine forms an S-shape and a natural, easy arch.

The pelvis is positioned incorrectly if it tilts slightly backwards. As a result, the spine becomes curved and can no longer deflect to an optimal extent.

A suitable riding position must be selected beforehand depending on the pedelec type, physical fitness and desired trip distance or speed.

It is especially advisable to check and optimise the riding position once more before longer rides.

6.3.2.1 Adjusting the seat post to body weight

The correct functioning of the following seat posts depends on the body weight:

- Suspension seat post,
- Rhomboid seat post
- Lowerable seat post

If the body weight falls below or exceeds the specifications in Section Weight, either the seat post spring or, in the case of integrated seat posts, the complete seat post must be replaced with a seat post from the same product series that is appropriate for the body weight.

► Contact your specialist dealer.

6.3.3 Saddle

6.3.3.1 Replacing the saddle

If the pre-mounted saddle is uncomfortable or causes pain, a saddle optimised to the rider's physique must be used.

6.3.3.2 Straightening the saddle

► Position saddle in direction of travel. In doing so, align the tip of the saddle with the top tube.




Figure 82: Positioning the saddle in direction of travel

6.3.3.3 Adjusting the saddle height

✓ To adjust the saddle height safely, either:

- Push the pedelec near to a wall so that the pedelec rider can lean on the wall to support themselves or
- Ask another person to hold the pedelec.

1 Use the seat height formula to roughly set the saddle height:

$$\text{Seat height (SH)} = \text{inner leg length (I)} \times 0.9$$

2 Climb onto the bicycle.

3 Place your heel on the pedal and extend your leg, so that the pedal is at the lowest crank

rotation point. Your knee should now be fully extended.




Figure 83: Heel method

4 Take a test ride.

⇒ Pedelec riders sit straight on the saddle at an optimal saddle height.

- If the pelvis moves to the left and right as you pedal, the saddle is too high.
- If your knees are painful after a few kilometres, the saddle is too low.

⇒ Position the seat post according to needs if necessary. Adjust the seat height with the quick release.

5 Open the quick release on the seat post to change the seat height (1). To do so, push the clamping lever away from the seat post (3).




Figure 84: Opening the seat post quick release

6 Set the seat post to the required height.

⚠ CAUTION Crash caused by an excessively high seat post setting

A seat post with is set too high will cause the seat post or the frame to break. This will result in a crash with injuries.

- ▶ Do not pull the seat post out of the frame beyond the minimum insertion depth marking.




Figure 85: Detailed view of the seat post – examples of the minimum insertion depth marking

- 7 To close it, push the seat post clamping lever as far as it will go into the seat post (2).
- 8 Check the clamping force of the quick releases.

6.3.3.4 Adjusting the saddle height with the remote control

Use the seat height formula to set the saddle height:
Seat height (SH) = inner leg length (l) × 0.9

Notice If you are unable to achieve the required saddle height, lower the seat post further into the seat tube. The seat post Bowden cable must be tightened in the frame up to the remote control to the same length as the seat post was lowered. If this is not possible, contact your specialist dealer.

6.3.3.5 Adjusting the saddle position

The saddle can be shifted on the saddle frame. The right horizontal position ensures an optimal leverage position for legs. This prevents knee pain and incorrect, painful pelvis positions. If you have displaced the saddle more than 10 mm, you need to adjust the saddle height again since both settings affect one another.

- ✓ You must only adjust the saddle setting when the bicycle is stationary.
- ✓ To set the saddle position, either:
 - Push the pedelec near to a wall so that the pedelec rider can lean on the wall to support themselves or
 - Ask another person to hold the pedelec.

- ✓ Move the saddle within its permitted displacement range only (marked on the saddle stay).

- 1 Climb onto the pedelec.
 - 2 Place the pedals into the vertical position with your feet.
- ⇒ Pedelec riders are adopting the optimal saddle position if the perpendicular line from the kneecap runs through the pedal axle.
- ▶ If the perpendicular line crosses behind the pedal, bring the saddle further forward.
 - ▶ If the perpendicular line crosses in front of the pedal, bring the saddle further back.




Figure 86: Knee cap perpendicular line

- 3 Unfasten and adjust the designated screw connections, and clamp them with the maximum tightening torque for the saddle clamping screws.

6.3.3.6 Adjusting the saddle tilt

The saddle tilt must be adjusted to the seat height, the saddle and handlebar position, and the saddle shape to ensure an optimum fit. This allows you to optimise the seating position.

The saddle prevents pedelec riders from slipping backwards or forwards when placed in a horizontal position. This avoids seat problems. The tip of the saddle may press uncomfortably into the crotch area in any other position. It is also recommended that the saddle be perfectly aligned in the centre. This ensures that the rider is seated with their sit bones on the wide rear part of the saddle.

- 1 Adjust the saddle tilt to horizontal.
- 2 Position saddle middle so that it is completely straight.




Figure 87: Horizontal saddle tilt with 0° tilt in the centre of the saddle

- ⇒ Pedelec riders sit comfortably on the saddle and do not slip backwards or forwards.
- 3 Pedelec riders tend to slip forwards or sit on the narrow part of the saddle; readjust the saddle to position or tilt the saddle very slightly backwards.

6.3.3.7 Checking the saddle

- ▶ Check the saddle after adjustment.

6.3.4 Handlebars

6.3.4.1 Replacing the handlebars

- ▶ Check handlebar width and hand position.
- ▶ Have handlebars replaced at the specialist dealer's if necessary.

6.3.4.2 Adjusting the handlebar width




Figure 88: Determining the optimal handlebar width

The handlebar width should be as wide as the rider's shoulders as a minimum. This is measured from mid-point to mid-point on the hand contact surfaces. The wider the handlebars are, the more control they provide, although wide handlebars require greater supporting force. Wider handlebars are particularly useful to ensure a safer ride for loaded touring bikes.

6.3.4.3 Adjusting the handlebars

The handlebars and their position determine the posture that the pedelec rider adopts on the pedelec.

- 1 After selecting the seating position, determine the angle of the upper body and the upper arm.
- 2 Tension the back muscles when adjusting the handlebars. The only way to stabilise the spine and protect it from excessive strain is to tension the back and abdominal muscles. Passive muscles are not able to perform this important task.
- 3 Set the required handlebar position on the stem by adjusting the stem height and angle.
- 4 After adjusting the handlebars, check the saddle height and riding position again. The position of the pelvis on the saddle may have changed when the handlebars were adjusted. This can have considerable impact on the position of the hip joint due to the pelvis tilting and may change the usable leg length on the saddle support by up to 3 cm.
- 5 Correct the saddle height and position if necessary.

6.3.5 Stem

6.3.5.1 Adjusting the handlebar height with quick release

- 1 Open the stem clamping lever.




Figure 89: Open (2) and closed (1) stem clamping lever; All Up used as an example

- 2 Pull out the handlebars to the required height. Observe minimum insertion depth.




Figure 90: Pulling the handlebars upwards; All Up used as an example

- 3 Close the stem clamping lever.

6.3.5.2 Checking the stem stability

- ▶ Hold handlebars firmly after adjusting the saddle. Press full body weight on the handlebars.
- ⇒ The handlebars remain stable in their position.

6.3.5.3 Adjusting the quick release clamping force

⚠ CAUTION Crash caused by incorrectly set clamping force

Applying excessive clamping force damages the quick release. Insufficient clamping force will result in unfavourable transmission of force. This can cause components to break. This will result in a crash with injuries.

Never fasten a quick release using a tool (e.g. hammer or pliers).

If the *handlebar clamping lever* stops before reaching its end position, unscrew the *knurled nut*.

- ▶ Tighten the *knurled nut on the seat post* if the seat post clamping lever's *clamping force* is not effective enough.
- ▶ Contact your specialist dealer if the clamping force cannot be set.

6.3.5.4 Adjusting the quill stem

In the case of a quill stem, the stem and fork steerer form a permanently interconnected component, which is clamped in the fork steerer. The stem and shaft must be replaced together.




Figure 91: Adjusting the quill stem height

- 1 Undo screw.
- 2 Pull quill stem out.
- 3 Tighten screw.

6.3.5.5 Adjusting the Ahead stem

In the case of an Ahead stem, the stem is placed directly on the fork steerer, which protrudes over the frame.




Figure 92: Raising the Ahead stem by fitting spacer rings

The handlebar height is adjusted once during production using spacer rings. The part of the fork steerer protruding is then cut off. The handlebar stem can then no longer be set higher, but only slightly lower.

6.3.5.6 Adjusting the angle-adjustable stem

Angle-adjustable stems are available in different lengths for quill and Ahead stems.




Figure 93: Different versions of angle-adjustable stems

Adjusting the stem angle (c) changes both the distance from the upper body to the handlebars (b) and the handlebar height (a).



Figure 94: City bike (blue) and trekking bike position (red) by changing the angle

6.3.5.7 Checking the stem

- ▶ Check saddle stem after adjusting it (see Section 8.5.5).

6.3.6 Handles

6.3.6.1 Adjusting the ergonomic handles




Figure 95: Incorrect (1) and correct (2) position of the handle

- 1 Undo handle clamping screw.
 - 2 Turn handle into the right position.
 - 3 Fasten handle clamping screw with the torque value indicated there.
- ⇒ The handles are firmly fastened.
 - ⇒ The pull-off force of the handles is at least 100 N in the roadster, city and trekking positions, and at least 200 N in the sporty position.

6.3.6.2 Checking the handlebars

- ▶ Check handlebars after adjusting the handles.

6.3.7 Tyres

The following applies to all tyres:

- ▶ Never exceed or go below the minimum and maximum pressure limits indicated on the tyre.

The correct tyre pressure largely depends on the weight load on the tyres. This load is determined by the pedelec's tare weight, the rider's body weight and the baggage load.

Unlike cars, the weight of the vehicle has little impact on the total weight. Moreover, the personal preferences for low rolling resistance or a high degree of suspension comfort vary a great deal.

It is important to remember that

- the higher the tyre pressure is, the lower the wear, rolling resistance and the risk of breakdown are.
- The lower the pressure in the tyre is, the greater the comfort and grip is that the tyre offers.

In the case of pedelecs used on the road, the rule is the greater the tyre pressure is, the lower the tyre rolling resistance is. The risk of breakdown is also lower when the pressure is high. A permanently excessively low tyre pressure often leads to premature wear in the tyre. Cracking in the side wall is a typical consequence of very low tyre pressure. Abrasion is also unnecessarily high.

On the other hand, a tyre can absorb road impacts more effectively at a low pressure.

As a general rule, wide tyres are used at a lower tyre pressure. They provide the option of exploiting the advantages of the lower tyre pressure without the serious disadvantages it causes with regard to wear, rolling resistance and breakdown protection.

► Pump the tyre to the recommend tyre pressure.

Tyre width	Tyre pressure (in bar) for body weight		
	about 60 kg	about 80 kg	about 110 kg
25 mm	6.0	7.0	8.0
28 mm	5.5	6.5	7.5
32 mm	4.5	5.5	6.5
37 mm	4.0	5.0	6.0
40 mm	3.5	4.5	6.0
47 mm	3.0	4.0	5.0
50 mm	2.5	4.0	5.0
55 mm	2.0	3.0	4.0
60 mm	2.0	3.0	4.0

Table 23: SCHWALBE recommend tyre pressure

4 Perform a visual check on tyres.



Figure 96: Correct tyre pressure. The tyre is barely deformed under the load of the body weight



Figure 97: Much too little tyre pressure

6.3.8 Brake

The handbrake grip distance can be adjusted to ensure that it can be reached more easily. The pressure point can also be adjusted to the pedelec rider's preferences.

6.3.8.1 Retracting the brake linings

Disc brakes require a break-in period. The braking force increases over time. The braking force is increased during the break-in period. This is also the case when the brake pads or brake discs are replaced.

- 1 Accelerate pedelec to 25 km/h.
- 2 Brake pedelec until it comes to a halt.
- 3 Repeat process 30 to 50 times. The disc brake is retracted and provides optimal braking power.

6.3.9 Determining the sitting position

The starting point for a comfortable posture is the correct position of the pelvis. If the pelvis is in the wrong position, it can cause different types of pain, e.g. in the shoulder or back.




Figure 98: The pelvis is in the right position (green) or incorrect position (red)

The pelvis is in the right position if the spine forms an S-shape and a natural, easy arch.

The pelvis is positioned incorrectly if it tilts slightly backwards. As a result, the spine becomes curved and can no longer deflect to an optimal extent.

A suitable sitting position must be selected beforehand depending on the pedelec type, physical fitness and desired trip distance or speed.

It is especially advisable to check and optimise the sitting position once more before longer rides.



Position on roadster	Position on city bike
	
Angle of upper body (black dashed line)	
Upright, almost vertical posture. Back at an angle of almost 90°. Handlebars and handles are very close to the upper body.	Slightly inclined upper body, back at an angle of 60°...70°.
Upper arm-upper body angle (red line)	
Extremely acute angle at around 20°. The upper arms are almost parallel to the upper body. Hands are simply placed loosely on the handlebars.	An angle of 75°–80° is optimum. Many people prefer a smaller angle of up to 60° as it requires less effort to support the shoulders, arms and hands.
Saddle-handlebar height difference [cm] (blue and green line)	
>10 The handlebars are positioned far higher than the saddle.	10...5 The handlebars are positioned higher than the saddle.
Benefits	
The spine is intuitively moved into its natural S-shape. The strain on arms and hands is very slight – no effort required to support.	The upright position provides a good overview in traffic. Force can be applied to the pedals when pedalling without using much energy.
Disadvantages	
Force is applied relatively inefficiently to the pedals. Weight rests exclusively on the buttocks. The spine slumps after a short time for many people (pelvic straightening).	The arms are often stretched through to the high handlebars – this leads to tense shoulders and painful hands. The spine tends to slump quickly due to the "high position".
Fitness level and use	
Low fitness level, occasional cyclists.	Medium fitness level, city cyclists.

Table 24: Overview of sitting positions

6.3.10 Seat post

6.3.10.1 Adjusting the seat post to body weight

Not included in price

The correct functioning of the following seat posts depends on the body weight:

- Suspension seat post,
- Rhomboid seat post
- Lowerable seat post

If the body weight falls below or exceeds the specifications in Section Dimensions, either the seat post spring or, in the case of integrated seat posts, the complete seat post must be replaced with a seat post from the same product series that is appropriate for the body weight.

The pre-tensioning in non-damped suspension seat posts must be adjusted in such a way that the suspension seat post does not deflect with just body weight. This prevents the suspension seat post from deflecting and bobbing intermittently at higher pedalling frequencies or if the rider pedals irregularly.

The spring stiffness can be set lower with damped suspension seat posts, thus making use of the negative deflection.

6.3.11 Saddle

6.3.11.1 Replacing the saddle

Not included in price

If the pre-mounted saddle is uncomfortable or causes pain, a saddle optimised to the rider's physique must be used.

- 1 Determining the saddle shape (see Section 6.3.11.2).
- 2 Determining the minimum saddle width (see Section 6.3.11.3).
- 3 Selecting the saddle hardness (see Section 6.3.11.4).

6.3.11.2 Determining the saddle shape

Ladies' saddle

To distribute the pressure optimally over the female bone structure in the seat area, a ladies' saddle should:

- have a relief opening far to the front
- have a wide, V-shaped saddle edge.



Figure 99: Example: Ergotec ladies' saddle

Men's saddle

Numbness when riding a pedelec is often caused by high pressure in the sensitive perineal area. If the saddle is adjusted incorrectly, too narrow or too hard, the nose of the saddle presses directly onto the genitals. Blood circulation deteriorates.

The genitals on the outside are seldom the cause of discomfort since they can move out of the way and are not compressed by bone structures.

You should always consult a doctor if you have problems with your prostate. After a prostate operation or inflammation, it is advisable to avoid any pressure in the perineal area and take a longer break from pedelec riding after consulting your doctor. A prostate saddle should then be used. This reduces the pressure in the perineal area by up to 100%.




Figure 100: Pressure points on a saddle, male anatomy

To distribute the pressure on the male bone structure in the seat area optimally, the saddle should:

- Shift the pressure to the sitting bones and parts of the pubic arches
- The perineal area must remain as free of pressure as possible.



Figure 101: Example: Ergotec men's saddle

6.3.11.3 Determining the minimum saddle width

With corrugated cardboard

- 1 Place corrugated cardboard on a flat, hard, unpadded seat.
- 2 Sit in the middle of the corrugated board.




Figure 102: Sitting on the corrugated board

- 3 Pull the seat with your hands and arch your back.
 - ⇒ The sitting bones are more prominent and stand out more clearly on the corrugated cardboard.
- 4 Trace the outer edges of the two depressed areas in a circle.
- 5 Determine the centre of both circles and mark them with a dot.
- 6 Measure the distance between the two centres.




Figure 103: Measuring the distance

⇒ The distance between the two centre points is the sit bone distance and corresponds to the minimum saddle width.

7 Calculate saddle width (see Section 6.5.4.4).

Using calculation

Depending on the position, the following value is added to the minimum saddle width.

Position on roadster	+ 4 cm
Position on city bike	+ 3 cm
Position on trekking bike	+ 2 cm
Position on sports bike	+ 1 cm
Triathlon/time trials	+ 0 cm

Table 25: Calculating the saddle width

6.3.11.4 Selecting the saddle hardness

Saddles are available in a wide range of hardnesses and must be adapted to the pedelec's use:

- A pedelec that is mainly used for commuting in jeans calls for a soft saddle.
- A pedelec that is mainly used for sports riding with padded cycling shorts requires a hard saddle.

If the degree of hardness is not suitable, a new saddle must be selected.

6.3.11.5 Adjusting the saddle hardness

Only applies to pedelecs with this equipment

The hardness of air cushion saddles can be adjusted using the pump valve beneath the seat surface.

Soft	Pump 3 times
Medium	Pump 5 times
Hard	Pump 10 times

Table 26: BULLS settings, air cushion saddle

6.3.11.6 Straightening the saddle

- ▶ Position saddle in direction of travel. In doing so, align the tip of the saddle with the top tube.




Figure 104: Positioning the saddle in direction of travel

6.3.11.7 Adjusting the saddle height

- ✓ To adjust the saddle height safely, either:

- Push the pedelec near to a wall so that the pedelec rider can lean on the wall to support themselves or
- Ask another person to hold the pedelec.

- 1 Use the seat height formula to roughly set the saddle height:

$$\text{Seat height (SH)} = \text{inner leg length (I)} \times 0.9$$

- 2 Climb onto the bicycle.

- 3 Place your heel on the pedal and extend your leg, so that the pedal is at the lowest crank rotation point. Your knee should now be fully extended.




Figure 105: Heel method

- 4 Take a test ride.

- ⇒ Pedelec riders sit straight on the saddle at an optimal saddle height.

- If the pelvis moves to the left and right as you pedal, the saddle is too high.
- If your knees are painful after a few kilometres, the saddle is too low.

- ⇒ Position the seat post according to needs if necessary. Adjust the seat height with the quick release.

- 5 Open the quick release on the seat post to change the seat height (1). To do so, push the clamping lever away from the seat post (3).




Figure 106: Opening the seat post quick release

Set the seat post to the required height.

⚠ CAUTION Crash caused by an excessively high seat post setting

A seat post with is set too high will cause the seat post or the frame to break. This will result in a crash with injuries.

- 6 Do not pull the seat post out of the frame beyond the minimum insertion depth marking.




Figure 107: Detailed view of the seat post – examples of the minimum insertion depth marking

- 7 To close it, push the *seat post clamping lever* as far as it will go into the *seat post* (2).
- 8 Check the clamping force of the quick releases.

6.3.11.8 Adjusting the saddle height with the remote control

Use the seat height formula to set the saddle height:
 Seat height (SH) = inner leg length (I) \times 0.9

Notice

- ▶ If you are unable to achieve the required saddle height, lower the seat post further into the seat tube. The seat post Bowden cable must be tightened in the frame up to the remote control to the same length as the seat post was lowered.
- ▶ If this is not possible, contact your specialist dealer.

6.3.11.9 Adjusting the saddle position

The saddle can be shifted on the saddle frame. The right horizontal position ensures an optimal leverage position for legs. This prevents knee pain and incorrect, painful pelvis positions. If you have displaced the saddle more than 10 mm, you need to adjust the saddle height again since both settings affect one another.

- ✓ You must only adjust the saddle setting when the bicycle is stationary.
 - ✓ To set the saddle position, either:
 - Push the pedelec near to a wall so that the pedelec rider can lean on the wall to support themselves or
 - Ask another person to hold the pedelec.
 - ✓ Move the saddle within its permitted displacement range only (marked on the saddle stay).
- 1 Climb onto the pedelec.
 - 2 Place the pedals into the vertical position with your feet.
 - ⇒ Pedelec riders are adopting the optimal saddle position if the perpendicular line from the kneecap runs through the pedal axle.
 - ▶ If the perpendicular line crosses behind the pedal, bring the saddle further forward.
 - ▶ If the perpendicular line crosses in front of the pedal, bring the saddle further back.




Figure 108: Knee cap perpendicular line

- 3 Unfasten and adjust the designated screw connections, and clamp them with the maximum tightening torque for the saddle clamping screws.

6.3.11.10 Adjusting the saddle tilt

The saddle tilt must be adjusted to the seat height, the saddle and handlebar position, and the saddle shape to ensure an optimum fit. This allows you to optimise the seating position.

The saddle prevents pedelec riders from slipping backwards or forwards when placed in a horizontal position. This avoids seat problems. The tip of the saddle may press uncomfortably into the crotch area in any other position. It is also recommended that the saddle be perfectly aligned in the centre. This ensures that the rider is seated with their sit bones on the wide rear part of the saddle.

- 1 Adjust the saddle tilt to horizontal.
- 2 Position saddle middle so that it is completely straight.




Figure 109: Horizontal saddle tilt with 0° tilt in the centre of the saddle

- ⇒ Pedelec riders sit comfortably on the saddle and do not slip backwards or forwards.
- 3 Pedelec riders tend to slip forwards or sit on the narrow part of the saddle; readjust the saddle to position (see Section 6.3.11.9) or tilt the saddle very slightly backwards.

6.3.11.11 Checking the saddle

- Check the saddle after adjustment (see Section 7.10.8).

6.3.12 Handlebars

6.3.12.1 Replacing the handlebars

Not included in price

- ▶ Check handlebar width and hand position.
- ▶ Have handlebars replaced at the specialist dealer's if necessary.

6.3.12.2 Adjusting the handlebar width

The handlebar width should be as wide as the rider's shoulders as a minimum. This is measured from mid-point to mid-point on the hand contact surfaces.




Figure 110: Determining the optimal handlebar width

The wider the handlebars are, the more control they provide, although wide handlebars require greater supporting force. Wider handlebars are particularly useful to ensure a safer ride for loaded touring bikes.

6.3.12.3 Adjusting the hand position

The hand is in an optimal position on the handlebars when the forearm and hand are in a straight line, i.e. the wrist is not bent. In this way, the nerves are not pinched and do not cause pain.




Figure 111: Distribution of nerves with curved and straight handlebars

The narrower the shoulders are, the greater the bend of the handlebars should be (maximum 28°).

Straight handlebars are advisable for sports bikes (e.g. MTB). They support direct steering behaviour, but lead to peaks in pressure and greater muscular strain on the arm and shoulder muscles.

6.3.12.4 Adjusting the handlebars

The handlebars and their position determine the posture that the pedelec rider adopts on the pedelec.

- 1 After selecting the seating position (see Section 0.0.2), determine the angle of the upper body and the upper arm.
- 2 Tension the back muscles when adjusting the handlebars. The only way to stabilise the spine and protect it from excessive strain is to tension the back and abdominal muscles. Passive muscles are not able to perform this important task.
- 3 Set the required handlebar position on the stem by adjusting the stem height and angle (see Section 6.3.13).
- 4 After adjusting the handlebars, check the saddle height and riding position again. The position of the pelvis on the saddle may have changed when the handlebars were adjusted. This can have considerable impact on the position of the hip joint due to the pelvis tilting and may change the usable leg length on the saddle support by up to 3 cm.
- 5 Correct the saddle height and position if necessary (see Section 0.0.4.14 and 0.0.4.17).

6.3.13 Stem

6.3.13.1 Adjusting the handlebar height with quick release

Only applies to pedelecs with this equipment

- 1 Open the stem clamping lever.




Figure 112: Open (2) and closed (1) stem clamping lever; All Up used as an example

- 2 Pull out the handlebars to the required height. Observe minimum insertion depth.




Figure 113: Pulling the handlebars upwards; All Up used as an example

- 3 Close the stem clamping lever.

6.3.13.2 Checking the stem stability

- ▶ Hold handlebars firmly after adjusting the saddle. Press full body weight on the handlebars.

⇒ The handlebars remain stable in their position.

6.3.13.3 Adjusting the quick release clamping force

CAUTION Crash caused by incorrectly set clamping force

Applying excessive clamping force damages the quick release. Insufficient clamping force will result in unfavourable transmission of force. This can cause components to break. This will result in a crash with injuries.

- ▶ Never fasten a quick release using a tool (e.g. hammer or pliers).

If the *handlebar clamping lever* stops before reaching its end position, unscrew the *knurled nut*.

- ▶ Tighten the *knurled nut* on the seat post if the *seat post clamping lever's* clamping force is not effective enough.

- ▶ Contact your specialist dealer if the clamping force cannot be set.

6.3.13.4 Setting the quill stem

Only applies to pedelecs with this equipment

In the case of a quill stem, the stem and fork steerer form a permanently interconnected component, which is clamped in the fork steerer. The stem and shaft must be replaced together.




Figure 114: Adjusting the quill stem height

- 1 Undo screw.
- 2 Pull quill stem out.
- 3 Tighten screw.

Only applies to pedelecs with this equipment

Angle-adjustable stems are available in different lengths for quill and Ahead stems.




Figure 116: Different versions of angle-adjustable stems

Adjusting the stem angle (c) changes both the distance from the upper body to the handlebars (b) and the handlebar height (a).

6.3.13.5 Adjusting the Ahead stem

Only applies to pedelecs with this equipment

In the case of an Ahead stem, the stem is placed directly on the fork steerer, which protrudes over the frame.




Figure 115: Raising the Ahead stem by fitting spacer rings

The handlebar height is adjusted once during production using spacer rings. The part of the fork steerer protruding is then cut off. The handlebar stem can then no longer be set higher, but only slightly lower.




Figure 117: City bike (blue) and trekking bike position (red) by changing the angle

6.3.13.7 Checking the stem

- Check saddle stem after adjusting it (see Section 7.10.6).

6.3.14 Handles

6.3.14.1 Replacing the handles

Not included in price

If there is pain or numbness in the index, middle finger or thumb, this may be due to excessive pressure on the carpal tunnel exit point. On longer rides, this can increasingly cause hand fatigue and make it more and more difficult to maintain a correct hand position.

In the case of ergonomically shaped handles, the palm rests on the anatomically shaped handle. A greater contact surface means that the pressure is more evenly distributed. Nerves and vessels are no longer squeezed in the carpal tunnel.

Moreover, the hand is supported and held in the correct position so that the hand can no longer bend.

If the pre-mounted handles are uncomfortable or cause pain or numbness in the index, middle finger or thumb, ergonomic handles, bar ends or multi-position handlebars should be used.

6.3.14.2 Adjusting the ergonomic handles

Only applies to pedelecs with this equipment




Figure 118: Incorrect (1) and correct (2) position of the handle

6.3.14.3 Checking the handlebars

- ▶ Check handlebars after adjusting the handles (see Section 7.10.7).

6.3.15 Tyres

6.3.15.1 Adjusting the tyre pressure

It is not possible to offer a general recommended tyre pressure for a particular pedelec or tyre. The correct tyre pressure largely depends on the weight load on the tyres, mainly determined by body weight and baggage.

Unlike cars, the weight of the vehicle has only a small impact on the total weight. Moreover, the personal preferences for low rolling resistance or a high degree of suspension comfort vary a great deal. It is important to remember that

- the higher the tyre pressure is, the lower the wear, rolling resistance and the risk of breakdown are.
- The lower the pressure in the tyre is, the greater the comfort and grip is that the tyre offers.

In the case of pedelecs used on the road, the rule is the greater the tyre pressure is, the lower the tyre rolling resistance is. The risk of breakdown is also lower when the pressure is high. A permanently excessively low tyre pressure often leads to premature wear in the tyre. Cracking in the side wall is a typical consequence of very low tyre pressure. Abrasion is also unnecessarily high.

On the other hand, a tyre can absorb road impacts more effectively at a low pressure.

As a general rule, wide tyres are used at a lower tyre pressure. They provide the option of exploiting the advantages of the lower tyre pressure without the serious disadvantages it causes with regard to wear, rolling resistance and breakdown protection.

- ✓ Never exceed or go below the minimum and maximum pressure limits indicated on the tyre.

- 1 Pump the tyre to the recommended tyre pressure.

Tyre width	Tyre pressure (in bar) for body weight		
	about 60 kg	about 80 kg	about 110 kg
25 mm	6.0	7.0	8.0
28 mm	5.5	6.5	7.5
32 mm	4.5	5.5	6.5
37 mm	4.0	5.0	6.0
40 mm	3.5	4.5	6.0
47 mm	3.0	4.0	5.0
50 mm	2.5	4.0	5.0
55 mm	2.0	3.0	4.0
60 mm	2.0	3.0	4.0

Table 27: SCHWALBE recommend tyre pressure

- 2 Perform a visual check on tyres.



Figure 119: Correct tyre pressure. The tyre is barely deformed under the load of the body weight



Figure 120: Much too little tyre pressure

6.3.16 Brake

The handbrake grip distance can be adjusted to ensure that it can be reached more easily. The pressure point can also be adjusted to the S pedelec rider's preferences.

6.3.16.1 Retracting the brake linings

Disc brakes require a break-in period. The braking force increases over time. The braking force is increased during the break-in period. This is also the case when the brake pads or brake discs are replaced.

- 1 Accelerate S pedelec to 25 km/h.
 - 2 Brake S pedelec until it comes to a halt.
 - 3 Repeat process 30 to 50 times.
- ⇒ The disc brake is retracted and provides optimal braking power.

6.3.16.2 Change handbrake position

Having the handbrake in the correct position prevents the rider from stretching their wrist too far. Moreover, the brake can also be operated without any discomfort and without changing the handle position or releasing the handle.

- ✓ Apply handbrake with the third finger phalanx in bursts to brake gently.
 - ✓ The setting for the middle finger is used for S pedelec riders who brake with their middle finger or with two fingers.
- 1 Position your hand on the handle in such a way that the outer heel of the hand is flush with the end of the handlebar.
 - 2 Extend the index finger (about 15°).



Figure 121: Handbrake position

- 3 Push handbrake outwards until the third finger phalanx sits in the recessed grip.

6.3.16.3 Changing the handbrake inclination angle

The nerves that pass through the carpal tunnel are connected to the thumb and the index and middle fingers. An excessively steep or excessively flat brake angle will cause the wrist to bend, thus narrowing the carpal tunnel. This can cause numbness and tingling in the thumb and index and middle fingers.

- 1 Calculate the difference between the height of the handlebars and the saddle height to determine the saddle-handlebar height difference.




Figure 122: Example of 4 different handlebar heights (A, B, C and D) and the saddle height (E)

Calculation	Saddle-handlebar height difference [mm]
A – E	>10
B – E	0... +10
C – E	0... -10
D – E	<-10

Table 28: Examples of saddle-handlebar height difference

Adjust the angle of the handbrake so that it forms a natural extension of the forearm.

- 2 Set the brake lever angle as indicated in the table.




Figure 123: Brake angle

6.3.16.4 Determining the grip distance

- 1 Measure hand size using the grip distance gauge.
- 2 Adjust the grip distance at the pressure point based on the hand size.



Figure 124: Handbrake positioning

Hand size	Grip distance (cm)
S	2
M	3
L	4

6.3.16.5 Setting the grip distance for a MAGURA handbrake disc brake

Only applies to pedelecs with this equipment

⚠ WARNING Crash caused by incorrectly set grip distance

If brake cylinders are set incorrectly or installed wrongly, the braking power may be lost at any time. This may cause a crash with injuries.

- ▶ Ensure that the fully applied handbrake is at a minimum distance of 20 mm from the handlebars.

The handbrake position can be adjusted to the rider's requirements. Such adjustment does not affect the pressure point or the position of the brake linings.

- ▶ Turn the setting screw/twist knob (5) anti-clockwise towards minus (-).
 - ⇒ The handbrake will move closer to the handlebar grip.
- ▶ Turn the setting screw/twist knob (5) clockwise towards plus (+).
 - ⇒ The handbrake will move away from the handlebar grip.




Figure 125: Adjusting the grip distance for a MAGURA handbrake disc brake

6.3.16.6 MAGURA handbrake pressure point Only applies to pedelecs with this equipment

⚠ WARNING Brake failure due to incorrect setting

If the pressure point is set with brake linings where the brake linings and brake disc have reached their wear limit, the brakes may fail and cause an accident with injury.

- ▶ Before you adjust the pressure point, ensure that the brake linings and brake disc have not reached their wear limit.

The pressure point setting is adjusted using the twist knob.

- ▶ Turn the twist knob towards the plus (+) symbol.
 - ⇒ The handbrake moves closer to the handlebars.
 - ⇒ The lever pressure point activates sooner.
- ▶ Re-adjust the grip distance as necessary.
- ▶ Turn the twist knob towards the minus (-).
 - ⇒ The handbrake moves further away from the handlebars.
 - ⇒ The lever pressure point activates later.
- ▶ Re-adjust the grip distance as necessary.




Figure 126: Using the twist knob (1) to adjust the pressure point

6.3.16.7 Setting the grip distance on a TEKTRON handbrake

Only applies to pedelecs with this equipment

Notice If the setting screw is fully removed, components inside the handbrake will also be permanently twisted off as well. The handbrake will be permanently damaged.

- ▶ Never completely remove setting screws.

The handbrake position can be adjusted to the rider's requirements.

- ▶ Undo 2 mm setting screw anti-clockwise.
 - ⇒ The handbrake will move closer to the handlebar grip.
- ▶ Turn 2 mm setting screw clockwise.
 - ⇒ The handbrake will move away from the handlebar grip.
 - ⇒ This adjustment affects the position of the brake linings.
- ▶ Re-adjust the brake linings after adjustment.




Figure 127: Setting screw position (1)

6.3.17 Control panel and gear shift

The control panel and gear shift must be adjusted to the rider's needs.

- 1 Undo attachment screw.
- 2 Place control panel or gear shift into the position where the rider can use the control panel or the shifter with their thumb and/or index finger.
- 3 Fasten attachment screw into position with a 4 mm hex bit with 3 Nm.

6.3.17.1 SHIMANO shifter

Only applies to vehicles with this equipment




Figure 128: Position of attachment screw (1)

6.3.17.2 Registering the Rohloff gear hub

Only applies to pedelecs with this equipment

Each Rohloff hub has a unique consecutive serial number on its housing.




Figure 129: ROHLOFF Speedhub 500/14 serial number

You must register the gear hub so that Rohloff can provide servicing (maintenance, repair) and the warranty. Registration means the year of manufacture and component generation can be classified for the ROHLOFF Speedhub 500/14 hub. This ensures that servicing can be handled quickly and conveniently. In the event of theft, the hub can be traced and misuse can be prevented.

- ✓ Check that the ROHLOFF Speedhub 500/14 is complete, including accessories, and that there are no apparent defects.
- ✓ Note down the serial number on the hub.
- ▶ Register the gear hub online at:

www.rohloff.de/de/service/meine-speedhub/registrierung

- ⇒ Verification that the ROHLOFF Speedhub 500/14 is complete (including accessories) and has no apparent defects has been confirmed. Servicing can be carried out.

6.3.18 Suspension and damping

Suspension and damping can be adjusted to the rider's weight in up to six increments, depending on the suspension system.

► Follow the correct order for adjustment.

Order sequence	Adjustment	Section	Only for pedelecs with components	
			Suspension fork	Rear frame damper
1	Adjusting the suspension fork sag	Section 6.3.19	x	
2	Adjusting the rear frame damper sag	Section 6.3.20		x
3	Adjusting the suspension fork rebound damper (optional)	Section 2.1.12	x	
4	Adjusting the rear frame damper rebound damper	Section 2.1.13		x
5	Before each ride:			
	Adjusting the rear frame damper compression damper	Section 6.4.16		x
6	While riding:			
	Adjusting the suspension fork	Section 6.21	x	

Table 29: Correct order for suspension and damping adjustment

6.3.19 Adjusting the suspension fork sag

⚠ CAUTION Crash caused by incorrectly set suspension

If the suspension is set incorrectly, the suspension fork may become damaged, meaning problems may occur when steering. This will result in a crash with injuries.

- Never ride without air in air suspension forks.
- Never use the pedelec without adjusting the suspension fork to the body weight.

Adjustments to the chassis settings change ride performance significantly. The rider needs to get used to the pedelec and break it in to prevent accidents.

The sag depends on the position and body weight and should be set based on preferences and on how the pedelec is used.

Greater sag

A greater sag increases sensitivity to bumps, thus producing greater suspension motion. A greater sensitivity to bumps ensures more comfortable ride performance and is used on pedelecs with longer deflection.

Decreased sag

A decreased sag reduces sensitivity to bumps, thus producing less suspension motion. A lower sensitivity to bumps ensures a firmer, more efficient ride performance and is generally used on pedelecs with shorter deflections. The adjustment shown here represents a default setting. The default settings should change, adapted to suit the surface and preferences.

It is advisable to make a note of the default settings. These can then be used as a starting point for subsequent optimised settings and as a safeguard against unintentional changes.

6.3.19.1 Adjusting the sag for the SR SUNTOUR steel suspension fork

Only applies to pedelecs with this equipment

You can set the fork by pre-tensioning the steel spring to adjust to the rider's weight and their

preferred riding style. It is not the hardness of the coil spring that is adjusted but its pre-tensioning.




Figure 130: Example with SR SUNTOUR, sag setting wheel on the fork crown

- 1 Put on normal cycling clothing (including baggage).
- 2 Turn the **sag setting wheel** (see Section [3.6.4.1](#)) until the required sag is reached.
 - ▶ Turn the **sag setting wheel** clockwise.
 - ⇒ The pre-tensioning in the spring is increased.
 - ▶ Turn the **sag setting wheel** anticlockwise.
 - ⇒ The pre-tensioning in the spring is increased.
- 3 If you are unable to achieve the required degree of hardness, contact your specialist dealer.

6.3.20 Adjusting the rear frame damper sag

CAUTION Crash caused by broken rear frame damper

If the rear frame damper's maximum air pressure is exceeded, this can cause the rear frame damper to break. This can result in loss of control and a crash with cut injuries or even death.

- ▶ Never exceed the indicated maximum air pressure when adjusting the sag.

Notice Adjustments to the chassis settings change ride performance significantly. The rider needs to get used to the pedelec and break it in to prevent accidents.

The adjustment shown here represents a default setting. The rider should change the default setting to suit the terrain surface and their preferences.

It is advisable to make a note of the default settings. These can then be used as a starting point for subsequent optimised settings and as a safeguard against unintentional changes.

Negative deflection (sag)

The sag is the percentage of total spring deflection that is compressed by the rider's body weight, including equipment (such as a backpack), their seating position and frame geometry. Sag is not caused by riding.

Greater sag

A greater sag increases sensitivity to bumps, thus producing greater suspension motion. A greater sensitivity to bumps ensures more comfortable ride performance and is used on pedelecs with a longer deflection.

Decreased sag

A decreased sag reduces sensitivity to bumps, thus producing less suspension motion. A lower sensitivity to bumps ensures a firmer, more efficient ride performance and is generally used on pedelecs with a shorter deflection.




Figure 131: Sag rear frame damper

When optimally adjusted, the rear frame damper deflects quickly and unhindered when the bike hits bumps and absorbs a bump. The traction is maintained.

6.3.20.1 Adjusting the SR SUNTOUR rear frame damper sag

Only applies to pedelecs with this equipment

Every rear frame damper has a specific delivery air pressure ex works. These levels are starting points. These settings can be changed based on riding skills, trail conditions, frame design and personal preferences.

After setting up the rear frame damper, check the sag to ensure that the recommended settings are observed.

Recommended air pressure [psi]										
	Vorocoil		Triair2		Triair		EDGE-comp	EDGE-Plus	EDGE	RAIDON
	Main body	Air reservoir	Main body	Air reservoir	Main body	Air reservoir	Main body	Main body	Main body	Main body
Pressure Factory setting	...	200	180	180	180	200	110	110	110	110
Maximum pressure	...	250	300	240	300	240	300	300	300	300

Table 30: Suntour rear frame damper filling pressure table

- ✓ Adjusting the suspension fork sag (see Section 6.3.19).
 - ✓ The **compression lever** is set to OPEN.
- 1 **Remove cap from the air valve** (rear frame damper).
 - 2 Attach a high-pressure damper pump to the **air valve (rear frame damper)**.
 - 3 Pump the rear frame damper to the required pressure. Never exceed the recommended maximum air pressure from the Suntour rear frame damper filling pressure table (see Table [Table: 30, page 138]).

Notice If the air pressure in the rear frame damper is exceeded or undershot, the damper can be permanently damaged.
 - 4 Remove high-pressure damper pump from the **air valve (rear frame damper)**.
 - 5 Apply force on the saddle to compress the rear frame damper several times by at least 50% of the full deflection.
- ⇒ This equalises the air pressure between positive and negative air chambers.

- 6 Measure the gap between the **air chamber seal** and the end of the rear frame damper. This gap is the **total deflection (rear frame damper)**.




Figure 132: Measuring the total deflection (rear frame damper)

- 7 Attach cable tie if there is no **O-ring** on the rear frame damper.
 - 8 Put on your normal cycling clothing, including baggage.
 - 9 Ask someone to hold the pedelec. Sit on the pedelec in your usual riding position and support yourself against an object, such as a wall or tree.
 - 10 Apply force on the saddle to fully deflect the rear frame damper gently two or three times.
 - 11 The helper pushes the **O-ring** or cable tie downwards against the **air chamber seal**.
 - 12 Get off the pedelec carefully, ensuring that the rear frame damper does not deflect.
 - 13 Measure the gap between the **air chamber seal** and the **O-ring**.
- ⇒ This measurement is the sag. The recommended value is between hard (lowest value) and soft (highest value).

Shock absorber deflection [mm]	SAG [%]	Gap [mm]
75	25... 35	18.75... 26.25
70		17.50... 24.50
65		16.25... 22.75
60		15.00... 21.00
55	25... 30	13.75... 16.50
50	20... 25	10.00... 12.50
45		9.00... 11.25
40		8.00... 10.00
35		7.00... 8.75
30		6.00... 7.50

Table 31: Recommended sag for the rear frame damper

- 14 The air pressure must be adjusted if the required sag level is not reached.
 - ▶ Increase the air pressure to reduce the sag.
 - ▶ Decrease the air pressure to increase the sag.
- 15 If the sag is correct, place the **cap** on the **air valve (rear frame damper)**.
- 16 If you are unable to achieve the required sag, the suspension fork will need to be adjusted internally. Contact specialist dealer.

6.3.21 Riding light

6.3.21.1 Setting the riding light

Example 1

If the headlight is positioned too high, the rider will dazzle oncoming traffic. This can cause a serious accident with fatalities.

Example 2

Positioning the headlight correctly can ensure that oncoming traffic is not dazzled and no-one is put at risk.

Example 3

If the headlight is positioned too low, the space ahead is not illuminated to an optimum extent and the rider's vision is reduced in the dark.




Figure 133: Light positioned too high (1), correctly (2) and too low (3)

6.3.21.2 Adjusting the headlight




Figure 134: Measuring on the wall

- 1 Position the pedelec so that its front is facing a wall.
- 2 Mark the height of the headlight (1) on the wall with chalk.
- 3 Mark half the height of the headlight (2) on the wall with chalk.

- 4 Place pedelec 5 m in front of the wall.
- 5 Stand the pedelec up straight.

- 6 Hold the handlebars straight with both hands. Do not use the kickstand.
- 7 Switch on riding light.




Figure 135: Light positioned too high (1), correctly (2) and too low (3)

- 8 Check the position of the light beam.
 - ▶ (I) if the upper edge of the light beam is above the headlight height mark (1), the riding light will dazzle. The headlight must be positioned lower.
 - ▶ If the mid-point of the light beam is on or slightly below the mark showing half the height of the headlight (2), the lighting is optimally positioned.
 - ▶ If the light beam is in front of the wall, move the headlight up.

6.3.22 Adjusting Kiox 300 and Kiox 500 on-board computer

A smartphone with the eBike Flow app is required to use all drive system functions. The pedelec is connected to the app via a Bluetooth® connection.

6.3.22.1 Creating a user account

The rider needs to register online and create a user account first.

Registering on a PC

- 1 Create the user account on the BOSCH website.
- 2 Enter all the details required for registration.

Registering on a smartphone

Apple iPhones

- ▶ Download the Bosch eBike Flow smartphone app from the App Store for free.

Android devices

- ▶ Download the eBike Flow smartphone app from the Google Play Store for free.

6.3.22.2 Connecting the on-board computer to a smartphone

- ✓ The BOSCH eBike Flow app is downloaded onto the smartphone.
- ✓ The drive system is switched on.
- ✓ The pedelec is stationary.

- 1 Launch app.
 - 2 Select the <My eBike> tab in the app.
 - 3 Select the <Add new eBike device> tab in the app.
 - 4 Press the **on-off button on the pedelec** for longer than 3 seconds.
- ⇒ The top bar on the control panel battery level indicator flashes blue.
 - ⇒ The on-board computer will switch the Bluetooth® Low Energy connection on and change to pairing mode

- 5 Release the **on-off button**.

- 6 Accept the connection prompt in the app.

- 7 Follow the instructions on the display.

- ⇒ The user data will be synchronised once the pairing process is complete.

6.3.22.3 Updating the software

Software updates are managed by the Bosch eBike Flow smartphone app.

- ✓ The on-board computer is now connected to the smartphone.
- ✓ The drive system is switched on.
- ✓ The pedelec is stationary.
- ⇒ A new software update is downloaded automatically onto the on-board computer.
- ⇒ The battery level indicator will flash green during updates to show how the update is progressing.
- ⇒ The system is restarted after an update has completed successfully.

6.3.22.4 Activating the activity tracking

- ✓ Your location will only be logged if the on-board computer is connected to the Bosch eBike Flow smartphone app.
- ▶ Agree to activities being collected and stored on the platform or in the app.
- ⇒ All the pedelec's activities are stored and displayed on the platform and in the app.

6.3.22.5 Setting up the lock function (optional)

The user account can be used to activate the lock function. This will create a digital key on the smartphone, which is required to start the drive system.

Once the lock function is switched on, the pedelec can only be put into use if:

- the configured smartphone is switched on,
- the smartphone is charged sufficiently and
- the smartphone is directly next to the control panel.

If the key is not immediately verified on the smartphone, the battery level indicator and the display of selected level of assistance on the pedelec flash white to indicate a search for the key.

If the key is found, the battery level indicator flashes white. The last configured level of assistance is displayed. If the key cannot be found on the smartphone, the pedelec drive system switches off. The indicators on the control panel go off.

As the smartphone is only used as a contactless key to switch on the pedelec, the battery and control panel can still be used on another, unblocked pedelec.

6.3.22.6 Inserting the display

- 1 Place display (1) on the locking hook (2) on the front edge of display mount (3) facing the direction of travel.
- 2 Press display rear onto the display mount.




Figure 136: Inserting the display

6.3.22.7 Securing the on-board, computer (optional)

It is possible to secure the on-board computer so that it cannot be removed. The locking plate does not offer theft detection.




Figure 137: Position of headset screw

- 1 Insert locking plate (3) into the adapter tray (2) until you hear the locking plate lock into position.
 - ⇒ The display mount (1) can now only be removed if the two attachment screws (4) are undone.

6.3.22.8 Removing the on-board computer

- ⇒ The on-board computer can be removed if it is not secured.




Figure 138: Removing the on-board computer

- Pull display (1) forwards until the display is lifted from the display mount (2).

6.3.22.9 Adjusting the on-board computer

Notice

- ▶ Never use on-board computer, the display or the display mount as a handle. If the on-board computer, display or display mount are used to lift the pedelec, components can become irreparably damaged.




Figure 139: BOSCH LCD Remote operating elements

	Symbol	Designation
1	>	Increase brightness button/ forward button (scroll left)
2	<	Decrease brightness button/ back button (scroll right)
3	◆	Select button
4	+	Plus button/ light button
5	-	Minus button/ push assist button

Table 32: Description of BOSCH LCD Remote operating elements

You can use the **select button** (4) to perform the following functions:

- Open the QUICK MENU while riding
- Open the SETTINGS MENU on the STATUS SCREEN while the bicycle is stationary
- Confirm values and accept information notifications
- Leave a dialogue.

You can use the **forward button** (1) and **back button** (2) to access the different user interfaces with information on ride values even when riding. This means both hands remain on the handlebars while you are cycling.

You can use the **plus button** (4) and the **minus button** (5) to increase and decrease the level of assistance. You can use the buttons to scroll up and down a list (such as the SETTINGS menu).

Open start screen

- ▶ Press **on-off button**
- ⇒ The START SCREEN is displayed.

Opening screens

- ▶ Press the **forward button** or **back button**.
- ⇒ A new screen is displayed.

Opening the Status screen

- 1 Open the START SCREEN.
 - 2 Press the **back button**.
- ⇒ The STATUS SCREEN is displayed.

6.3.22.10 Adjusting the on-board computer

- ✓ The pedelec is stationary. You cannot open and adjust the settings while riding.
- ✓ Inserting the display.
- ✓ [Switching on the electric drive system](#)

- 1 Open STATUS SCREEN.
- 2 Press the **select button**.

The settings menu is displayed.

Menu	Sub-menu
My eBike	
	→ <Range reset>
	→ <Auto trip reset>
	→ <Wheel circum.>
	→ <Service>
	→ <Components>

Table 33: Basic structure of menu and sub-menu

Menu	Sub-menu
My Kiox	
	→ <Status bar>
	→ <Language>
	→ <Units>
	→ <Time>
	→ <Time Format>
	→ <Brightness>
	→ <Settings reset>
Information	
	→ <Contact>
	→ <Certificates>

Table 33: Basic structure of menu and sub-menu

⇒ Use the **plus** and **minus buttons** to select the required setting.

- ▶ Press the **select button** to confirm.
- ▶ Use the **back button** to return to the previous menu.
- ▶ Follow the instructions on the on-board computer.

6.3.22.11 Selecting the language

- 1 Open <System> menu item.
- 2 Open <Language> sub-menu item.
- 3 Follow the instructions on the on-board computer.

⇒ The language has been selected.

6.3.22.12 Adjusting the clock

- 1 Open <System> menu item.
- 2 Open <Time> sub-menu item.
- 3 Follow the instructions on the on-board computer.

⇒ The time has been set.

6.3.22.13 Setting the time format

- 1 Open <System> menu item.
 - 2 Open <Time Format> sub-menu item.
 - 3 Follow the instructions on the on-board computer.
- ⇒ The Time Format is set.

6.3.22.14 Selecting units

- 1 Open <System> menu item.
 - 2 Open <Units> sub-menu item.
 - 3 Follow the instructions on the on-board computer.
- ⇒ The unit of speed is displayed in the selected km/h or mph format.

6.3.22.15 Setting the brightness

- 1 Open <System> menu item.
 - 2 Open <Brightness> sub-menu item.
 - 3 Follow the instructions on the on-board computer.
- ⇒ The brightness has been set.

6.3.22.16 Resetting the settings

- 1 Open <System> menu item.
 - 2 Open <Settings reset> sub-menu item.
 - 3 Follow the instructions on the on-board computer.
- ⇒ All settings are reset to the factory settings. All user data has been cleared.

6.4 Accessories

The following accessories are approved for i:SY pedelecs.

6.4.1 Child seat

⚠ WARNING Crash caused by attachment to non-load-bearing components

Pannier racks with a maximum load capacity under 27 kg and the down tube are unsuitable for mounting child seats and may break. Such an incorrect position may cause a crash with serious injuries for the pedelec rider or child.

- ▶ Never attach a child seat to the saddle, handlebars or down tube.

Carbon frames are unsuitable for child seats and may break. Such an incorrect position may cause a crash with serious injuries for the pedelec rider or child.

- ▶ Never fasten a child seat to a carbon frame or a carbon component.

⚠ CAUTION Crash caused by improper handling

When using child seats, the pedelec's handling characteristics and stability change considerably. This can cause a loss of control, a crash and injuries.

- ▶ You should practice how to use the child seat safely before using the pedelec in public spaces.

⚠ CAUTION Risk of crushing due to exposed springs

The child may crush their fingers on exposed springs or open mechanical parts attached to the saddle or the seat post.

- ▶ Never install saddles with exposed springs if a child seat is being used.
- ▶ Only fit suspension seat posts with a protected mechanism springs if you use a child seat.

Notice

- ▶ Observe the legal regulations on the use of child seats.
- ▶ Observe the operating and safety instructions for the child seat system.
- ▶ Never exceed the maximum permitted total weight.

The specialist dealer will advise you on which child seat system is suitable for the child and the pedelec.

The specialist dealer must install the child seat the first time to ensure that it is safely fitted.

When installing a child seat, it must be ensured that:

- the seat and the seat fastening are suitable for the pedelec
- all components are installed and securely fastened
- shift cables, brake cables, hydraulic and electrical cables are adjusted as necessary
- the pedelec rider has optimum freedom of movement
- the maximum permitted total weight of the pedelec is observed.

The specialist dealer will provide instruction on how to handle the pedelec and the child seat.

6.4.1.1 THULE, Yepp 2 Maxi Rack Mount



Figure 140: THULE, Yepp 2 Maxi Rack Mount

Adjustable, padded 5-point safety harness for secure, personalized fitting and maximum comfort, made of water-repellent materials and with an integrated lock for securing to the pannier rack.

Compatible with the i:SY MONKEYLOAD ready Pannier Rack for model year 2022 and later.

- Maximum weight of child: 22 kg
- Product weight: about 3.5 kg

Article number	Description
5021310	THULE, Yepp 2 Maxi Rack Mount

6.4.1.2 Suspension seat post protective covers



Figure 141: Suspension seat post protective covers

Protects the suspension seat post spring mechanism against dirt and prevents children's hands from becoming trapped when using a child seat.

Article number	Description
6032506	by.schulz (ST)
6032507	by.schulz (LT)
6032371	SR SUNTOUR neoprene cuff

6.4.2 Trailers

⚠ WARNING Crash caused by attachment to non-load-bearing components

Carbon frames are unsuitable for use with trailer adapters and may break. Such an incorrect position may cause a crash with serious injuries for the pedelec rider.

- ▶ Never use a trailer adapter on a carbon frame.

⚠ CAUTION Crash caused by brake failure

The braking distance may be longer if the trailer is carrying excessive load. The long braking distance can cause a crash or an accident and injuries.

Notice

- ▶ The operating and safety instructions for the trailer system must be observed.
- ▶ Observe the statutory regulations on the use of bicycle trailers.
- ▶ Only use type-approved coupling systems.

A pedelec which is approved for towing a trailer will bear an appropriate adhesive label. You may only use trailers with a tongue load and weight which do not exceed the permitted values.




Figure 142: Trailer sign

6.4.2.1 i:SY Trailer Adapter



Figure 143: i:SY Trailer Adapter 1.0 and 2.0

There are suitable trailer adapters for the frames to fasten a trailer to an i:SY pedelec.

The adapter provides level attachment for the trailer and is compatible with all standard couplings for mounting to the axle. The adapter comes in an assembly kit. We recommend asking your i:SY specialist dealer to assemble it.

The max. tongue load is 6 kg and the max. tensile load is 60 kg.

Article number	Description
23000176	i:SY Trailer Adapter 1.0
23000177	i:SY Trailer Adapter 2.0

6.4.3 MonkeyLoad system

i:SY pannier racks are MonkeyLoad ready. This means all MonkeyLoad system components can be used on the pannier rack. Other systems such as I-Rack, racktime or MIK are not compatible.

- ▶ Never exceed the indicated maximum load capacity of 10 kg for MonkeyLoad system components when using them.
- ▶ Use a paint protection film when attaching panniers. This will reduce abrasion on paint and wear on components.

There are two holding fixtures beneath MonkeyLoad bags and baskets which fit into the pannier rack fastening points precisely.





Figure 144: Basket with MonkeyLoad adapter plate and pull knob (1)

6.4.3.1 Attaching MonkeyLoad system components

- 1 Place MonkeyLoad system component in the correct position on the pannier rack.
- 2 Apply a little pressure to the MonkeyLoad system components.
 - ⇒ The system component is now attached to the pannier rack.
- 3 If the system component is to remain on the pedelec for a longer period of time, lock the MonkeyLoad system with the key.
- 4 Remove the key.

6.4.3.2 Detaching MonkeyLoad system components

- 1 Open locked MonkeyLoad system with the key.
 - 2 Pull on the pull knob gently.
 - 3 The system component is unlocked.
- ⇒ The system component can be removed from the pannier rack.



5121602	MonkeyLoad adapter plate
---------	--------------------------



23000035	i:SY Pannier Rack Trunk Bag
----------	-----------------------------






i:SY Watertight Pannier, large

23000064	Black
----------	-------

23000168	Neon yellow
----------	-------------



Article number	Description
5020319	MonkeyLoad lock
	
23000127	i:SY Aluminium Crosswise Pannier Rack Basket
	
23000128	i:SY Aluminium Lengthwise Pannier Rack Basket
	
23000126	i:SY Aluminium Front Basket
	
23000034	i:SY Foldable Basket



5031841	Bordo lock, combination lock
5031840	Bordo lock, lock



6.4.4 Front baskets

6.4.4.1 i:SY, KLiCKfix Front Carrier



Figure 145: i:SY, KLiCKfix Front Carrier

- Material: steel
- Colour: black
- Dimensions: 18 x 26 x 20 cm (W x H x D)
- Max. load: 12 kg (carrier)/7 kg (KLiCKfix system components)

Article number	Description
23000000	i:SY, KLiCKfix Front Carrier

6.4.4.2 i:SY, 2.0 Front Carrier



Figure 146: i:SY, 2.0 Front Carrier

Suitable for the SKYFLY und P12 models. With integrated MonkeyLoad-T and KLiCKfix® mount.

- Material: Aluminium
- Max. load: 15 kg (carrier) | 10 kg MonkeyLoad-T | 7 kg (KLiCKfix)

Article number	Description
23000178	i:SY, 2.0 Front Carrier

6.4.4.3 i:SY, MiK Front Carrier



Figure 147: i:SY, MiK Front Carrier

- Compatible with the BASIL Buddy dog basket
- MiK system integrated
- Can be attached with a KLiCKfix adapter
- Colour: black
- Dimensions: 28 x 20 x 16 cm (W x H x D)
- Max. load: 12 kg

Article number	Description
23000001	i:SY, MiK Front Carrier

6.4.4.4 KLiCKfix Caddy handlebar adapter



Figure 148: KLiCKfix Caddy handlebar adapter

upgrades the i:SY MiK Front Carrier so that it can also hold KLiCKfix® baskets and bags.

Article number	Description
5020544	KLiCKfix Caddy handlebar adapter

6.4.4.5 i:SY, MAXI Front Carrier



Figure 149: i:SY, MAXI Front Carrier

- Material: Steel
- Colour: black
- Dimensions: 45 x 16 x 29 cm (W x H x D)
- Max. load: 12 kg

Article number	Description
23000002	i:SY, MAXI Front Carrier

0.0.0.4 i:SY, Lowrider



Figure 150: i:SY, Lowrider

Attached to the fork; suitable for the watertight i:SY pannier rack bags

- Material: Aluminium
- Colour: black
- Weight: about 580 g
- Max. load: 4 kg per side

Article number	Description
23000003	i:SY, Lowrider

6.4.5 Panniers and cargo boxes

6.4.5.1 BASIL, Buddy Dog Basket by i:SY



Figure 151: BASIL, Buddy Dog Basket

Dog basket for MIK Front Carrier

- Material: polypropylene
- Weight: about 1600 g
- Capacity: about 32 l
- Capacity: 32 litres; max. load: 9 kg

Article number	Description
23000156	Chestnut brown
23000050	Midnight blue

6.4.5.2 Dog basket



Figure 152: i:SY Clipper Dog Equipment

Retrofit kit for the i:SY Clipper, consisting of a cushion, leash harness and wire dome. Suitable for dogs up to 8 kg.

Article number	Description
23000152	i:SY Clipper Dog Equipment
5020932	Wire dome for the Buddy dog basket

6.4.5.3 i:SY, front shopping basket



Figure 153: i:SY, front shopping basket

Shopping basked for KLICKfix Front Carrier

- Large, oval bike basket with carrying handle, including KLICKfix adapter plate
- Dimensions: 27 × 27 × 36 cm
- Capacity: 16 litres
- Max. load: 7 kg

Article number	Description
23000053	i:SY, Front Shopping Basket

6.4.5.4 i:SY, watertight pannier, small



Figure 154: i:SY, front shopping basket

Shopping basked for KLICKfix Front Carrier

- Large, oval bike basket with carrying handle, including KLICKfix adapter plate
- Dimensions: 27 × 27 × 36 cm
- Capacity: 16 litres
- Max. load: 7 kg

Article number	Description
23000053	i:SY, Front Shopping Basket

6.4.5.5 Tension belt



Figure 155: i:SY, tension belt

The tension belt is suitable for pannier racks model year 2022 and later. The hooks also feature integrated safety clips so that the belt remains firmly attached even when riding over potholes.

Article number	Description
23000157	i:SY, tension belt

6.4.6 Saddle

6.4.6.1 Leather saddle



Figure 156: i:SY real leather saddle

- Material: Leather
- Weight: about 430 g

Description	Article number
Real leather saddle	23000129

6.4.6.2 ZECURE-saddle



Figure 157: ZECURE (S, M and L) saddle

Description	Article number
ZECURE, hydro foam, size S Width: 16.3 cm	061-30793
ZECURE, hydro foam, size M Width: 19.3 cm	061-30794
ZECURE, hydro foam, size L Width: 22.0 cm	061-30795
ZECURE, Comfort, size XL Width: 22.0 cm, with indent for coccyx	061-30799

6.4.6.3 Saddle protection



Figure 158: i:SY Feel Good saddle cover

If you park your bike outdoors, you'll be all too familiar with a wet saddle and wet trouser seat. This waterproof saddle cover with heat-sealed seams provides a remedy. An integrated adjustment system adapts the cover to the different i:SY saddle sizes.

- Material: Oxford Cloth 600D
- Weight: approx. 40 g

Description	Article number
i:SY Feel Good saddle cover	061-30793

6.4.7 Seat post



Figure 159: BY.SCHULZ Parallelogram suspension seat post G.2

Description	Article number
BY.SCHULZ, G.2 ST	
Body weight: 60 ... 85 kg	6032487
Body weight: 80 ... 105 kg	6032509
Body weight: 100 ... 130 kg	6032488
Body weight: 125 ... 150 kg	6032489
BY.SCHULZ, G.2 LT	
Body weight: 60 ... 85 kg	23000090
Body weight: 80 ... 105 kg	23000093
Body weight: 100 ... 130 kg	23000094
Body weight: 125 ... 150 kg	23000095
SR SUNTOUR NCX	
Reducing sleeve, 31.6 mm	6032377

6.4.8 Saddle tensioner



Figure 160: i:SY saddle tensioner

Adjust the saddle height with little effort with no need for tools.

- Material: Aluminium
- Weight: approx. 65 g

Description	Article number
i:SY SPECIAL SADDLE TENSIONER	23000092

6.4.9 Adjustable stem



Figure 161: i:SY adjustable stem

- Material: Aluminium
- Weight: approx. 380 g
- Length: 90 mm

Description	Article number
i:SY adjustable stem	23000080

6.4.10 Handlebars



Figure 162: i:SY Comfort handlebars

- Material: Aluminium
- Weight: approx. 320 g
- Offset: 40°

Description	Article number
i:SY Comfort handlebars	23000145

6.4.11 Leather handles



Figure 163: i:SY leather handles

Ergonomically shaped, high-quality sewn real leather handles.

- Material: Leather
- Weight: 190 g

Description	Article number
i:SY leather handles	23000130

6.4.12 Folding pedals



Figure 164: i:SY folding pedals

Metal-reinforced, tool-free folding mechanism. With an enlarged tread surface, lined with high-grade sandpaper for an optimum grip, even when you're wearing shoes with smooth soles.

- Material: Aluminium
- Weight: 540 g

Description	Article number
i:SY Folding Pedals	23000115

6.4.13 Protective covers

Description	Article number
	
i:SY motor protective cover	23000106
	
i:SY battery protective cover 400 and 500 WH	23000107
	
i:SY battery protective cover 545 Wh	23000169
	
i:SY contacts protective cover	23000108
	
Transport protection set	23000170

6.4.14 Two-leg stand



Figure 165: ATRAN VELO two-leg stand

Sturdy two-leg stand for the i:SY. We recommend using a handlebar damper.

⚠ WARNING Crash caused by tipping over

A pedelec parked on a two-leg stand can topple over if a child who is strapped into a child seat moves around. This may cause a crash with serious injuries for the child.

- ▶ If you are using a child seat, keep an eye on the child at all times, even when the two-leg stand is extended.

Not suitable for models with Schwalbe Super Moto X tyres, i:SY Comfort variants from 2024 and later, i:SY Cargo, i:SY P12 and i:SY SKYFLY.

Description	Article number
ATRAN VELO two-leg stand	23000146

6.4.15 Lock chain



Figure 166: i:SY lock chain

- Length: 130 cm
- Weight: about 1.1 Kg

Description	Article number
i:SY Lock Chain	23000116

6.4.16 Adapter



Figure 167: i:SY Adapter

Fitted to the head tube, this adapter can hold numerous accessory items.

Description	Article number
Black	23000158
Silver	23000004

6.4.17 Rear mirror



Figure 168: i:SY rear mirror

Description	Article number
Rear mirror	23000132

6.4.18 ROHLOFF gear hub tool

ROHLOFF recommends taking suitable precautions, especially when touring in countries or regions where a poor supply of spare parts or tools is to be expected. ROHLOFF has compiled a list of tools and other small items you should take with you on bike tours.

Tools for touring within the EU

- Hex key, 2 mm (bayonet locks/cable drum screws)
- Hex key, 3 mm (oil drain screw)
- Hex key, 5 mm (attachment screw for chain tensioner and torque support)
- Ring/open-end spanner, 8 mm (to rotate the gear shift shaft)
- Chain oil and grease
- Torx® TX 20 (all other screws for the ROHLOFF Speedhub 500/14)

Additional accessories for touring worldwide

- Oil change set
- Sprocket remover
- Spare chain and spare sprocket
- Spare spokes
- Spare gear cables
- Internal gear shift control: Spare shift cable
- Shift cable easy set
- Axle ring

► Contact specialist dealer to purchase tools

6.5 Personal protective equipment and accessories for road safety

Seeing and being seen is crucial in road traffic. The following requirements must be met for riding a pedelec safely on public roads.




Figure 169: Road safety

- 1 The **helmet** must have a reflective strip or a light in a clearly visible colour.
- 2 **Cycle clothing** is essential at all times of year. Clothing should be retroreflective or as light as possible. Fluorescent materials are also suitable. High-visibility jackets and straps on your upper body ensure even greater safety. Never wear a skirt. Always wear trousers which reach down to your ankles instead.
- 3 The **large red reflector** with a “Z” registration mark and the **red rear light** must be clean. The rear light is attached high enough so that cars can see it (minimum height 25 cm). The rear light must work.
- 4 The two **reflectors on the two non-slip pedals** must be clean.
- 5 The **yellow spoke reflectors** on both wheels or the **white, fluorescent surface** on both wheels must be clean.
- 6 The **white front light** must work and must be positioned so that it does not dazzle other road users. The white front light and the **white reflector** must be clean at all times.
- 7 The **two separate brakes** on the pedelec must work at all times.
- 8 The **clearly audible bell** must be fitted and must work.

6.6 Before each ride

- ▶ Check pedelec before each ride; see Section [6.1](#).

Checklist before each ride		
<input type="checkbox"/>	Check everything is sufficiently clean.	See Section 6.2
<input type="checkbox"/>	Check safety guards.	See Section 6.1.1
<input type="checkbox"/>	Check battery to ensure it is firmly in place.	See Section 6.16.2
<input type="checkbox"/>	Check lights.	See Section 6.1.13
<input type="checkbox"/>	Check brake.	See Section 6.1.14
<input type="checkbox"/>	Check suspension seat post.	See Section 6.1.9
<input type="checkbox"/>	Check pannier rack.	See Section 6.1.5
<input type="checkbox"/>	Check bell.	See Section 6.1.10
<input type="checkbox"/>	Check handles.	See Section 6.1.11
<input type="checkbox"/>	Check rear frame damper.	See Section 6.1.4
<input type="checkbox"/>	Check frame.	See Section 6.1.2
<input type="checkbox"/>	Check wheel concentricity.	See Section 6.1.7
<input type="checkbox"/>	Check quick releases.	See Section 6.1.8
<input type="checkbox"/>	Check guards.	See Section 6.1.6
<input type="checkbox"/>	Check USB cover.	See Section 6.1.12

- ▶ Be alert to any unusual noises, vibrations or odours while riding. Watch out for any unusual responses or behaviour when braking, pedalling or steering. This indicates material fatigue.
- ✓ Take pedelec out of service if there are any deviations from the “Before each ride” checklist or any unusual behaviour. Contact specialist dealer.

6.7 Using the battery

- ✓ Switch off the battery and the drive system before removing or inserting the battery.

6.7.1 Inserting the battery

- ✓ The key is inserted in the lock.
 - ✓ The lock is unlocked.
- 1 Place the battery into the lower mount with the contacts facing the front (1).




Figure 170: Insert the PowerPack battery

- 2 Flip the battery upwards so that the battery is held by the retainer guard (2).




Figure 171: Close the PowerPack battery upwards

- 3 Keep the lock open with the key.
 - 4 Push the battery upwards (3).
- ⇒ The battery can be heard locking into place.

- 5 Check battery to ensure it is firmly in place on all sides.
- 6 Lock the battery with the battery key; otherwise, the battery may fall out of the mount when you open (4).
- 7 Remove the battery key from the battery lock.
- 8 Check the battery to ensure it is firmly in place before each ride.

6.7.2 Removing the battery

- 1 Open battery lock with battery key (1).
- ⇒ The battery is released and falls into the retainer guard (2).
- 2 Hold the battery in your hand from below. Use the other hand to push on the retainer guard from above (3).
- ⇒ The battery is released and falls into the hand (4).
- 3 Remove the battery from the frame.
 - 4 Remove the battery key from the battery lock.

6.7.3 Charging the battery

The battery can remain on the pedelec or can be removed for charging. Interrupting the charging process does not damage the battery. The battery is fitted with a temperature monitoring system which only allows charging within a temperature range between 0 °C and 40 °C.

- ✓ The ambient temperature during the charging process lies within the range between 0 °C to 40 °C.
- 1 Remove the cable connection cover if necessary.
 - 2 Connect the mains plug of the charger to a normal domestic, grounded socket.

Connection data	
	230 V, 50 Hz

Notice

- ▶ Check that mains voltage! The power source voltage must match the voltage indicated on the charger nameplate. Chargers labelled 230 V may be operated at 220 V.
- 3** Connect the charging cable to the battery's charging port.
- ⇒ The charging process starts automatically.
- ⇒ The battery level indicator shows the charge level during charging. When the drive system is switched on, the *on-board computer* displays the charging process.

Notice

If an error occurs during the charging process, a system message is displayed.

- ▶ Remove the charger and battery from operation immediately and follow the instructions.
- ⇒ The charging process is complete when the LEDs on the battery level indicator go out.
- 4** Once charging is complete, disconnect the battery from the charger.
- 5** Disconnect the charger from the mains.

6.8 Straightening the quickly adjustable stem

Only applies to pedelecs with this equipment

- 1 Open stem clamping lever.
- 2 Use your finger to lift the unlocking bolt.



Figure 172: Pressing the unlocking bolt upwards

- 3 Pull handlebars into the highest possible position.




Figure 173: Turn handlebars.

- 4 Turn handlebars by 90° so that they are straight.
- 5 Place handlebars at required height.




Figure 174: Adjusting the height

- 6 Close stem clamping lever.

6.9 Lowering the pedals

CAUTION

Crushing fingers in the pedal folding latch

The pedal folding latch uses a high clamping force. There is a risk of crushing fingers in the flap.

- ▶ Never allow the pedal folding mount to snap shut uncontrollably.
- ▶ Be careful where you position your fingers when opening and closing.

- 1 Use two fingers to pull the pedal folding latch (1) downwards and hold in position.

⇒ The folding system is unlocked.




Figure 175: Pulling the pedal folding latch (1) downwards

- 2 Fold the pedal down.
- 3 Release your grip to carefully allow the pedal folding latch to return to its original position.

⇒ The pedal is extended.

6.10 Using the pannier rack

CAUTION

Crash caused by loaded pannier rack

The pedelec is handled differently with a loaded *pannier rack*, in particular when the rider needs to steer and brake. This can lead to a loss of control. This may cause a crash with injuries.

- ▶ You should practice how to use a loaded *pannier rack* safely before using the pedelec in public spaces.

Crushing fingers in the spring flap

The spring flap on the *pannier rack* uses a high clamping force. There is a risk of crushing fingers in the flap.

- ▶ Never allow the spring flap to snap shut in an uncontrolled manner.
- ▶ Be careful where you position your fingers when closing the spring flap.

Crash caused by unsecured baggage

Loose or unsecured objects on the *pannier rack*, e.g. belts, may become caught in the rear wheel. This may cause a crash with injuries.

Objects which are fastened to the pannier rack may cover the *reflectors* and the *riding light*. Other users may not see the pedelec on public roads as a result. This may cause a crash with injuries.

- ▶ Secure any objects which are attached to the *pannier rack* firmly.
- ▶ Objects fastened to the *pannier rack* must never cover the *reflectors*, the *headlight* or the *rear light*.
- ▶ Distribute the baggage as evenly as possible between the left- and right-hand side.
- ▶ We recommend using panniers and baggage baskets.



Figure 176: The maximum load bearing (1) capacity is indicated on the pannier rack

- ▶ Pack the pedelec to its *maximum permitted total weight* (PTW) only.
- ▶ Pack the pedelec to the pannier rack's (1) maximum load capacity only.
- ▶ Use the original pannier rack only.

6.11 Raising the kickstand

- ▶ Use your foot to raise kickstand completely before setting off.

6.12 Using the saddle

- ▶ Do not wear studded jeans as these can damage the saddle covering.
- ▶ Wear dark clothes for your first few rides as new leather saddles can stain clothing.

Riders often experience pain in the sitting bones, especially beginners or at the start of the season, after a longer break. The periosteum around the sitting bones is irritated as it is unaccustomed to the chafing. To reduce chafing:

- ▶ Wear cycling shorts with shock-absorbing seat padding.
 - ▶ Use a chamois cream or ointment.
- ⇒ The sensation of pain is reduced after five to six rides, although it may increase again after two to three weeks of riding.

6.12.1 Using the leather saddle

Sunlight and UV -light tarnish the colour and cause the leather to dry out and fade.

- ▶ Park pedelec in the shade.
- ▶ Always use a saddle cover.

Moisture may cause the leather to detach from material beneath and mould may form.

- ▶ If the leather saddle gets wet, dry saddle completely.
- ▶ Always use a saddle cover.

6.13 Using the pedals

- ▶ The ball of the foot is placed on the pedal when riding and pedalling.




Figure 177: Correct (1) and incorrect (2) foot position on the pedal

6.14 Using the bell

- 1 Press the bell button downwards.
- 2 Let button spring back.

6.15 Using the handlebars

- ▶ Wear heavily padded cycling gloves.
- ⇒ This helps protect sensitive areas of your palms.
- ▶ Vary your grip position continuously while riding.
- ⇒ This prevents overstraining and fatigue in your hands.

6.15.1 Using multi-position handlebars

Only applies to pedelecs with this equipment

Multi-position handlebars are ideal for dynamic riding. The contoured ends of the handlebars, also known as horn handlebars, provide a variety of grip options. Changing muscle groups reduces strain on the hands, arms and back during longer rides.

- ▶ Vary your grip position continuously while riding.
- ⇒ This prevents overstraining and fatigue in your hands.




Figure 178: Grip positions on the multi-position handlebars

Grip position 1

The top grip position is suitable for riding slowly.

- ▶ Straighten your upper body without tensioning in this position.

Grip position 2 and 3

The middle and bottom grip position is suitable for fast rides and riding on inclines.

- ▶ In the middle position, hold the arm and wrist upright and relax tension.
- ▶ In the bottom position, place your upper body slightly lower. Keep your fingers close to the brake handle ready for use.

6.15.2 Using bar ends

Only applies to pedelecs with this equipment

Bar ends can be added to normal handlebars.

Adjustable bar ends feature a ball joint, which you can use to choose the optimum position as required.

- ▶ Adjust bar ends correctly. To do so, your hand, elbow and shoulder must be in line with one another when the hand takes hold of the bar ends.
 - ▶ During the ride, keep varying your grip position between a flat (1) and upright (2) hand position.
- ⇒ This prevents overstraining, fatigue and numbness in your hands and fingers.



Figure 179: Grip positions on a bar end

6.15.3 Using leather handles

Only applies to pedelecs with this equipment

Sweat and grease from the skin are two of the greatest enemies of leather. They penetrate the surface of leather and cause it to disintegrate more quickly, meaning the leather can soften and abrade.

- ▶ Wear gloves.

Sunlight and UV -light damage the colour and can cause the leather to dry out and fade.

- ▶ Park pedelec in the shade.

Moisture may cause the leather to detach from material beneath and mould may form.

- ▶ If the leather handles get wet, dry handles completely.

6.16 Use BOSCH electric drive system with LED Remote

6.16.1 Switching on the electric drive system

⚠ CAUTION Crash caused by failure to prepare to brake.

When it is switched on, the drive system can be activated by applying force to the pedals. There is a risk of a crash if the drive is activated unintentionally and the brake is not reached.

Never start the electric drive system, or switch it off immediately, if the brake cannot be reached safely and reliably.

- ✓ A sufficiently charged battery has been inserted into the pedelec.
- ✓ The battery is firmly positioned and locked. The battery key has been removed.
- ✓ The speed sensor is connected correctly.

There are two options for switching on the drive system.

On-off button (on-board computer)

- ▶ Press the **on-off button (on-board computer)** briefly (<3 seconds).




Figure 180: Position of the on-off button on the BOSCH LED Remote

On-off button (battery)

- ▶ Press the **on-off button (battery)** briefly.
- ⇒ All LEDs on the on-board computer will light up briefly.
- ⇒ The battery level is displayed in colour by the battery level indicator (on-board computer) and the configured level of assistance by the indicator for the selected level of assistance. The pedelec is ready to ride.
- ⇒ If the battery capacity is less than 5%, the battery level indicator will remain dark. Only the on-board computer indicates whether the drive system is switched on or not.

If the drive system is switched on, the drive is activated as soon as the pedals are moved with sufficient force (except if the selected level of assistance is "OFF"). The motor power is based on the level of assistance selected on the on-board computer.

6.16.2 Switching off the electric drive system

As soon as the rider stops pushing the pedals in normal mode or reaches a speed of 25 km/h, the drive system switches off the assistance system. The assistance system starts up again when you push the pedals and your speed is less than 25 km/h.

The system switches off automatically ten minutes after the last command.

There are two options for switching off the drive system manually.

On-off button (on-board computer)

- ▶ Press the **on-off button (on-board computer)** briefly (<3 seconds).

On-off button (battery)

- ▶ Press the **on-off button (battery)**.
- ⇒ The battery level indicator (on-board computer) and the indicator for the selected level of assistance go out.
- ⇒ The pedelec is switched off.

6.17 Using the on-board computer

Notice

- ▶ Never use on-board computer, the display or the display mount as a handle. If the on-board computer, display or display mount are used to lift the pedelec, components can become irreparably damaged.




Figure 181: Overview of BOSCH LED Remote on-board computer

	Symbol	Designation
1		Selected level of assistance indicator
2		ABS indicator (optional)
3		Battery level indicator (control panel)
4	◆	Select button
5	⏻	On-off button (control panel)
6		Ambient light sensor

Table 34: Overview of control panel

	Symbol	Designation
7	>	Increase brightness button/ forward button
8	<	Decrease brightness button/ back button
9	+	Plus button/ light button
10	-	Minus button/ push assist button
11		Diagnosis connection (for maintenance purposes only)
12		Mount

Table 34: Overview of control panel

6.17.1 Using the diagnosis port

Notice

A USB connection is not a waterproof plug connection. Any moisture seeping through the USB port may cause a short circuit in the control panel.

- ▶ Never connect an external device.
- ▶ Regularly check the position of the rubber cover on the USB port and adjust it as necessary.

The diagnosis connection is only designed for maintenance purposes and is not suitable for connecting external devices.

- ▶ Keep the diagnosis port flap closed at all times to ensure no dust or moisture can penetrate through the port.

6.17.2 Charging the control panel battery

If both the charge level in the battery and the control panel's internal battery are low, the battery can be charged via the diagnosis port.

- ▶ Connect the internal battery to a power bank or another suitable power source with a USB type C® cable. (charge voltage: 5 V; charging current: max. 600 mA).

6.17.3 Using the riding light

- ✓ The drive system needs to be already switched on to turn on the *riding light*.



Figure 182: Position of riding light button (1)

- ▶ Press the **light button** for more than 1 second.
- ⇒ The front light and rear light are both switched on (*riding light symbol* is displayed) and switched off (*Riding light symbol* is switched off) at the same time.

6.17.4 Using the main beam

Only applies to pedelecs with this equipment

- ✓ Never use the main beam within city limits or on roads with consistently adequate lighting.
- ✓ Only use the main beam when it will not dazzle other road users.
- ✓ The riding light is on and the LED in the main beam switch is green.
- ▶ Press the **main beam switch** on the handlebars.
- ⇒ The main beam is activated.
- ⇒ The LED in the main beam switch lights up blue.
- ▶ Press the **main beam switch** on the handlebars.
- ⇒ The riding light is switched on.
- ⇒ The LED in the main beam switch lights up green.

6.17.5 Using the headlamp flasher

- ✓ Another road user is putting themselves or others at risk.
- ▶ Press the **main beam switch** twice quickly.
- ⇒ The other road user has been alerted that they are putting themselves or others at risk.

6.17.6 Setting the brightness of indicators

The ambient light sensor regulates the indicator brightness.

- ✓ The ambient light sensor must be clean and must not be covered.



Figure 183: Position of increase brightness button (2) and decrease brightness button (1)

- ▶ Press the **increase brightness button** and **decrease brightness button** to set the brightness of the indicator LEDs.

6.17.7 Using the push assist system



Injury from pedals or wheels

The pedals and the drive wheel turn when the push assist system is used. There is a risk of injury if the pedelec wheels are not in contact with the ground when the push assist system is used (e.g. when carrying the pedelec up stairs or when placing it on a bicycle rack).

- ▶ Only use the push assist mode when pushing the pedelec.
- ▶ You must steer the pedelec securely with both hands when using push assist.
- ▶ Allow for enough freedom of movement for the pedals.

The push assist system helps move the pedelec. The push assist system speed depends on the selected gear. The lower the selected gear is, the lower the speed in the push assist function is (at full power). The maximum speed is 6 km/h.

- ✓ We recommend using first gear for cycling uphill to protect the drive.



Figure 184: Position of push assist button (1)

- 1 Press **push assist button** for longer than 1 seconds. Hold down the button.
 - ⇒ The battery level indicator goes out and a white running light in the direction of travel indicates push assist is ready.
- 2 One of the following actions must be taken within the next 10 seconds:
 - ▶ Push pedelec forwards.
 - ▶ Push pedelec backwards.
 - ▶ Make a weaving movement with the pedelec.
 - ⇒ The push assist is activated. The continuous white bars change colour to ice blue.
 - ⇒ The motor starts to push.
- 3 Release the **push assist button** on the control panel to switch off motor assistance.
- 4 Push the **push assist button** within 10 seconds to reactivate motor assistance.
- 5 If motor assistance deactivates within 10 seconds, the push assist function switches off automatically.

Push assist will also switch off automatically if

- the rear wheel blocks
- speed bumps cannot be ridden over
- a part of the body is blocking the bicycle crank
- an obstacle turns the crank further
- the rider pedals
- the **plus button** or **on-off button** is pressed.

The push assist mode of operation is subject to country-specific regulations and may therefore differ from the above description or may be deactivated.

6.17.8 Selecting the level of assistance

The control panel is used to set how much the electric drive should assist the rider when pedalling. You can change the level of assistance at any time while you are cycling.



Figure 185: Position of plus and minus buttons

- ▶ Press the **plus button** (2) on the control panel to increase the level of assistance.
- ▶ Press the **minus button** (1) on the control panel to reduce the level of assistance.
- ⇒ The motor power used is displayed in colour in the level of assistance indicator.

If the system is switched off, the level of assistance last displayed is saved.

6.18 Using the brake

⚠ WARNING Crash caused by brake failure

Oil or lubricant on the brake disc in a disc brake or on the rim of a rim brake can cause the brake to fail completely. This may cause a crash with serious injuries.

- ▶ Never allow oil or lubricant to come into contact with the brake disc or brake linings or on the rim of a rim brake.
- ▶ If the brake linings have come into contact with oil or lubricant, contact specialist dealer to have the components cleaned or replaced.

If the brakes are applied continuously for a long time (e.g. while riding downhill for a long time), the fluid in the brake system may heat up. This may create a vapour bubble. This will cause air bubbles or water contained in the brake system to expand. This may suddenly make the lever travel wider. This may cause a crash with serious injuries.

- ▶ Release the brake regularly when riding downhill for a longer period of time.
- ▶ Use the front and rear wheel brakes alternately.

6.18.1 Using the handbrake

Only applies to pedelecs with this equipment




Figure 186: Handbrake, front (2) and rear (1) – SHIMANO brake used as an example

- ▶ In order to achieve optimum braking results, do not pedal while braking.
- ▶ Pull the left *handbrake* to apply the *front wheel brake*.
- ▶ Pull the right *handbrake* to apply the *rear wheel brake*.

6.18.2 Using the back-pedal brake

Only applies to pedelecs with this equipment

- 1 Move pedals a little beyond the 3-o'clock and 9-o'clock position.
- 2 Pedal in the opposite direction to the *direction of travel* until the desired speed has been reached.

6.19 Brakes

⚠ WARNING Crash caused by brake failure

Oil or lubricant on the brake disc in a disc brake or on the rim of a rim brake can cause the brake to fail completely. This may cause a crash with serious injuries.

- ▶ Never allow oil or lubricant to come into contact with the brake disc or brake linings or on the rim of a rim brake.
- ▶ If the brake linings have come into contact with oil or lubricant, contact specialist dealer to have the components cleaned or replaced.

If the brakes are applied continuously for a long time (e.g. while riding downhill for a long time), the fluid in the brake system may heat up. This may create a vapour bubble. This will cause air bubbles or water contained in the brake system to expand. This may suddenly make the lever travel wider. This may cause a crash with serious injuries.

- ▶ Release the brake regularly when riding downhill for a longer period of time. Use the front and rear wheel brakes alternately.

The motor's drive force is switched off during the ride as soon as the pedelec rider is no longer pedalling. The electric drive system does not switch off when braking.

- ▶ In order to achieve optimum braking results, do not pedal while braking.

6.19.1 Using the handbrake




Figure 187: Handbrake, front (2) and rear (1) – SHIMANO brake used as an example

- ▶ Pull the left *handbrake* to apply the front wheel brake.
- ▶ Pull the right *handbrake* to apply the rear wheel brake.

6.19.2 Using the back-pedal brake

Only applies to pedelecs with this equipment

- 1 Move pedals a little beyond the 3-o'clock and 9-o'clock position.
- 2 Pedal in the opposite direction to the *direction of travel* until the desired speed has been reached.

6.20 Switching gears

⚠ CAUTION Risk of a crash due to a level of assistance which is too high on starting up

If a level of assistance which is too high is used when starting up the pedelec with a powerful motor or when setting off on a hill, the pedelec may lurch violently. The front wheel can lift off the ground or the rear wheel may veer. This may cause a crash with injuries.

- ▶ Never start up pedelec with a high level of assistance.
- ▶ Always select the lowest gear when setting off to ensure the front wheel does not lift off the ground.
- ▶ When setting off on a hill, start with as little force as possible.
- ▶ Practice starting up before your first ride on public roads.

The selection of the appropriate gear is a prerequisite for a physically comfortable ride and making sure that the electric drive system functions properly. The ideal pedalling frequency is between 70 and 80 revolutions per minute.

- ▶ Stop pedalling briefly when changing gears. This makes it easier to switch gears and reduces wear on the drivetrain.

6.20.1 Using the derailleur gears

The speed and range can be increased while applying the same force if you select the right gear.

- ✓ Stop pedalling briefly when changing gears. This makes it easier to switch gears and reduces wear on the drivetrain. However, keep the crank moving while switching gears.




Figure 188: Switching gears with lever A, using gear shift SL-M315 as an example

Lever A switches up from the smallest sprocket to the largest sprocket.

- ▶ Place shifter A in position 1.
- ⇒ System shifts one sprocket higher.
- ▶ Place shifter A in position 2.
- ⇒ System shifts two sprockets higher.




Figure 189: Switching gears with lever B, using gear shift SL-M315 as an example

Lever B switches down from the largest sprocket to the smallest sprocket. There are two ways to switch down a gear:

- ▶ Place shifter B in position 1.
- ⇒ System shifts one sprocket lower.
- ▶ Place shifter B in position 2.
- ⇒ System shifts one sprocket lower.

Switching gears

- ▶ Select the appropriate gear with the *gear shift unit*.
- ⇒ The gear shift switches gear.
- ⇒ The shifter returns to its original position.
- ▶ Clean and lubricate the rear derailleur if gear changes block.

6.20.2 Using pinion gears

6.20.2.1 Activating the SMART.SELECT automatic gear setting

- ✓ The pedelec is stationary.
- ▶ Activate START.SELECT by selecting the <Shift> menu in the settings on the on-board computer.
- ⇒ The system shifts into the selected starting gear automatically when the pedelec comes to a halt.

6.20.2.2 Activating the SMART.SELECT automatic gear setting

- ✓ The pedelec is stationary.
- ▶ Activate PRE.SELECT by selecting the <Shift> menu in the settings on the on-board computer.
- ⇒ The system automatically shifts into the perfect gear for the speed at the preferred pedalling frequency when the user rides without pedalling.

6.20.2.3 Shifting gear manually with E-Trigger TE1

Pinion gears switch between 9 or 12 speeds. It is possible to switch between several gears in one shift action (e.g. from 06 to 02). Changing gear is possible while stationary or with the crank stationary or turning backward and is gentle on the gears.

It is possible to shift down gears (12-11-10 ... -01) without any restrictions when under load. The gear change will not be completed if there is too much pressure on the crank or on the pedal.

A mechanism in the gears allows the ride to shift up gears (01-02-03 ... -12) under load. This is possible for all gear shifts, except a change of gear between the different half-gears. The rider needs to take pressure off the pedals briefly in this case.

- ▶ Always reduce pressure on the pedals when shifting down gears (12-11-10 ... -01).

Applies to P1.12 motor

- ▶ Always reduce pressure on the pedals when shifting up a gear from 04 to 05 or from 08 to 09.

Applies to P1.9 motor

Always reduce pressure on the pedals when shifting up a gear from 03 to 04 or from 06 to 07.

- ▶ Push the front shifter (1) backwards to shift up.
 - ▶ Push the rear shifter (2) backwards to shift down.
- ⇒ The gear shift switches gear.
- ⇒ The crank occasionally drops about 10° after a gear change. This causes the bike to jerk until the pawl is securely engaged in the next tooth. This phenomenon cannot always be eliminated but will not cause damage to the gears.

6.20.3 Using a SHIMANO hub gear**Only applies to pedelecs with this equipment****⚠ CAUTION Crash caused by incorrect use**

If the rider applies too much pressure on the pedals during a gear change and activates the shifter or changes several gears at a time, their feet may slip from the pedals. This may cause a crash or flip-over with injuries.

Switching down several gears to a low gear may cause the twist grip shifter outer sleeve to come off suddenly. This will not prevent the twist grip shifter from functioning correctly since the outer guide returns to its original position after the gear change is complete.

- ▶ Apply little pressure on the pedals while changing gears.
- ▶ Never change more than one gear at a time.

Notice The interior hub is not completely waterproof. If water gets into the hub, it may rust and the gear switch function may no longer function as a result.

- ▶ Never use the pedelec in places where water may get into the hub.

Notice In rare cases, noises may be heard from the rear derailleur in the hub interior after a gear change. This is normal when gears are changed.

Notice Never detach the hub yourself. Contact specialist dealer.




Figure 190: SHIMANO SL-C30000-70 gear shift

- ▶ Turn the twist grip shifter (1) backwards to switch up a gear (4).
 - ▶ Turn the twist grip shifter (1) forwards to switch down a gear (2).
- ⇒ The gear shift switches gear.
- ⇒ The screen display (3) shows the changed gear.

6.20.4 Using a SHIMANO hub gear

Only applies to pedelecs with this equipment

CAUTION Crash caused by incorrect use

If the rider applies too much pressure on the pedals during a gear change and activates the shifter or changes several gears at a time, their feet may slip from the pedals. This may cause a crash or flip-over with injuries.

Switching down several gears to a low gear may cause the twist grip shifter outer sleeve to come off suddenly. This will not prevent the twist grip shifter from functioning correctly since the outer guide returns to its original position after the gear change is complete.

- ▶ Apply little pressure on the pedals while changing gears.
- ▶ Never change more than one gear at a time.

Notice The interior hub is not completely waterproof. If water gets into the hub, it may rust and the gear switch function may no longer function as a result.

- ▶ Never use the pedelec in places where water may get into the hub.

Notice In rare cases, noises may be heard from the rear derailleur in the hub interior after a gear change. This is normal when gears are changed.

Notice Never detach the hub yourself. Contact specialist dealer.

- ▶ Turn the twist grip shifter (1) backwards to switch up a gear (4).
- ▶ Turn the twist grip shifter (1) forwards to switch down a gear (2).
- ⇒ The gear shift switches gear.
- ⇒ The screen display (3) shows the changed gear.




Figure 191: SHIMANO SL-C30000-70 gear shift

6.20.5 Using a ROHLOFF gear shift

Only applies to pedelecs with this equipment

WARNING

Risk of falling if gear shift subject to high pedal load

Shifting gears when applying great force to the pedals produces a strong, shock-like impact load on the coupling elements in the gear mechanism. This can cause the crank to rotate unrestrictedly temporarily due to the coupling elements snapping back. The rider can lose their balance and fall as a result.

- ▶ Shift down in good time, e.g. before ascents, and thus avoid shifting gears when pressing hard on the pedals (e.g. going uphill).

The grip shifter can be easily turned from detent to detent when the bike is stationary or low force is applied to the pedals. The manual force required to turn the shift lever increases as the pedal force intensifies.

- ▶ If you wish to change gear quickly in any crank position, relieve the pressure on the pedal at the exact moment you turn the shifter without interrupting the pedalling motion.
- ⇒ The amount of force applied determines how smooth the shifting process is.

The pedalling force is reduced when the crank passes through its dead centres. Shifting gears when passing through a crank dead centre therefore always ensures a low force is required for shifting.

You turn the twist grip to shift gears with the ROHLOFF gear hub.




Figure 192: ROHLOFF twist grip with shifter (1) and indicator (2)

- ▶ Turn towards number 14 to switch up to higher gear speeds.
- ▶ Turn towards number 1 to switch down to slower gear speeds.
- ⇒ Immediately after you turn to another gear speed, the ROHLOFF gear hub switches a gear higher or lower.
- ▶ When changing gears between 7 and 8 or 8 and 7, avoid shifting very slowly or while applying great force to the pedals; otherwise, you may shift to gear 11 or 14 briefly as an intermediate gear.

6.21 Adjusting the suspension fork

- Adjusting the suspension and damping on the suspension fork or on the remote control (suspension fork) while riding:

Use	Position
Suspension	
Downhill rides and uneven terrain	Open or OPEN
Flat, hilly, even or slightly bumpy terrain or uneven roads	Threshold or medium position
Uphill or tarmacked roads	Lock out or LOCK
Damping	
Bumpy terrain	Soft
Uniformly hilly terrain and around bends	Hard

6.21.1 Adjusting the suspension fork suspension

Lockout

Some suspension forks thus feature a lockout on the fork crown or a *remote lockout* activated on the handlebars.

A suspension system is designed to cushion and compensate for unevenness on a surface whether the user is riding on bumpy cycle paths, dirt roads or off road. A suspension system absorbs great deal of motor and muscle power during rides uphill or on optimally tarmacked roads. This increases energy consumption and reduces propulsion. It thus makes sense to lock the suspension on tarmacked roads and when riding uphill.

The lockout setting prevents the suspension fork from deflecting until there is a strong impact force. The suspension fork deflects when a very strong impact or downward movement occurs.

Threshold (optional)

Just like the lockout, the threshold mode prevents the suspension fork from deflecting. The suspension fork deflects when a medium or strong impact or downward force occurs.

6.21.1.1 Lock out SR SUNTOUR suspension fork

Only applies to pedelecs with this equipment





LORC-PCS LORC	LOR	LO	HLO	NLO
				

Table 35: Lockout on the fork crown on SR Suntour suspension forks

▶ Turn **lockout** (1) on the fork crown clockwise to LOCK.

⇒ The suspension fork is blocked.

▶ Turn **lockout** (1) on the fork crown anticlockwise to OPEN.

⇒ The suspension fork is open.

RL22-DUAL-L-2C-22	RL22-SINGLE-L-2C-22	RL22-SINGLE-U-2C-22 RL22-SINGLE-U-2C-32	SL9SC-RLO
			

Table 36: SR Suntour suspension fork lockout on the handlebars

▶ Press **locking lever** (1) on the handlebars.

⇒ The suspension fork is blocked.

▶ Press **release lever** (2) on the handlebars.

⇒ The suspension fork is open.

6.22 Parking

Notice Heat or direct sunlight can cause the *tyre pressure* to increase above the permitted maximum pressure level. This can destroy the *tyres*.

- ▶ Never park the pedelec in the sun.
- ▶ On hot days, check the *tyre pressure* regularly and adjust it as necessary.

Notice Moisture penetrating at cold temperatures may impair individual functions due to the open structural design.

- ▶ Always keep the pedelec dry and free from frost.
- ▶ If the pedelec is used at temperatures below 3 °C, the specialist dealer must perform maintenance beforehand and prepare it for winter use.

Notice The pedelec's force of weight may cause the kickstand to sink into soft ground, possibly causing the pedelec to topple over as a result.

- ▶ The pedelec must be parked on firm, level ground only.
- 1 Switch off the drive system.
 - 2 After getting off, use your foot to lower the kickstand completely before parking. Ensure that it is stable.
 - 3 Park the pedelec carefully and check that it is stable.
 - 4 Protect saddle with saddle cover if you park the pedelec outside.
 - 5 Lock the pedelec with the bicycle lock.
 - 6 Remove battery to protect it against theft.
 - 7 Clean and service pedelec after every ride; see Section 7.7.

Checklist after each ride

Cleaning		
<input type="checkbox"/>	Lights and reflectors	See Section 7.7.5
<input type="checkbox"/>	Brake	See Section 7.7.5
<input type="checkbox"/>	Suspension fork	See Section 7.7.1
<input type="checkbox"/>	Suspension seat post	See Section 7.7.6
<input type="checkbox"/>	Rear frame damper	See Section 7.7.7
<input type="checkbox"/>	Pedal	See Section 7.7.4
Servicing		
<input type="checkbox"/>	Suspension fork	See Section 3

6.22.1 Screwing in the quickly adjustable stem

Only applies to pedelecs with this equipment

Screw in the quickly adjustable stem to save space when parking.

- 1 Open stem clamping lever.
- 2 Press handlebars down as far as they will go.




Figure 193: Adjusting the height

- 3 Use your finger to lift the unlocking bolt.



Figure 194: Pressing the unlocking bolt upwards




Figure 195: Turn handlebars.

- 4 Turn handlebars by 90° so that they are straight.

- 5 Close stem clamping lever.

6.23 Folding up the pedal

CAUTION Crushing fingers in the pedal folding latch

The pedal folding latch uses a high clamping force. There is a risk of crushing fingers in the flap.

- ▶ Never allow the pedal folding mount to snap shut uncontrollably.
- ▶ Be careful where you position your fingers when opening and closing.

May lead to minor or moderate injuries if ignored.
Low-risk hazard.

- ✓ Clean the pedal (see Section 7.7.4).

- 1 Use two fingers to pull the pedal folding latch (1) downwards and hold in position.

⇒ The folding system is unlocked.




Figure 196: Pulling the pedal folding latch (1) downwards

- 2 Fold the pedal upwards.

- 3 Release your grip to carefully allow the pedal folding latch to return to its original position.

⇒ The pedal is folded away.

6.23.1 Activating the lock function

Only applies to pedelecs with this equipment

- ▶ Remove the on-board computer used during set-up.
- ⇒ The lock function is activated. The drive system now provides no assistance. However, the rider can continue to use the pedelec without assistance.
- ⇒ The drive unit will emit a lock sound (an audible signal) as long as the drive system is switched on.
- ⇒ The lock function status is displayed with a lock icon on the on-board computer for around 3 seconds.

6.23.1.1 Activating for System Controller and Purion 200

- ⇒ The eBike Lock function is activated automatically in the System Controller by switching the electric drive system off.
- ⇒ The drive unit will emit a lock sound (an audible signal) as long as the drive system is switched on.
- ⇒ The System Controller control panel flashes white and (optionally) displays a lock symbol on the screen whenever the eBike Lock function is active after switching on.

7 Cleaning, servicing and inspection

⚠ WARNING Crash caused by brake failure

Oil or lubricant on the brake disc in a disc brake or on the rim of a rim brake can cause the brake to fail completely. This may cause a crash with serious injuries.

- ▶ Never allow oil or lubricant to come into contact with the brake disc or brake linings or on the rim of a rim brake.
- ▶ If the brake linings have come into contact with oil or lubricant, contact specialist dealer to have the components cleaned or replaced.

After cleaning, servicing or repair, carry out a few test brake applications.

⚠ WARNING The brake system is not designed for use on a bicycle which is placed on its side or turned upside down. The brake may not function correctly as a result. This can cause a crash, which may result in injuries.

- ▶ If bicycle has been placed on its side or turned upside down, apply the brakes a couple of times before setting off to ensure they work as normal.

⚠ WARNING The brake seals are unable to withstand high pressures. Damaged brakes can fail and cause an accident with injury.

- ▶ Never clean the bicycle with a pressure washer or compressed air.
- ▶ Take great care when using a hosepipe. Never point the water jet directly at the seal section.

Notice Water may enter the inside of the bearings if you use a steam jet. This dilutes the lubricant inside, the friction increases and, as a result, the bearings are permanently damaged in the long term. Water may also penetrate the electric components and damage them permanently.

- ▶ Never clean bicycle with a pressure washer, water jet or compressed air.

Notice Greased parts, such as the seat post, the handlebars or the stem, may no longer be safely and reliably clamped.

- ▶ Never apply grease or oil to parts which are clamped.

Notice Harsh cleaning agents such as acetone, methylene and trichloroethylene and solvents such as thinners, alcohol and corrosion protection can attack bicycle components and damage them permanently.

- ▶ Use approved care and cleaning products only.

Complying with these cleaning instructions is the only way to reduce wear on components, increase the operating hours and guarantee safety.

7.1 Before each ride

7.1.1 Checking the safety guards

The chain or belt guards, mudguards or the motor cover may break and fall off when the bicycle is transported or parked outside.

- ▶ Check that all guards are in place.
- ▶ Take bicycle out of service if a guard is damaged or missing. Contact specialist dealer.

7.1.2 Checking the frame

- ▶ Check frame for cracks, warping and damage to the paintwork.
- ▶ If there are any cracks, warping or damage to the paintwork, remove the bicycle from service. Contact specialist dealer.

7.1.3 Checking the fork

- ▶ Check fork for cracks, warping, tarnished components, leaked oil and damage to the paintwork. Also look at concealed sections on the vehicle's lower surfaces.
- ⇒ If there are any cracks, warping, tarnished components, leaked oil or damage to the paintwork, remove the bicycle from service. Contact specialist dealer.

7.1.4 Checking the rear frame damper

- ▶ Check rear frame damper for cracks, warping, tarnished components, leaked oil and damage to the paintwork. Also look at concealed sections on the vehicle's lower surfaces.
- ⇒ If there are any cracks, warping, tarnished components, leaked oil or damage to the paintwork, remove the bicycle from service. Contact specialist dealer.

7.1.5 Checking the pannier rack

- 1 Hold onto bicycle by its frame. Hold onto pannier rack with the other hand.
 - 2 Move the pannier rack backwards and forwards to check that all screw connections are firmly in place.
- ⇒ Tighten loose screws.
 - ⇒ Attach loose baskets permanently with a basket bracket or cable ties.

7.1.6 Checking the guards

- 1 Hold onto bicycle by its frame. Hold onto mudguard with the other hand.
 - 2 Move the mudguard backwards and forwards to check that all screw connections are firmly in place.
- ⇒ Tighten loose screws.

7.1.7 Check wheel concentricity

- ▶ Lift the front and rear wheels one after the other and spin each wheel when lifted.
- ⇒ If the wheel is loose or crooked when it turns, take bicycle out of service. Contact specialist dealer.

7.1.8 Checking the quick releases

- ▶ Check quick releases to ensure that all quick releases are firmly in their fully closed end position.
- ⇒ If a quick release is not firmly in its closed end position, open quick release and place in its end position.
- ⇒ If the quick release cannot be firmly placed in its end position, take bicycle out of service. Contact specialist dealer.

7.1.9 Checking the suspension seat post

- ▶ Deflect the suspension seat post and let it rebound.
- ⇒ If you hear unusual noises when the suspension seat post deflects and rebounds, or it yields without any resistance, take bicycle out of service. Contact specialist dealer.

7.1.10 Checking the bell

- 1 Press the bell button downwards.
 - 2 Let button spring back.
- ⇒ If you do not hear a clear, distinct ring of the bell, replace bell. Contact specialist dealer.

7.1.11 Checking the handles

- ▶ Check the handles are firmly in place.
- ⇒ Screw loose handles firmly into place.

7.1.12 Checking the riding light

- 1 Switch light on.
 - 2 Check that the headlight and rear light come on.
- ⇒ If the headlight and rear lights do not come on, take bicycle out of service. Contact specialist dealer.

7.1.13 Checking the brake

- 1 Pull both handbrakes when stationary.
 - 2 Push the pedals.
- ⇒ If no resistance is generated in the handbrake's usual position, take bicycle out of service. Contact specialist dealer.
- ⇒ If the brake is losing fluid, take bicycle out of service. Contact specialist dealer.

7.2 After every ride

The following tools and cleaning agents should be ready for use to clean the bicycle after each ride:

7.2.1 Cleaning the riding light and reflectors

- 1 Clean headlight, rear light and reflectors with a damp cloth.

7.2.2 Cleaning the brake

- ▶ Clean dirt on the rim and brake components with a slightly dampened cloth.

7.2.3 Cleaning the suspension fork

- 1 Remove dirt and deposits from the stanchions and deflector seals with a damp cloth. Check stanchions for dents, scratches, staining or leaking oil.
- 2 Lubricate the dust seals and stanchions with a few drops of silicone spray.
- 3 Service the suspension fork after cleaning.

7.2.4 Cleaning the suspension seat post

- ▶ Clean dirt on the articulated joints with a slightly dampened cloth immediately after a ride.

7.2.5 Servicing the suspension fork

- ▶ Apply fork oil to dust seals.

7.2.6 Cleaning the rear frame damper

- ▶ Clean dirt on the articulated joints with a slightly dampened cloth immediately after a ride.

7.2.7 Cleaning the pedals

- ▶ Clean pedals with a brush and soapy water.

7.3 Basic cleaning

The following are required for basic cleaning:

7.3.1 Remove and clean by hand

The basic components include the fork, the pannier rack, the guards and the kickstand.

- 1 Soak the components with dishwashing liquid if the dirt is thick and ingrained.
- 2 After leaving it to soak for a short time, remove the dirt and mud with a sponge, brush and toothbrushes.
- 3 Rinse off the components with water from a watering can.
- 4 Wipe away oil stains with a degreaser.

7.3.2 Cleaning the stem

- 1 Clean stem with a cloth and soapy water.
- 2 Rinse off component with water from a watering can.

7.3.3 Cleaning the handlebars

- 1 Clean handlebars, including handles and all gears or twist grip shifter, with a cloth and soapy water.
- 2 Rinse off component with water from a watering can.

7.3.4 Cleaning the handles

- 1 Clean handles with sponge, water and soapy water.
- 2 Rinse off component with water from a watering can. Care for rubber handles after cleaning (see Section 6.4.8.1).

7.3.4.1 Cleaning the leather handles

Leather is a natural product and has similar properties to human skin. Regular cleaning and care help to prevent leather dehydrating, fading or becoming brittle or stained.

- 1 Remove dirt with a soft, damp cloth. Remove stubborn stains with a leather cleaner.
- 2 Service leather handles after cleaning (see Section 6.4.8.2).

7.3.5 Cleaning the seat post

- 1 Clean seat post with a cloth and soapy water.
- 2 Rinse off component with water from a watering can.
- 3 Wipe away any grease or assembly paste residue with a cloth and degreaser.

7.3.6 Cleaning the saddle

- 1 Clean the saddle with lukewarm water and a cloth dampened with soapy water.
- 2 Rinse off component with water from a watering can.

7.3.6.1 Cleaning the leather saddle

Leather is a natural product and has similar properties to human skin. Regular cleaning and care help to prevent leather dehydrating, fading or becoming brittle or stained.

- 1 Remove dirt with a soft, damp cloth.
- 2 Remove stubborn stains with a leather cleaner.
- 3 Service leather saddle after cleaning (see Section 6.4.11).

7.3.7 Cleaning the tyres

- 1 Clean tyres with a sponge, a brush and soap cleaner.
- 2 Rinse off component with water from a watering can.
- 3 Remove any embedded chips and small stones.

7.3.8 Cleaning the spokes and spoke nipples

- 1 Clean spokes from the inside to the outside with a sponge, brush and soapy water.
- 2 Clean rim with a sponge.
- 3 Rinse off component with water from a watering can.
- 4 Care for spoke nipples after cleaning (see Section 6.4.13).

7.3.9 Cleaning the hub

- 1 Put on protective gloves.
- 2 Remove dirt from hub with a sponge and soapy water.
- 3 Rinse off component with water from a watering can.
- 4 Wipe off oily dirt with a degreaser and a cloth.

7.3.10 Cleaning the switching elements

- 1 Clean gear shift and shift cables with water, a brush and dishwashing liquid.
- 2 Rinse off component with water from a watering can.

7.3.11 Cleaning the SRAM AXS rear derailleur

Notice

The rear derailleur battery or the battery mount battery will be permanently damaged if water enters them.

- ▶ If fitted, remove the rear derailleur battery from the SRAM rear derailleur and insert the battery separator into the rear derailleur before cleaning.
- ▶ Never immerse the rear derailleur battery in water.
- ▶ Never use acidic or degreasing agents on the electrical components.
- ▶ Never use chemical cleaning agents or solvents as they can destroy the plastic components.
- ▶ Clean all derailleur components with a damp cloth.

7.3.11.1 Cleaning the shifter

- ▶ Carefully clean shifter with a damp, soft cloth.

7.3.12 Cleaning the cassette, chain wheels and front derailleur

- 1 Put on protective gloves.
- 2 Spray cassette, chain wheels and front derailleur with degreasing agent.
- 3 Clean coarse dirt with a brush after soaking for a short time.
- 4 Wash down all parts with dishwashing liquid and a toothbrush.
- 5 Rinse off component with water from a watering can.

7.3.13 Cleaning the brake

7.3.13.1 Cleaning the handbrake

- ▶ Carefully clean the handbrake with a damp, soft cloth.

7.3.14 Cleaning the brake disc

Notice

- ▶ Protect brake disc against lubricants and grease from hands.
- 1 Put on protective gloves.
 - 2 Spray brake disc with brake disc cleaning spray.
 - 3 Wipe with a cloth.

7.3.15 Cleaning the belt

Notice

- ▶ Never use aggressive (acid-based) cleaners, rust removers or degreasers when cleaning the belt.
- 1 Dampen a cloth with soapy water. Place the cloth on the belt.
 - 2 Hold and apply slight pressure while slowly turning the rear wheel so that the belt passes through the cloth.

7.3.16 Cleaning the chain

Notice

- ▶ Never use aggressive (acid-based) cleaners, rust removers or degreasers when cleaning the chain.

Notice

- ▶ Never use gun oil or rust remover spray.

Notice

- ▶ Never use chain cleaning devices or chain cleaning baths.

Notice

- ▶ Have chain with all-round guard cleaned and serviced during major inspection.
 - ✓ Place newspaper or paper towels underneath to collect dirt.
- 1 Slightly dampen a brush with dishwashing liquid. Brush both sides of the chain.
 - 2 Dampen a cloth with soapy water. Place the cloth on the chain.
 - 3 Hold and apply slight pressure while slowly turning the rear wheel, so the chain passes through the cloth.
 - 4 Wipe off oily, dirty chains thoroughly with a cloth and degreaser.
 - 5 Service the chain after cleaning (see Section 6.4.16).

7.3.16.1 Cleaning the chain and all-round chain guard

Notice

- ▶ The chain guard must be removed before cleaning. Contact specialist dealer.
- ▶ Clean water hole on the chain guard lower surface.
- ▶ Service the chain after cleaning (see Section 6.4.16.1).

7.4 Servicing

Complying with these servicing instructions is the only way to reduce wear on components, increase the operating hours and guarantee safety.

7.4.1 Servicing the frame

Notice

- ▶ Hard wax polish and protection wax are particularly resistant on gloss paintwork. These car accessory retail products are unsuitable for matt paint finishes.

Notice

- ▶ Try wax spray out on a small spot before applying.
- 1 Dry frame with a cloth. Spray frame with spray wax and leave to dry.
 - 2 Wipe away any wax residue with a cloth.

7.4.2 Servicing the fork

Notice

- ▶ Hard wax polish and protection wax are particularly resistant on gloss paintwork. These car accessory retail products are unsuitable for matt paint finishes.

Notice

- ▶ Try wax spray out on a small spot before applying.
- 1 Dry fork with a cloth.
 - 2 Spray frame care oil on frame and leave to dry.
 - 3 Wipe away any wax residue with a cloth.

7.4.3 Caring for the pannier rack

- 1 Dry pannier rack with a cloth.
- 2 Spray pannier rack with spray wax and leave to dry. Wipe pannier rack with a cloth.
- 3 Protect chafing points on panniers with adhesive film. Replace worn adhesive film.
- 4 Care for coil springs with silicone spray or wax spray from time to time.

7.4.4 Servicing the mudguard

- ▶ Depending on the requirements for the mudguard material, apply hard wax polish, metal polish or a plastic care product as per the product instructions.

7.4.5 Servicing the kickstand

- 1 Dry kickstand with a cloth.
- 2 Spray kickstand rack with spray wax and leave to dry.
- 3 Wipe down kickstand with a cloth.
- 4 Lubricate the kickstand joints with spray oil.

7.4.6 Servicing the stem

- 1 Spray painted and polished metal surfaces with wax spray and leave to dry.
- 2 Wipe away any wax residue with a cloth.
- 3 Apply silicone or Teflon oil to the stem shaft tube and the quick release lever pivot point with a cloth.
- 4 If you have a Speedlifter Twist, also apply oil to the unlocking bolt groove in the Speedlifter body.
- 5 Apply a little acid-free lubricant grease between the stem quick release lever and the sliding piece to reduce the quick release lever operating force.
- 6 If you have a stem with a cone clamp, apply a new protective layer of assembly paste onto the stem and fork steerer contact point once a year.

7.4.7 Caring for handlebars

- 1 Spray painted and polished metal surfaces with wax spray and leave to dry.
- 2 Wipe away any wax residue with a cloth.

7.4.8 Caring for the handles

7.4.8.1 Caring for rubber handles

Notice

- ▶ Never apply talcum powder to leather or foam handles.
- ▶ Apply talcum powder to sticky rubber handles.

7.4.8.2 Caring for leather handles

Standard leather care products keep leather smooth and resistant, brighten its appearance and improve or replace stain protection.

- 1 Try leather care product out on a less visible spot before use.
- 2 Care for leather handles with a leather care product.

7.4.9 Servicing the seat post

- 1 Carefully preserve screw connections with wax spray. In doing so, ensure that no wax is applied to the metal contact surfaces.
- 2 Replace the assembly paste protective layer on the metal contact surfaces on the seat post and seat tube every year.

7.4.9.1 Servicing the suspension seat post

- 1 Lubricate articulated joints with spray oil.
- 2 Deflect and let the suspension seat post rebound five times. Remove any surplus lubricant with a clean cloth.

7.4.9.2 Servicing the carbon seat post

Notice

Rain and puddle water can cause contact corrosion if carbon seat posts are used in an aluminium frame without protective assembly paste. It may then take a great deal of force to remove the seat post. The carbon seat post may break as a result.

- 1 Take out the carbon seat post.
- 2 Remove old assembly paste with a cloth.
- 3 Apply new assembly paste with a cloth.
- 4 Re-insert the carbon seat post.

7.4.10 Caring for the rims

- ▶ Care for chrome rims, stainless steel rims and polished aluminium with chrome or metal polish. Never apply polish to the brake surface.

7.4.11 Caring for the leather saddle

Standard leather care products keep leather smooth and resistant, brighten its appearance and improve or replace stain protection.

- 1 Try leather care product out on a less visible spot before use.
- 2 Service leather saddle from below with a leather care product. Only maintain the top of leather saddles with a leather care product if they are badly worn and dried-out.
- 3 Avoid wearing light-coloured trousers after care due to staining.

7.4.12 Servicing the hub

- 1 Apply wax spray, especially around the spoke holes. In doing so, ensure that no wax is applied to brake parts.
- 2 Treat rubber seals with a cloth with one or two drops of silicone spray. Never use oil if you have disc brakes.

7.4.13 Servicing the spoke nipples

- 1 Apply wax spray onto the spoke nipples from the rim side.
- 2 Treat heavily corroded spoke nipples with a drop of penetrating of special care oil.

7.4.14 Servicing the gear shift

7.4.14.1 Servicing the rear derailleur articulated shafts and jockey wheel

- ▶ Apply Teflon spray to front and rear derailleur articulated shafts and jockey wheels.

7.4.14.2 Servicing the shifter

Notice

- ▶ Never treat shifters with degreaser or penetrating oil spray.
- ▶ Lubricate articulated joints and mechanical parts which are accessible from outside with a few drops of spray oil or precision mechanics oil.

7.4.15 Servicing the pedals

- 1 Treat pedals with spray oil. In doing so, ensure that no lubricant is applied to the pedal surfaces.
- 2 Lubricate seals and mechanical parts sparingly with a few drops of oil.
- 3 Remove any surplus lubricant with a clean cloth.
- 4 Spray metal foot rests with silicone spray.

7.4.16 Servicing the chain

- ✓ Place newspaper or paper towels underneath to collect chain oil.
- 1 Lift rear wheel.
 - 2 Turn the crank briskly in an anti-clockwise direction.
 - 3 Use slight finger pressure to the chain oil bottle to apply a wafer-thin thread of oil to the chain links. The faster the crank is turned, the thinner the threads of oil will be.




Figure 197: Lubricating the chain

- 4 Remove excessive chain oil with a cloth. If you apply too much oil, it will make the chain all the dirtier at a later point in time.
- 5 Leave chain oil to penetrate into the chain links for a few hours or overnight.

7.4.16.1 Servicing the chain and all-round chain guard

- ✓ Place newspaper or paper towels underneath to collect chain oil.
- 1 Lift rear wheel.
 - 2 Turn the crank briskly in an anti-clockwise direction.
 - 3 Use slight finger pressure to the chain oil bottle to apply a wafer-thin thread of oil onto the chain links through the oil hole on the upper surface of the chain guard. The faster the crank is turned, the thinner the threads of oil will be.
 - 4 Remove excessive chain oil with a cloth. If you apply too much oil, it will make the chain all the dirtier at a later point in time.
 - 5 Leave chain oil to penetrate into the chain links for a few hours or overnight.

7.4.17 Servicing the brake

7.4.17.1 Servicing the handbrake

Notice

- ▶ Never treat brake handbrake with degreaser or penetrating oil spray.
- ▶ Lubricate articulated joints and mechanical parts which are accessible from outside with a few drops of spray oil or precision mechanics oil.

7.5 Inspection

7.5.1 Checking the wheel

- 1 Hold the bicycle firmly.
- 2 Hold onto the front or rear wheel and try to move the wheel sideways. In doing so, check to see if the wheel nuts or quick releases move.
 - ⇒ If the wheel moves or the wheel nut or quick release moves sideways, take bicycle out of service. Contact specialist dealer.
- 3 Lift bicycle slightly. Turn front or rear wheel. In doing so, check whether the wheel deflects sideways or outwards.
 - ⇒ If the wheel deflects sideways or outwards, take bicycle out of service. Contact specialist dealer.

7.5.1.1 Checking the tube

Notice If the tyre pressure is too low, the tyre cannot support its full load capacity. The tyre is not stable and may come off the rim. If the tyre pressure is too high, the tyre may burst.

Tyres are wear parts and degrade due to fatigue, storage, environmental influences or mechanical impacts. Only optimum tyre pressure will guarantee greater safety, lower rolling resistance, effective protection against punctures and a longer service life.

Air loss

Even the most airtight tube will gradually lose pressure since the air pressures in bicycle tyres are significantly higher and the wall thicknesses significantly finer than in a car tyre. Pressure loss of 1 bar per month can be considered normal. At high pressures, this loss occurs significantly faster while loss is much slower at lower pressures.

Checking tyre pressure

The permitted pressure range is indicated on the side of the tyre.



Figure 198: Tyre pressure specification in bar (1) and psi (2)

- Verify tyre pressure against the value noted in the bike pass every 10 days as a minimum.

Dunlop valve

The tyre pressure cannot be measured on the simple Dunlop valve. The tyre pressure is thus measured in the filling tube while pumping slowly with the bicycle air pump.

- ✓ It is recommendable to use a bicycle air pump with a pressure gauge.
- 1 Unscrew and remove the valve cap.
 - 2 Undo the rim nuts.
 - 3 Connect the bicycle air pump.
 - 4 Pump up the tyre slowly, keeping an eye on the tyre pressure.
 - 5 Correct the tyre pressure according to specifications in the bike pass.
 - 6 If the tyre pressure is too high, unfasten the union nut, let air out and re-tighten the union nut.
 - 7 Remove the bicycle air pump.
 - 8 Screw the valve cap tight.
 - 9 Screw the rim nut gently against the rim with the tips of your fingers.
- ⇒ Correct tyre pressure if necessary (see Section 7.5.8.1).

Schrader valve

- ✓ It is recommended to use an air pump at a filling station or a modern bicycle air pump with a pressure gauge. Older and simple bicycle air pumps are unsuitable for filling tyres via a Schrader valve.
- 1 Unscrew and remove the valve cap.
 - 2 Undo the rim nuts.
 - 3 Connect the bicycle air pump.
 - 4 Pump up the tyre slowly, keeping an eye on the tyre pressure.
- ⇒ The tyre pressure has been adjusted as per indications.
- 5 Remove the bicycle air pump.
 - 6 Screw the valve cap tight.
 - 7 Screw the rim nut gently against the rim with the tips of your fingers.
- ⇒ Correct tyre pressure if necessary (see Section 7.5.8.1).

Presta valve

- ✓ It is recommendable to use a bicycle air pump with a pressure gauge. You must observe the bicycle air pump operating instructions.
 - 1 Unscrew and remove the valve cap.
 - 2 Open the knurled nut around four turns.
 - 3 Carefully attach the bicycle air pump so that you do not bend the valve insert.
 - 4 Pump up the tyre slowly, keeping an eye on the tyre pressure.
 - 5 Correct the tyre pressure as per the specifications on the tyre.
 - 6 Remove the bicycle air pump.
 - 7 Tighten the knurled nut with your fingers.
 - 8 Screw the valve cap tight.
 - 9 Screw the knurled nut gently against the rim with the tips of your fingers.
- ⇒ Correct tyre pressure if necessary (see Section 7.5.8.1).

7.5.1.2 Checking the tyres

The tread is far less important for bicycle tyres than it is for car tyres, for example. Consequently, tyres with a worn tread can still be used, except if the tyre is on a mountain bike.

- 1 Check the tread for wear. The tyre is worn if the anti-puncture protection or the carcass cords are visible on the tread.
Since resistance to punctures also depends on the thickness of the tread, it may be a good idea to change the tyre earlier.




Figure 199: Tyres without a tread which can be replaced (1) and tyres with puncture protection showing through (2) must be replaced

- 2 Check the side walls for wear. If there are any cracks or tears, the tyre must be replaced.
- 3 Replacing a tyre requires considerable mechanical expertise. If a tyre is worn, it needs to be replaced at a specialist dealer's.

7.5.1.3 Checking the rims

⚠ WARNING Crash caused by a worn rim

A worn rim can break and block the wheel. This may cause a crash with serious injuries.

- ▶ Check rim wear on a regular basis.
- ▶ Do not use bicycle if the rim has any cracks or is warped. Contact specialist dealer.



Figure 200: Examples of fatigue cracks (1) and ageing cracks (2)

Rims are wear parts and degrade due to fatigue, mechanical impacts, environmental influences or due to braking if rim brakes are used.

- ▶ Check the rim bed thoroughly for wear.
- ⇒ The rims of a rim brake with an invisible wear indicator are worn as soon as the wear indicator becomes visible in the rim joint area.
- ⇒ The rims with a visible wear indicator are worn as soon as the black, all-round groove on the pad friction surface is no longer visible.
- ▶ We recommend that you also replace the *rims* at the same time as every second brake lining replacement.

7.5.1.4 Checking the nipple holes

Nipples cause fatigue and stress on the edge of the nipple hole.

- ▶ Check whether there are cracks on the edge of the nipple hole.

If there are cracks on the edge of the nipple hole, contact your specialist dealer.

7.5.1.5 Checking the nipple well

The nipple holes can weaken the tyre bed.

- ▶ Check to see if any cracks are forming around the nipple holes.

⇒ Contact your specialist dealer if there are any cracks radiating from the nipple holes.

7.5.1.6 Checking the rim hooks

Mechanical impacts can warp the rim hooks. There is no longer a guarantee that a tyre can be fitted safely if this is the case.

▶ Check for twisted rim hooks.

⇒ Replace rims with twisted rim hooks. Never repair the rim with pliers and bend the hook back.

7.5.1.7 Checking the spokes

▶ Press spokes slightly together with your thumb and index finger. Check to ensure that the tension is the same for all spokes.

⇒ Contact your specialist dealer if the spokes are loose or are tensioned differently.

7.5.2 Checking the brake system

⚠ CAUTION Crash caused by brake failure

Worn brake discs and brake linings and a lack of hydraulic fluid in the brake cable reduce braking power. This may cause a crash with serious injuries.

▶ Check brake disc, brake linings and the hydraulic brake system regularly. Contact specialist dealer.

The inspection interval for the brake depends on how often it is used and on the weather conditions. If the bicycle is used under extreme conditions such as rain, dirt or high mileage, inspection must be performed more frequently.

7.5.2.1 Checking the handbrake

- 1 Check that all screws in the handbrake are firmly in place (see Section 3.5.4).
- 2 Tighten loose screws.
- 3 Check that handbrake is torsionally rigid on the handlebars (see Section 3.5.4).
- 4 Tighten loose screws.
- 5 Check that there is a gap of at least 1 cm between the handbrake and the handle when the handbrake is fully applied.
- 6 Adjust the grip distance if the gap is too narrow (see Section 5.2.19.5).

7 Check the braking effect by pedalling while pulling the handbrake.

- ▶ If the braking power is too weak, adjust the brake pressure point (see Section 6.5.9.8).
- ▶ Contact your specialist dealer if the pressure point cannot be reached.

7.5.2.2 Checking the hydraulic brake system

- 1 Pull on the handbrake and check whether any brake fluid leaks out of the lines, connections or on the brake linings.
- 2 If any brake fluid leaks from anywhere, take bicycle out of service. Contact specialist dealer.
- 3 Pull and hold handbrake several times.
- 4 If you are unable to clearly detect the pressure point and it changes, the brake needs to be bled. Contact specialist dealer.

7.5.2.3 Checking the Bowden cables

- 1 Pull on handbrake several times. Check whether the Bowden cables get stuck or they make scraping noises.
- 2 Check the physical condition of the Bowden cables for visible damage and check to see if wire strands are broken.
- 3 Have defective Bowden cables replaced. Contact specialist dealer.

7.5.2.4 Checking the disc brake

Checking the brake linings

- ▶ Check that the brake linings are no less than 1.8 mm wide at any point and there are no less than 2.5 mm between the brake lining and supporting plate.



Figure 201: Checking the brake lining when fitted with the help of the transport safety wear gauge

- 1 Check brake linings for damage and thick dirt.
- ⇒ Have damaged or very dirty brake linings replaced. Contact specialist dealer.
- 2 Pull handbrake and hold.
- 3 In doing so, check whether the transport safety wear gauge can fit between the brake linings supporting plates.
- ⇒ If the transport safety wear gauge fits between the supporting plates, the brake linings have not reached their wear limit.
- ⇒ Contact your specialist dealer if they are worn.

Checking the brake discs

- ✓ Put on gloves as the brake disc is very sharp.
- 1 Take hold of brake disc and wiggle it gently to check whether the brake disc is positioned against the wheel free of backlash.
 - 2 Check that the brake linings move steadily and symmetrically back towards the brake disc when you pull and release handbrake.
 - ⇒ If the brake disc can be moved or the brake linings move erratically, contact your specialist dealer.
 - 3 Check that the brake disc is no less than 1.8 mm thick at any point.
 - ⇒ If the brake disc is under the wear limit and is less than 1.8 mm thick, the brake disc must be replaced. Contact specialist dealer.

7.5.3 Check chain

- ▶ Check chain for rust, damage and chain links that are difficult to move.
- ⇒ Replace rusted, damaged or difficult-to-move chains since they will not withstand the tensile loads from the drive and will soon break. Contact your specialist dealer.

7.5.4 Checking the chain tension

Notice

Excessive chain tension increases wear. If the chain tension is too low, there is a risk that the chain will slip off the chain wheels.

- ▶ Check the chain tension once a month.

7.5.4.1 Checking the tension in derailleur gears

The rear derailleur tensions the chain on bicycles with derailleur gears.

- 1 Check to see if the chain is sagging.
- 2 Gently press the rear derailleur forwards to check whether it moves and whether it goes back into position by itself.
- ⇒ If the chain is sagging or the rear derailleur does not go back into position by itself, contact your specialist dealer.

7.5.4.2 Checking the tension in the hub gear

- 3 Remove the chain guard on bicycles with a circumferential chain guard.




Figure 202: Checking the chain tension (example): 5 mm upwards, 10 mm downwards = 15 mm deviation

- 1 Lift chain upwards. Measure the distance to the centre. Press chain downwards. Measure the distance to the centre.
- 2 Add the two values together to calculate the deviation.
- 3 Check the chain tension at three to four points.
- ⇒ If the deviation is greater than 20 mm, tighten chain.
- ⇒ If the deviation is less than 10 mm, Loosen chain.
- ▶ If a hub gear is fitted, the rear wheel must be pushed backwards and forwards to tighten the chain. Contact specialist dealer.
- ▶ In the case of bicycles with a hub gear or back-pedal brake, the chain is tensioned by an eccentric bearing or movable fork end in the bottom bracket axle. Special tools and specialist knowledge are required to tension the chain. Contact specialist dealer.

7.5.5 Checking the chain for wear

Each chain has a wear limit. If this limit is exceeded, the chain needs to be replaced.

Manufacturer	Wear limits
SHIMANO	>1%
KCM	>0.8 mm per link
SRAM	>0.8%
ROHLOFF	S: >0.1 mm per link A: >0.075 mm per link

Table 37: Chain wear limit by manufacturer

7.5.5.1 Rough check

You can perform a rough check on the chain wheel by hand on conventional chains

1 Place the chain on the largest chain wheel.

2 Lift the chain from the front to the centre of the wheel.

⇒ If the chain can be lifted more than half a link from the chain wheel, carry out a check or contact your specialist dealer.

7.5.5.2 Check

There is a different wear gauge for each chain, depending on the manufacturer:

1 Insert gauge between two chain links on the right-hand side.




Figure 203: Gauge is inserted

2 Lower gauge down to the left-hand side.




Figure 204: Lower gauge to the left

⇒ If the gauge does not fit between the links, the chain is not worn yet.




Figure 205: Gauge does not fit

⇒ If the gauge does not fit between the links, the chain is worn and must be replaced. Contact specialist dealer.




Figure 206: Gauge fits

7.5.6 Checking the belt

7.5.6.1 Checking the belt for wear

► Check belt for indications of wear:




Figure 207: Indications of wear on a belt

- 1 Carbon tensile fibres are exposed
- 2 Worn webbing with visible polymer
- 3 Missing belt tooth
- 4 Imbalance
- 5 Shark tooth or
- 6 Cracks

⇒ If there is one or more indications of wear, replace belt. Contact specialist dealer.

7.5.6.2 Checking the belt sprocket for wear

► Check belt sprocket.

⇒ The tooth profile is rounded and the teeth are thick. The belt drive sprocket does not need to be replaced.




Figure 208: Optimum tooth profile

⇒ The tooth profile is pointed and teeth have worn thinner. Replace belt sprocket. Contact specialist dealer.




Figure 209: Worn tooth profile




Figure 210: Photo showing worn tooth profile

7.5.6.3 Checking belt tension

If the belt tension is too low, this can cause the system to miss out a tooth or slip, i.e. the teeth on the belt slip over the teeth on the rear wheel belt sprocket. Excessive tension can cause damage to the bearings, sluggishness in the system and increased wear on the electric drive system. Belt tension adjustment varies depending on the bicycle. Common tensioning systems include angled or vertical fork ends, horizontally sliding dropouts and eccentric bottom bracket axle. There are three common methods of measuring belt tension:

- Gates Carbon Drive mobile app for iPhone® and Android®,
- Gates Krikrit tension meter
- Eco tension tester.

The tension along the belt may vary slightly with any of these methods, so you should repeat the process several times. Turn the pedal a quarter after each measurement. Measure again.

The tools measure the tension only. They do not provide specifications for the required tension. The table below contains specifications for the correct tensioning range for Gates Carbon Drive belts.

	Steady pedalling	Sports usage
MTBs* and single-speed bicycles	45–60 Hz (35–45 lbs)	60–75 Hz (45–53 lbs)
Hub gear/pinion gear	35–50 Hz (28–40 lbs)	

Table 38: Specifications for tensioning

* The CDN and SideTrack systems are not permitted for mountain bikes, gears, bikes without a gear shift or for trekking or touring bikes.

These tension specifications are designed as initial guidance and may have to be corrected upwards or downwards, depending on the body size, gear ratio and the force applied to the pedals.

7.5.6.4 Gates Carbon Drive mobile app



The Gates Carbon Drive mobile app measures the belt tension based on the belt's natural frequencies (Hz). To do so, the app uses the phone's mic to record the sound of the belt and determines the main frequency.

- ✓ Download Gates Carbon Drive mobile app free of charge from the App Store or Google Play on your mobile phone.
 - ✓ Measure in a quiet environment.
 - ✓ Ensure that the phone microphone is switched on.
- 1 Open app.
 - 2 Click on the tension symbol.
 - 3 Click on MEASURE.
 - 4 Point phone microphone towards the belt.
 - 5 Pluck the belt so that the belt vibrates like a guitar string.
 - 6 It is recommended to take several measurements for comparison. Turn the crank a quarter. Repeat frequency measurement.

- 7 Check the belt frequency displayed against the specifications for tensions in Table 44.
 - ⇒ If the value is higher than the specification, reduce belt tension,
 - ⇒ If the value is within the specified range, the belt tension has been correctly adjusted.
 - ⇒ If the value is lower than the specification, increase belt tension.

7.5.7 Checking the riding light

- 1 Check the cable connections on the headlight and rear light for damage and corrosion and ensure they are firmly in position.
 - ⇒ If cable connections are damaged or corroded, or are not firmly in positioned. take bicycle out of service. Contact specialist dealer.
- 2 Switch light on.
- 3 Check that the headlight and rear light come on.
 - ⇒ If the headlight or rear lights do not come on, take bicycle out of service. Contact specialist dealer.
- 4 Place bicycle 5 m from the wall.
- 5 Stand the bicycle up straight. Hold the handlebars straight with both hands. Do not use the kickstand.




Figure 211: Light positioned too high (1), correctly (2) and too low (3)

- 6 Check the position of the light beam.
 - ⇒ If the light is positioned too high or too low, adjust riding light (see Section 5.2.26.1).

7.5.8 Checking the stem

- ▶ The stem and quick release system must be inspected at regular intervals. The specialist dealer should adjust them if they require adjustment.
 - ▶ If the hexagon socket screw is also loosened, the bearing clearance also needs to be adjusted. Medium-strength thread locker, such as Loctite blue, then needs to be applied to the loosened screws and the screws tightened as per specifications.
 - ▶ Check metal contact surfaces on cone, stem clamping screw and fork steerer for corrosion.
- ⇒ Take bicycle out of service if there is any wear or signs of corrosion. Contact specialist dealer.

7.5.9 Checking the handlebars

- 1 Take hold of handlebars with both hands on the handles.
 - 2 Move handlebars up and down and press to tilt.
- ⇒ If the handlebars can move, contact your specialist dealer.
- 3 Place front wheel in position where it can't move sideways (e.g. in a bike stand).
 - 4 Hold handlebars firmly with both hands.
 - 5 Check if the handlebars are able to twist against the front wheel.
- ⇒ If the handlebars can move, contact your specialist dealer.

7.5.10 Checking the saddle

- 1 Hold saddle firmly.
 - 2 Check whether the saddle twists, tilts or can be pushed in one direction or other.
- ⇒ If the saddle twists, tilts or can be pushed in one direction or other, adjust the saddle (see Section 6.5.4).
- ⇒ Contact your specialist dealer if the saddle cannot be fixed into position.

7.5.11 Checking the seat post

- 1 Take seat post out of the frame.
- 2 Check seat post for cracks and corrosion.
- 3 Reinsert seat post.

7.5.12 Checking the pedal

- 1 Hold pedal and try to move it sideways toward the inside or outside. In doing so, observe whether the crank arm or bearing move sideways.
- ⇒ If the pedal, crank arm or crank bearing moves sideways, fasten screw on the pedal crank rear.
- 2 Hold pedal and try to move it upwards and downwards vertically. In doing so, observe whether the pedal, crank arm or crank bearing moves vertically.
- ⇒ If the pedal, crank arm or crank bearing moves vertically, fasten screw.

7.5.13 Checking the gear shift

- 1 Check that all gear shift components are free of damage.
- 2 Contact your specialist dealer if components are damaged.
- 3 Place the bicycle on stand.
- 4 Turn the pedal crank clockwise.
- 5 Switch through all speeds.
- 6 Check that pedelec can switch through all speeds without making unusual noises.
- 7 Adjust the gear shift if gears cannot be changed correctly.

7.5.13.1 Checking the electric gear shift

- 1 Check the cable connections for damage and corrosion and ensure they are firmly in position.
- ⇒ If cable connections are loose, damaged or corroded, contact your specialist dealer.

7.5.13.2 Checking the mechanical gear shift

- 1 Change gear a number of times. Check whether the Bowden cables get stuck or they make scraping noises.
 - 2 Check the physical condition of the Bowden cables for visible damage and check to see if wire strands are broken.
- ⇒ Have defective Bowden cables replaced. Contact specialist dealer.

7.5.13.3 Checking the derailleur gears

The chain is tensioned by the rear derailleur in bicycles with derailleur gears.

- 1 Place the bicycle on stand.
- 2 Check to see if the chain is sagging.
- 3 Gently press the rear derailleur forwards to check whether it moves and whether it goes back into position by itself.
 - ⇒ If the chain is sagging or the rear derailleur does not go back into position by itself, contact your specialist dealer.
- 4 Check that there is clearance between the chain tensioner and spokes.
 - ⇒ If there is no clearance or the chain scrapes against the spokes or tyres, contact your specialist dealer.
- 5 Check that there is clearance between the chain or rear derailleur and spokes.
 - ⇒ If there is no clearance or the chain scrapes against the spokes, contact your specialist dealer.

7.5.13.4 Checking the hub gear

In the case of bicycles with a hub gear or back-pedal brake, the chain or the belt is tensioned by an eccentric bearing or movable fork end in the bottom bracket axle. Special tools and specialist knowledge are required to tension the chain. Contact specialist dealer.

- ✓ Remove the chain guard on bicycles with a circumferential chain guard.

- 1 Place the bicycle on stand.
- 2 Check the chain or belt tension in three or four positions, turning the crank a full revolution.




Figure 212: Checking the chain tension (example): 5 mm upwards, 10 mm downwards = 15 mm deviation

- 3 If the chain or the belt can be pushed more than 2 cm, the chain will need to be re-tensioned. Contact specialist dealer.
 - ⇒ If the chain or belt can only be pushed up and down less than 1 cm, you will need to slacken the chain or belt slightly. Contact specialist dealer.
 - ⇒ The ideal chain and belt tension has been achieved if the chain can be pushed between a maximum of 10 and 15 mm in the middle between the sprocket and the toothed wheel. The crank must also turn without resistance.

7.5.13.5 Adjusting the cable-operated gear shift, dual-cable

- ▶ For a smooth gear shift, adjust the **adjusting sleeves** underneath the chain stay on the frame.
- ▶ The shift cable has around 1 mm play when it is pulled out gently.




Figure 213: Adjusting sleeves (2) on two alternative versions (A and B) of a dual-cable, Bowden-cable-operated gear shift on the chain stay (1)

7.5.13.6 Checking kickstand stability

- 1 Place the bicycle on a slight elevation of 5 cm.
- 2 Extend kickstand.
- 3 Jolt bicycle to check stability.
 - ⇒ If bicycle topples over, tighten screws or change height of the kickstand.

8 Inspection and maintenance

⚠️ WARNING Injury due to damaged brakes

Special tools and specialist knowledge are required to repair the brakes. Incorrect or unauthorised assembly can damage the brakes. This may lead to an accident with serious injuries.

- ▶ Only specialist dealers may carry out repairs on brakes.
- ▶ Only carry out work or changes, such as dismantling, sanding or painting, which are permitted and described in the brake operating instructions.

⚠️ WARNING Injury to the eyes

Problems may arise if the settings are not made properly and you may sustain serious injuries as a result.

- ▶ Always wear safety glasses during inspection and maintenance work.

⚠️ CAUTION Crash and falling caused by unintentional activation

There is a risk of injury if the electric drive system is activated unintentionally.

- ▶ Remove the battery before inspection or maintenance.

⚠️ CAUTION Crash caused by material fatigue

If the service life of a component has expired, the component may suddenly fail. This may cause a crash with injuries.

- ▶ Have the specialist dealer carry out basic cleaning of the pedelec every six months, preferably at the same time as the required servicing work.

⚠️ CAUTION Hazard for the environment due to toxic substances

The brake system contains toxic and environmentally harmful oils and lubricants. Such fluids will contaminate if they enter the sewers or groundwater.

- ▶ Dispose of lubricants and oils left over after repairs in an environmentally responsible way in accordance with statutory regulations.

Notice

The motor is maintenance-free and only qualified specialist personnel may open it.

- ▶ Never open the motor.

8.1 Initial inspection

After 200 km or 4 weeks after purchase

Vibrations produced while riding can cause screws and springs that were tightened when pedelec was manufactured to settle or come loose.

- ▶ Arrange an appointment for the initial inspection intermediately when purchasing the pedelec.
- ▶ Have the initial inspection entered and stamped in the maintenance book.

8.2 Carrying out the initial inspection

⚠️ WARNING Crash caused by loose screws

Incorrectly fastened screws may come loose due to impact. The stem may no longer be firmly fixed in its position as a result. This will result in a crash with injuries.

- ▶ Check the handlebars and the stem quick release system are firmly in position after the first two hours of riding.

⚠ WARNING Crash caused by loose screws, springs or quick releases

Vibrations produced while riding can cause screws, springs and quick releases that were tightened when pedelec was manufactured to jam or come loose.

- ▶ Check quick release system is fixed in position.
- ▶ Check all tightening torques of screws and screw connections.

8.3 Major inspection

Every six months

You must have your specialist dealer perform a major inspection every six months as a minimum. This is the only way to ensure that the pedelec remains safe and fully functional.

The tasks require technical expertise, special tools and special lubricants. The pedelec may become damaged if the stipulated major inspection and procedures are not carried out. This is why only specialist dealers may carry out the major inspection.

- ▶ Contact your specialist dealer and arrange an appointment.
- ▶ Enter and stamp major inspection tasks in the maintenance book.

8.4 Component-specific maintenance

High-quality components require extra maintenance. The tasks require technical expertise, special tools and special lubricants. The pedelec may become damaged if the stipulated maintenance intervals and procedures are not observed. This is why only specialist dealers may carry out maintenance.

Correct maintenance on the fork not only guarantees a long service life, but also ensures optimal performance.

Each maintenance interval shows the maximum cycling hours for the required type of maintenance that the component manufacturer recommends.

- ▶ Optimise performance with shorter maintenance intervals, depending on use, terrain and environmental conditions.

Inspection and maintenance intervals for suspension fork		
SR SUNTOUR suspension fork		
<input type="checkbox"/>	Maintenance 1	Every 50 hours
<input type="checkbox"/>	Maintenance 2	Every 100 hours
FOX suspension fork		
<input type="checkbox"/>	Maintenance	Every 125 hours or once a year
ROCKSHOX suspension fork		
<input type="checkbox"/>	Maintenance of stanchions for: Paragon™, XC™ 28, XC 30, 30™, Judy®, Recon™, Sektor™, 35™, Bluto™, REBA®, SID®, RS-1™, Revelation™, PIKE®, Lyrik™, Yari™, BoXXer	Every 50 hours
<input type="checkbox"/>	Maintenance of spring and damper unit for: Paragon, XC 28, XC 30,30 (2015 and earlier), Recon (2015 and earlier), Sektor (2015 and earlier), Bluto (2016 and earlier), Revelation (2017 and earlier), REBA (2016 and earlier), SID (2016 and earlier), RS-1 (2017 and earlier), BoXXer (2018 and earlier)	Every 100 hours
<input type="checkbox"/>	Maintenance of spring and damper unit for: 30 (2016+), Judy (2018+), Recon (2016+), Sektor (2016+), 35 (2020+), Revelation (2018+), Bluto (2017+), REBA (2017+), SID (2017+), RS-1 (2018+), PIKE (2014+), Lyrik (2016+), Yari (2016+), BoXXer (2019+)	Every 200 hours

Inspection and maintenance intervals for seat post		
by.schulz suspension seat post		
<input type="checkbox"/>	Maintenance	After the first 250 km; every 1,500 km after that
eightpins suspension seat post		
<input type="checkbox"/>	Clean wiper	20 hours
<input type="checkbox"/>	Clean slide bushing	40 hours
<input type="checkbox"/>	Replace slide bushing, wiper and felt strip	100 hours
<input type="checkbox"/>	Seal service for gas pressure spring	200 hours
FOX suspension seat post		
<input type="checkbox"/>	Maintenance	Every 125 hours or once a year
KINDSHOCK suspension seat post		
<input type="checkbox"/>	Maintenance	Every 6 months
ROCKSHOX dropper post		
<input type="checkbox"/>	Venting of remote control lever and/or maintenance of lower seat post unit for: Reverb™ A1/A2/B1, Reverb Stealth A1/A2/B1/C1	Every 50 hours
<input type="checkbox"/>	Detach lower seat post, clean brass pins, check and replace if necessary and apply new grease for Reverb AXS™ A1	Every 50 hours
<input type="checkbox"/>	Venting of remote control lever and/or maintenance of lower seat post unit for: Reverb B1, Reverb Stealth B1/C1, Reverb AXS™ A1	Every 200 hours
<input type="checkbox"/>	Complete maintenance of seat post for: Reverb A1/A2, Reverb Stealth A1/A2	Every 200 hours
<input type="checkbox"/>	Complete maintenance of seat post for: Reverb B1, Reverb Stealth B1	Every 400 hours
<input type="checkbox"/>	Complete maintenance of seat post for: Reverb AXS™ A1, Reverb Stealth C1	Every 600 hours
SR SUNTOUR dropper seat post		
<input type="checkbox"/>	Maintenance	Every 100 hours or once a year
All other suspension seat posts		
<input type="checkbox"/>	Maintenance	Every 100 hours

Inspection and maintenance intervals for rear frame damper		
RockShox rear frame damper		
<input type="checkbox"/>	Service the air chamber assembly	Every 50 hours
<input type="checkbox"/>	Service the damper and spring	Every 200 hours
FOX rear frame damper		
<input type="checkbox"/>	Maintenance	Every 125 hours or once a year
SR SUNTOUR rear frame damper		
<input type="checkbox"/>	Complete shock absorber service, including damper reassembly and air seal replacement	Every 100 hours
Inspection and maintenance intervals for motor		
pinion C1.12, C1.9XR, C1.6		
<input type="checkbox"/>	<p>Maintenance 1 Check shift cables, outer sleeves, chains/belts, chainring and sprockets or belt sprockets for wear; replace if necessary. Check shift cables to ensure they are tensioned and move easily. Adjust or replace if necessary.</p> <p>Open shift box. Clean cable pulley, slide surfaces, gear box interior, epicyclic wheels and similar thoroughly and grease generously. Check and tighten all screw connections except gear box screws to ensure they are firmly in place and fasten with correct tightening torque.</p>	Every 500 km
<input type="checkbox"/>	Maintenance 2 Oil change	Every 10,000 km or once a year
pinion E1.12, E1.9		
<input type="checkbox"/>	Oil change	Every 10,000 km

Inspection and maintenance intervals for hub		
SHIMANO 11-speed hub		
<input type="checkbox"/>	Internal oil change and maintenance	1,000 km after start of use, then every 2 years or 2,000 km
All other SHIMANO gear hubs		
<input type="checkbox"/>	Lubricate internal components	Once a year or every 2,000 km
ROHLOFF Speedhub 500/14		
<input type="checkbox"/>	Clean cable box and grease cable drum interior	Every 500 km
<input type="checkbox"/>	Oil change	Every 5,000 km or at least once a year
pinion		
<input type="checkbox"/>	<p>Maintenance 1 Check shift cables, outer sleeves, chains/belts and sprockets or belt sprockets for wear; replace if necessary. Check shift cables to ensure they are tensioned and move easily. Adjust or replace if necessary.</p> <p>Open shift box. Clean cable pulley, slide surfaces, gear box interior, epicyclic wheels and similar thoroughly and grease generously. Check and tighten all screw connections except gear box screws to ensure they are firmly in place and fasten with correct tightening torque.</p>	Every 500 km
<input type="checkbox"/>	Maintenance 2 Oil change	Every 10,000 km

9 Troubleshooting, fault clearance and repair

9.1 Preventing pain

The pedelec is both a means of transport and a piece of sports equipment that promotes health.

After the first few rides, you may experience sore muscles the next day. However, permanent pain should never occur during or after a ride.

The most common complaints are:

- Sitting discomfort
- Pain in hips
- Backache
- Pain in shoulders and nape of neck
- Numb or aching hands
- Pain in upper thigh
- Pain in the knee
- Pain in the foot

If you suffer from one or more of the complaints above, take the following action steps:

- 1** Check the correct adjustment of all components. In most cases, however, pain after pedelec rides is due to a lack of training and components set incorrectly or components that are not adjusted to the rider's physique.
- 2** Consult a doctor as soon as possible and talk openly about the complaints. Pain may be a sign of medical problems that need to be treated.



- 3** If the doctor does not diagnose a medical condition, visit a gym, sports trainer or physiotherapist. Personalised stretching or musculature strengthening exercises must be supervised to ensure they are performed correctly.




Figure 214: Recognised pain due to lack of training and/or incorrect component adjustment

9.1.1 Sitting discomfort

Around 50% of all pedelec riders experience sitting discomfort:

- Pressure pain in the sitting bones
- Pain in the lower back
- Pressure pain and numbness in perineal region.

Solution

- Adopt an optimal riding position (see Section 6.5.2).
- Adjust the saddle height and tilt (see Section 6.5.4).
- Wear cycling shorts and use chamois cream (see Section 6.12).
- Use an ergonomically adjusted saddle (see Section 6.5.4).

- Ride standing up now and again.



9.1.2 Pain in hips

Lower back pain is often not caused by the back muscles, but by the iliopsoas muscle instead. This muscle is part of the inner hip musculature and flexes the hip. It is attached to the thigh bone and reaches up to the spine. Pain can occur in the back if this muscle is strained too much or shortened.

Solution

- Strengthening exercises for the iliopsoas muscle
- Stretching exercises for hip flexors and extensors.



9.1.3 Backache

Riding a pedelec strengthens the back musculature. The greater the saddle-to-bar drop is, the greater the strain on the back musculature is. At the beginning, a posture where you lean too far forward can lead to pain in the back, arms and wrists. The abdominal muscles are the counterpart to the back muscles and stabilise the pelvis and the back. Back pain is thus often caused by weak abdominal muscles.

Solution

- Contact specialist dealer. You need to adopt a more upright sitting position (see Section 6.5.3).

- Stretching exercises for the back and abdominal muscle ligaments and moderate bicycle training will lengthen the tendons and build new back and abdominal muscles.



The desired position can be adopted after a period of training.

9.1.4 Pain in shoulders and nape of neck

The weight of the upper body places a strain on the shoulders due to the bent-forward posture on the pedelec. The more stretched the position is, the more strain there is on the shoulders.

The specific posture adopted is often the source of pain. Pedelec riders often extend their arms. Impacts such as those occurring on bumpy roads are thus transmitted to the shoulders without suspension. This causes severe pain.

Another source of pain is a hunchback. Due to the posture adopted, the neck needs to be extended backwards excessively so that the rider can look forwards. This causes strain in the neck and shoulder muscles.

9.1.5 Numb or aching hands

Your hands are one of the three points of contact when you ride a pedelec. The hands transmit the weight of the upper body to the handlebars. In the upright Holland position, there is almost no weight applied whereas body weight is at its highest in the sports position. The force is applied to a small area on the handle, meaning the pressure load on the hands is very high. Hands are highly sensitive and can bear a maximum of 20% of body weight during prolonged exposure to load.

9.1.6 Pain in upper thigh

Pain in the upper thigh is usually due to muscular problems. A muscular imbalance between the extensors, flexors and adductors can cause this pain.

Solution



- A more upright riding position will immediately reduce pain.
- Always bend elbows slightly.
- ⇒ The elbow joint will not block. The arms cushion impacts.
- Adjust the handlebars (see Section 6.5.5).
- Always adopt an optimal riding position (see Section 6.5.3).

Solution

- Position handles perfectly (see Section 6.5.5.1, 6.5.5.2 and 6.5.8)
- Move hands and arms while riding (see Section 6.15)
- Use padded cycling gloves (see Section 2.15)
- Optimise handles (see Section 6.5.7).

Solution

- Increasing assistance on the pedelec will bring immediate relief.



- Targeted exercises to correct imbalance and shortening of the thigh muscles.
- Stretching exercises for the thigh muscles.

9.1.7 Knee pain

Pedelec riding is a sport that is easy on the knee joints and is recommended for beginners. Very powerful forces are transmitted from the thigh to the foot via the knee when pedalling. As a result, the tendons and cartilage in the knee are subjected to great stress.

Pain on the inside and outside of the knee is often caused by incorrect adjustment of the click system and the foot being out of position as a consequence. Pain in the lower part of the knee usually stems from an improper riding position.

Cold weather can also cause knee pain. Tendons are less elastic at low temperatures and thus rub against the knee more.

If the knee is out of position, the cartilage becomes very worn. Muscular imbalances or ligaments that are too short can increase this effect. Pain on the top of the kneecap often indicates a muscular imbalance. Pain under the kneecap is usually related to excessive pressure in the knee joint and consequential irritation to the patellar tendon.

9.1.8 Pain in the foot

Your feet are one of three points of contact when you ride a pedelec. Feet transmit force from the upper thigh to the pedal, thus driving the pedelec. In the process, your feet are subjected to between 100% and, during jumps, even up to 1,000% of your body weight.

Foot pain often arises when the saddle is too low or the foot is placed incorrectly on the pedal.

Unsuitable shoes can also be the cause of pain in the feet.

Solution

- Contact specialist dealer. Have the pedelec adjusted (see Section 6.5). Then measure the wheel.
- Avoid cold.



- Get imbalances under control through stretching exercises, strengthening the muscles and Blackroll training.

Solution

- Wear sturdy shoes which are not too tightly laced (see Section 2.5).
- Position feet correctly on the pedals (see Section 6.13).
- Adjust the saddle height to an optimum position (see Section 6.5.4).

9.2 Kiox 300 and Kiox 500 drive system

The control panel indicates whether a critical or less critical error has arisen in the drive system.

The error messages generated by the drive system can be read in the eBike Flow app and by the bicycle dealer.

The rider can use a link in the eBike Flow app to display all information on errors and assistance on eliminating errors.

9.2.1 Drive system or on-board computer does not start up

If the on-board computer and/or the drive system do not start up, proceed as follows:

- 1 Check whether the battery is switched on. If not, start the battery.
- ⇒ Contact your specialist dealer if the battery level indicator LEDs do not light up.
- 2 If the LEDs on the Battery Level indicator light up, but the drive system does not start, remove the battery.
- 3 Insert the battery.
- 4 Start the drive system.
- 5 If the drive system does not start up, remove the battery.
- 6 Clean all the contacts with a soft cloth.
- 7 Insert the battery.
- 8 Start the drive system.
- 9 If the drive system does not start up, remove the battery.
- 10 Fully charge the battery.
- 11 Insert the battery.
- 12 Start the drive system.
- 13 If the drive system does not start, press the **on-off button (control panel)** for at least 8 seconds.
- 14 If the drive system does not start after about 6 seconds, press the **on-off button (control panel)** for at least 2 seconds.
- 15 Contact your specialist dealer if the drive system won't start.

More info on Kiox 300

Description
Adjusting
Use
Cleaning
Maintenance
Error solution

9.2.2 Errors in assistance function

Symptom	(Possible) cause	Remedy
Assistance is not available.	Is the battery charged sufficiently?	<ol style="list-style-type: none"> 1 Check battery is charged. 2 Recharge the battery if it is almost flat.
	Is the system switched on?	<p>▶ Press on-off button (battery).</p> <p>⇒ The drive system starts.</p>
	Is the level of assistance set to [OFF]?	<ol style="list-style-type: none"> 1 Set the assistance mode to a different level of assistance than [OFF]. 2 Contact your specialist dealer if you still feel that the no assistance is being supplied.
	The rechargeable battery, on-board computer or assistance switch may be connected incorrectly, or one or more of them may have a problem.	▶ Contact specialist dealer.
	Are the pedals being pushed?	<p>The pedelec is not a motorbike.</p> <p>▶ Push the pedals.</p>
	Is the speed too high?	<p>The electronic gear assistance is only active up to a maximum speed of 25 km/h.</p> <p>▶ Check on-board computer indicators.</p>
	Is the lock function activated?	▶ Use suitable on-board computer.
	The battery may become too hot during rides at high temperatures, up long inclines or when carrying a heavy load for a long time.	<ol style="list-style-type: none"> 1 Switch off the drive system. 2 Leave pedelec to cool down. 3 Start the drive system.
The assisted journey distance is too short.	Is the battery fully charged?	<ol style="list-style-type: none"> 1 Check charge level. 2 Recharge the battery if it is almost flat.
	The battery does not perform as well in winter weather.	This does not indicate a problem.
	The journey distance can be shorter, depending on the road conditions, the gear level and the entire light usage time.	This does not indicate a problem.
	The battery is a consumable. Repeated charging and long periods of use cause the battery to degrade (loss of power).	<p>If the distance covered with a fully charged battery has become shorter, the battery may be affected.</p> <p>▶ Replace old battery with new one.</p>
It is difficult to pedal.	Are the tyres pumped to an adequate pressure?	1 Pump up tyres.
	Is the level of assistance set to [OFF]?	<ol style="list-style-type: none"> 1 Set level of assistance to [HIGH], [STD], [ECO] or [AUTO]. 2 Contact your specialist dealer if the pedals are still stiff.
	Is the battery fully charged?	<ol style="list-style-type: none"> 1 Check charge level. 2 Recharge the battery if it is almost flat.
	Have you switched on the system with your foot on the pedal?	<ol style="list-style-type: none"> 1 Switch system on again without applying pressure to the pedal. 2 Contact your specialist dealer if the pedals are still stiff.

Table 39: Error solution for assistance system

9.2.3 Battery errors

Symptom	(Possible) cause	Remedy
The battery discharges very quickly.	The battery may be at the end of its useful life.	► Replace old battery with new one.
The battery cannot be recharged.	Is the charger mains plug firmly connected to the socket?	<ol style="list-style-type: none"> 1 Disconnect the charger mains plug and plug it in again. 2 Start charging. 3 If the battery still won't recharge, contact your specialist dealer.
	Is the charger plug firmly connected to battery?	<ol style="list-style-type: none"> 1 Disconnect the charger plug and plug it in again. 2 Start charging. 3 If the battery still won't recharge, contact your specialist dealer.
	Is the adapter firmly connected to the charger plug or the battery's charging port?	<ol style="list-style-type: none"> 1 Connect the adapter firmly to the charger plug or the battery charging port. 2 Start charging. 3 If the battery still won't recharge, contact your specialist dealer.
	Is the connection terminal for the charger, charger adapter or batteries dirty?	<ol style="list-style-type: none"> 1 Wipe with a dry cloth to clean the connection terminals. 2 Start charging. 3 If the battery still won't recharge, contact your specialist dealer.
The battery does not start charging when the charger is connected.	The battery may be at the end of its useful life.	► Replace old battery with new one.
The battery and charger become hot.	Has the battery or charger temperature exceeded the operating temperature range?	<ol style="list-style-type: none"> 1 Interrupt charging process. 2 Leave battery and charger to cool down. 3 Start charging. <p>⇒ If the battery becomes too hot to touch, there might be a problem with the battery.</p> <ol style="list-style-type: none"> 4 Contact specialist dealer.
The charger is hot.	If the charger is used continuously to charge batteries, it may become hot.	<ol style="list-style-type: none"> 1 Interrupt charging process. 2 Leave charger to cool down. 3 Start charging.
The LED on the charger does not light up.	The LED on the charger will go out when the battery is fully charged.	This is not a malfunction.
	Is the charger plug firmly connected to battery?	<ol style="list-style-type: none"> 1 Check connection for any contaminants. 2 Insert charger plug. 3 If the battery still won't recharge, contact your specialist dealer.
	Is the battery fully charged?	<ol style="list-style-type: none"> 1 Disconnect charger mains plug. 2 Insert mains plug again. 3 Start charging. 4 Contact your specialist dealer if the LED on the charger still doesn't light up.
The battery cannot be removed.		► Contact your specialist dealer.
The battery cannot be inserted.		► Contact specialist dealer.
Fluid is leaking from the battery.		► Observe all the warnings in Section 2 Safety.

Table 40: Error solution for battery

Symptom	(Possible) cause	Remedy
There is an unusual smell.		<ol style="list-style-type: none"> 1 Remove from the battery immediately. 2 Contact the fire service immediately. 3 Observe all the warnings in Section 2 Safety.
Fumes are emitted from the battery.		<ol style="list-style-type: none"> 1 Remove from the battery immediately. 2 Contact the fire service immediately. 3 Observe all the warnings in Section 2 Safety.

Table 40: Error solution for battery

9.2.4 Display screen errors

Symptom	(Possible) cause	Remedy
No data are shown on the display screen if you press the on-off button (battery) .	The battery charge level may be insufficient.	<ol style="list-style-type: none"> 1 Charge the battery. 2 Switch on the power.
	Is the power switched on?	▶ Press the on-off button (battery) to switch the power on.
	Is the battery charged?	If the battery is fitted to the pedelec and is being charged, it cannot be switched on. ▶ Interrupt charging.
	Is the connector fitted to the power cable correctly?	<ol style="list-style-type: none"> 1 Check whether the connector is fitted to the power cable correctly. 2 If the connector is fitted correctly, contact your specialist dealer.
	A component may be connected which the system is unable to recognise.	▶ Contact specialist dealer.
The gear level is not shown on the display screen.	The gear level is only shown if the electronic gear shift is used.	<ol style="list-style-type: none"> 1 Check that the power cable connector has not been disconnected. 2 If this is not the case, contact your specialist dealer.
The settings menu cannot be opened while you are pedalling.	The product is designed in such a way that the Settings menu cannot be opened if the system detects that the pedelec is moving. This is not a malfunction.	<ol style="list-style-type: none"> 1 Stop pedelec. 2 Change settings when stationary only.
The lock function cannot be set up or switched off.	It may be a firmware error.	▶ Contact specialist dealer.
The connect account has been deleted or deactivated and the lock function is still activated.	...	▶ Contact specialist dealer.

Table 41: On-board computer error solution

9.2.5 Lighting does not work

Symptom	(Possible) cause	Remedy
Front lamp or rear lamp does not go on, even when the switch is pressed.	The default settings in the electric drive system have probably been configured incorrectly.	<ol style="list-style-type: none"> 1 Take pedelec out of service immediately. 2 Contact specialist dealer.
	The light is defective.	

Table 42: Lighting fault solution

9.2.6 BOSCH error message

9.2.6.1 On-board computer

The on-board computer indicates whether a critical or less critical error has arisen in the drive system.

The error messages generated by the drive system can be read in the eBikeFlow app or by the specialist dealer.

The rider can use a link in the eBike Flow app to display information on errors and assistance on eliminating errors.

Critical errors

The indicator for the selected level of assistance and battery level indicator flash red to indicate critical errors.

Flash sequence	Meaning
	LED Remote is flashing red: Critical error

- ▶ Functions have failed. Contact your specialist dealer.
- ▶ Never connect a charger.

Less critical errors

The indicator for the selected level of assistance will flash orange in the event of less critical errors.

Flash sequence	Meaning
	LED Remote is flashing orange: Less critical error

- ▶ Press selection button.

⇒ The error is acknowledged and the indicator for the selected level of assistance displays the colour for the configured level of assistance permanently.

You can eliminate errors yourself using the following table when necessary. Contact your specialist dealer if the problem persists.

Code	Description	Method of resolution
0x523005 0x514001 0x514002 0x514003 0x514006	The sensors do not detect the magnetic field properly.	<ul style="list-style-type: none"> ▶ Check that the magnet wasn't lost while riding. ▶ If a magnet sensor is used, check that the sensor and magnet have been fitted properly. In doing so, ensure that the cable to the sensor is not damaged. ▶ If a rim magnet is used, ensure that there are no magnetic field interference near the drive unit.
580	System software for the Enviolo gear shift is not the latest version.	▶ Contact specialist dealer. Update ENVILO software.
591	The Enviolo gear shift could not be identified correctly. The motor assistance was off or delayed in activating. Push assist system or Drive-Off mode not available. No gear shift.	<ul style="list-style-type: none"> ▶ Use ENVILO components only. ▶ Switch off the pedelec, remove the battery and reinsert. ▶ Re-start pedelec.
593	Pedelec is not designed for eShift. Wrong software container. No motor assistance and no gear shift possible.	<ul style="list-style-type: none"> ▶ Switch off system and re-start. ▶ If the problem persists, contact a specialist dealer.

Table 43: List of on-board computer error messages

Code	Description	Method of resolution
595	No gear communication, no eShift indicator.	<ul style="list-style-type: none"> ▶ Contact your specialist dealer. 1 Switch off system and re-start. 2 Check cables and plug connections. 3 Carry out a system check with the desktop software. 4 If the error persists, replace the ENVILO interface.
596	No gear communication, no eShift indicator.	<ul style="list-style-type: none"> ▶ Error 596 occurs during the firmware update of the new ENVILO AUTOMATiQ AHI because the system restarts, causing a brief interruption in the connection. This is not an error. 1 If the error code does not appear at this time, switch off the system and re-start. 2 Check cable and plug connections. 3 If Error 595 is displayed, look at the corresponding error description.
596	Occurs when new ENVILO products are installed for the first time.	<ul style="list-style-type: none"> ▶ Check that the plug connection is connected correctly. ▶ Ensure that it is an Automatic+ interface or the CAN protocol is set to Bosch. ▶ Error 596 can be ignored in systems with a wireless control panel.
750	Pedalling frequency control and shifting gears is not possible.	<ul style="list-style-type: none"> ▶ Contact your specialist dealer.
751	The ENVILO shift box has tried to calibrate. However, the user didn't pedal.	<ul style="list-style-type: none"> ▶ Perform calibration again while pedalling. Contact your specialist dealer if the problem persists. ▶ Contact your specialist dealer if the problem persists. Check the set-up using the ENVILO desktop software tool.

Code	Description	Method of resolution
761	ENVILO calibration completed and determined that the entire transmission range is not available.	<ul style="list-style-type: none"> ▶ Perform ENVILO calibration again. ▶ If the error persists, contact specialist dealer. Check with another interface of the same design to ensure the interface functions correctly.
770	Limited cadence control functions. Manual shifting is possible.	<ul style="list-style-type: none"> ▶ Switch off system and re-start. 1 If the error persists, contact specialist dealer. Check the RPM sensor position. 2 Ensure that all twelve magnets are in place. 3 If the problem persists, contact the ENVILO Service Center for a further diagnosis.
771	Limited cadence control functions.	<ul style="list-style-type: none"> ▶ Switch off system and re-start. 1 If the error persists, contact specialist dealer. Check the speed sensor position. 2 Ensure that all six magnets are in place. 3 If the problem persists, contact the ENVILO Service Center for a further diagnosis.
780	Pedalling frequency control and shifting gears is not possible. The gear shift is stuck in an unknown transmission.	<ul style="list-style-type: none"> 1 Switch off system and re-start. 2 If the error persists, contact specialist dealer. Contact the ENVILO Service Center for a further diagnosis.
781	Pedalling frequency control and shifting gears is not possible. The gear shift is stuck in an unknown transmission.	<ul style="list-style-type: none"> 1 Switch off system and re-start. 2 If the error persists, contact specialist dealer. Contact the ENVILO Service Center for a further diagnosis.
799	Pedalling frequency control and shifting gears is not possible.	<ul style="list-style-type: none"> 1 Contact specialist dealer. Perform a system update with the ENVILO desktop software tool.

Table 43: List of on-board computer error messages

Table 43: List of on-board computer error messages

9.2.6.2 Battery

The battery is protected against deep discharge, overcharging, overheating and short circuits by Electronic Cell Protection (ECP). In the event of a hazard, a protective circuit switches the battery off automatically. If a fault is detected on the battery, the LEDs will flash on the battery level indicator.




Description	Method of resolution
<p>Code: </p> <p>If the battery is outside its charging temperature range, three LEDs will flash on the battery level indicator.</p>	<ol style="list-style-type: none"> 1 Disconnect charger from battery. 2 Leave battery to cool down or warm up. 3 Contact your specialist dealer if the problem persists.
<p>Code: </p> <p>If a battery fault is detected, two LEDs will flash on the battery level indicator.</p>	<p>► Contact specialist dealer.</p>
<p>Code: </p> <p>No LEDs will light up if there is no power.</p>	<ol style="list-style-type: none"> 1 Check all plug connections. 2 Check contacts on the battery for dirt. Clean the contacts carefully if needed. 3 Contact your specialist dealer if the problem persists.

Table 44: List of battery error messages

9.2.7 Correcting disc brake faults

Symptom	(Possible) cause	Remedy
Ringing and unusual sounds from the disc brake.	Riding on tarmac with off-road tyres.	▶ Contact specialist dealer. Fit a city or trekking tyre.
Low braking power from the disc brake.	Dirty or greasy brake disc.	▶ Clean brake disc thoroughly with white spirit or brake cleaner.
	Worn brake disc.	▶ Contact specialist dealer. New brake disc.
	Worn brake lining. Brake lining vitrification.	▶ Contact specialist dealer. New brake linings.
Metallic noises from disc brake.	Worn brake linings.	▶ Contact specialist dealer. New brake linings and brake disc.
Spongy, soft or poor pressure point in disc brakes.	Brake calliper fitted incorrectly, brake disc loose, brake disc or brake lining worn or brake system leaking.	▶ Contact specialist dealer.
Noises when a disc brake is applied.	Dirt.	1 Clean brake disc and brake thoroughly. 2 If the problem is not solved, contact your specialist dealer.
	Worn or incorrect brake linings.	▶ Contact specialist dealer. New brake linings and brake discs.
	Wheel, hub or axle fitted incorrectly.	▶ Contact specialist dealer. Check brake system and wheel assembly.
	Brake calliper and/or brake disc fitted incorrectly.	
	Incorrect torques.	
	Brake disc damaged by side impact.	
	Vitrified brake linings.	
	Brake system leaking.	
Incorrect brake mount height.		

Table 45: Disc brake error solution

9.2.8 Correcting faults in the SR SUNTOUR suspension fork

9.2.8.1 Rebound too fast

The suspension fork rebounds too quickly, producing a "pogo stick" effect, where the wheel lifts from the ground in an uncontrolled way. This impairs traction and control (blue line).

Fork head and handlebars are deflected upwards if the wheel bounces back from the ground. Body weight may be thrown up and back in an uncontrolled way (green line).



Figure 215: Suspension fork rebounding too quickly

Solution

► Turn **rebound adjuster (suspension fork)** clockwise.

⇒ The rebound speed is decreased (slower return).



Figure 216: Example of SR SUNTOUR rebound adjuster (suspension fork) (1)

9.2.8.2 Rebounding too slowly

The suspension fork does not rebound quickly enough after absorbing a bump. The suspension fork also remains deflected over subsequent bumps, which reduces deflection and increases the hardness of impacts. Available deflection, traction and control decrease (blue line).

The suspension fork remains in a deflected state, causing the headset and handlebars to move to a lower position. Body weight is shifted forward after the impact (green line).




Figure 217: Suspension fork rebounding too slowly

Solution

► Turn **rebound adjuster (suspension fork)** anti-clockwise.

⇒ The rebound speed is increased (faster return).



Figure 218: Example of SR SUNTOUR rebound adjuster (suspension fork) (1)

9.2.8.3 Suspension too soft on inclines

The suspension fork deflects at a low point in the terrain. The deflection is quickly used up, body

weight shifts forward and the pedelec loses some momentum.




Figure 219: Excessively soft suspension in the suspension fork on hilly terrain

Solution

- Turn **compression level** clockwise towards **LOCK**.

⇒ Damping and the compression hardness are increased and the deflection stroke speed is reduced. Efficiency on hilly and flat terrain is improved.

R2C2-PCS R2C2 RC2 RC2-PCS	RC-PCS RC	RLRC-PCS RLRC	LORC-PCS LORC

Table 46: Low-speed lever (1) on the SR SUNTOUR suspension fork on the fork crown

9.2.8.4 Excessively hard damping on bumps

When the bike hits a bump, the suspension fork deflects too slowly and the wheel lifts up from the bump. Traction decreases when the wheel no longer touches the ground.

The headset and handlebars are deflected upwards significantly, which can impair control.




Figure 220: Excessively hard damping in the suspension fork on bumps

Solution

► Turn **compression lever** clockwise towards OPEN.

⇒ Damping and the compression hardness are reduced and the deflection stroke speed is increased. Sensitivity to small bumps is increased.

R2C2-PCS R2C2 RC2 RC2-PCS	RC-PCS RC	RLRC-PCS RLRC	LORC-PCS LORC

Table 47: Low-speed lever (1) on the SR SUNTOUR suspension fork on the fork crown

9.2.9 Problems with the Rohloff hub gear

Symptom	(Possible) cause	Remedy
A noise is heard when the pedals are turning.	All gear speeds except 1.	▶ This is not a malfunction.
A noise is heard when the pedelec is pushed backwards.	All gear speeds except 1.	
Noises and vibrations occur on switching on.	All gear speeds.	
Gear shifting feels different, depending on the gear speed.	All gear speeds.	
A noise is heard whenever the rider isn't pedalling while riding.	All gear speeds.	
The gears are difficult to engage.	The cable has not been installed properly.	▶ Contact specialist dealer.
	The gear shift unit has been set to the override state.	▶ Contact specialist dealer. (readjust gear shift unit).
Gears cannot be engaged smoothly.	Shift cable tension setting not correct.	1 Carefully pull the <i>adjusting sleeve</i> away from the shifter housing, turning it as you do so. 2 Check the gear shift functions properly after each adjustment.
The gear speed cannot be changed.	The cable was not set correctly.	▶ Contact specialist dealer. (Reset gear shift unit; check whether the gear speed can be changed when the wheel is detached from the frame.)
Strange noises occur.	When switching gears.	▶ Contact specialist dealer.
	When pedalling.	
The gear speed shown on the indicator differs from the speed in the hub.	The cable was not set correctly.	▶ Contact specialist dealer.
	The internal unit has a defect.	
The hub rotates with difficulty only or does not rotate smoothly.	The cone is firmly positioned.	▶ Contact specialist dealer.
	The internal unit has a defect.	▶ Contact specialist dealer.
A rattling noise is heard when rider pedals.	The section around the cone is damaged.	▶ Contact specialist dealer.
Free rotation is not smooth if the rider does not pedal.		▶ Contact specialist dealer.
The brakes are too sensitive.		▶ Contact specialist dealer.
The brakes are not strong enough.		▶ Contact specialist dealer.
The rider needs to push the pedals too far back before the brakes engage.		▶ Contact specialist dealer.
The wheels block if the pedelec is pushed backwards.		▶ Contact specialist dealer.

Table 48: Error solution for limit stop

Symptom	(Possible) cause	Remedy
Strange noises occur when the brakes are applied.		▶ Contact specialist dealer.
Rotation feels stiff during free rotation.		▶ Contact specialist dealer.
Chain jumps between the gearwheels when gear is changed.	Gearwheels and/or chain worn.	▶ Contact specialist dealer. New chain, gearwheels or hub.

Table 48: Error solution for limit stop

9.2.10 Problems with the Rohloff hub gear

The ROHLOFF Service Team can be reached at service@rohloff.de. The service team strives to help cyclists around the world with technical problems and purchasing spare parts.

Shipping parts is very expensive or impossible in some countries. That is why sufficient spare parts for components subject to wear or at risk of falling off/breaking and the necessary tools should be carried (see Section 6.6.11).

Symptom	(Possible) cause	Remedy
Noises from new hubs.	Hub not run in yet.	<p>During the first 1000 km, the gears and clutch elements in a new ROHLOFF Speedhub 500/14 gear hub hone into one another. This is not a defect.</p> <p>▶ Run gear hub in over 1,000 km. Existing driving noises will become quieter and gear changes smoother as a result. The running-in period does not cause any limitations.</p>
Crank spins while bike is pushed.	Sprocket dragged by the hub shaft seal.	<p>▶ Apply a drop of Rohloff cleaning oil onto the hub seal through the holes in the sprocket.</p> <p>⇒ The dragging effect is reduced.</p>
Backlash too great.	Tensile stress has shifted.	<p>1 Adjust tensile stress so that it is correct.</p> <p>2 If the problem is not solved, contact your specialist dealer.</p>
Gear indicator does not match the marking on the shift handle.	Tension adjuster incorrectly adjusted.	<p>1 Adjust tension adjuster correctly.</p> <p>2 If the problem is not solved, contact your specialist dealer.</p>
Shift handle no longer move through all 14 gear speeds (14 speeds = 13 lock positions).	Shift cable trimmed incorrectly.	▶ Contact specialist dealer.
	Tension adjuster incorrectly adjusted.	<p>1 Adjust tension adjuster correctly.</p> <p>2 If the problem is not solved, contact your specialist dealer.</p>
	In the case of external switch control: Cable box hexagonal compressed connection in wrong position.	▶ Contact specialist dealer.
Slipping (chain doesn't settle into position after gear shift).	Axle nut on the screw-on axle fastened too tightly.	▶ Contact specialist dealer (tighten axle mount using specified torque).
	Gear shift does not settle properly; tensile stress too high.	<p>1 Adjust tensile stress so that it is correct.</p> <p>2 If the problem is not solved, contact your specialist dealer.</p>
	Gear oil too sticky.	▶ Contact specialist dealer (change oil).
	Oil screw fastened too far.	▶ Fasten oil screw so that it is flush.
	...	▶ Contact specialist dealer if none of the aforementioned solutions apply.
Slipping (chain doesn't settle into position after gear shift).	Gear oil too sticky.	▶ Contact specialist dealer (change oil).
	Using the bike at temperatures below -15 °C.	▶ Contact specialist dealer (flush the gearbox and use a mixture of 50% Rohloff all-season oil and 50% Rohloff spray oil as lubricant [total amount 50:50, max. 25 ml]).
Gears 1 to 7 slip after detaching the axle ring or the shifter housing.	...	▶ Contact specialist dealer.

Table 49: Error solution for limit stop

Symptom	(Possible) cause	Remedy
Freewheel is stiff when rotating.	Shaft seal rubs against sprocket.	▶ Contact specialist dealer (loosen shaft seal).
	Housing bearing tensioned (e.g. after fall, accident or sprocket replaced).	▶ Contact specialist dealer (relieve pressure on housing bearing).
	Chain tension too high.	▶ Contact specialist dealer (reduce tension, about 5 mm chain slack; twist out-of-round chainrings; replace if necessary).
Twist shifter does not rotate freely.	Shift cable tension too high.	1 Reduce the shift cable tension. 2 If the problem is not solved, contact your specialist dealer.
	Shift cables worn, dirty or damaged.	▶ Contact specialist dealer (fit new shift cables).
	Wrong shift cables fitted.	
	Shift cable routing has too many bends or kinks.	
	Inner nylon cable liner has penetrated into the twist shifter or the cable box.	
	Twist shifter rubs against shifter rubber.	▶ Contact specialist dealer (separate to leave a small gap between twist shifter rubber and the grip).
	Twist shifter degreased by weather.	▶ Contact specialist dealer (remove the twist shifter grip rubber, clean and regrease it).
	Hub cable broken and frayed.	▶ Contact specialist dealer.
	Gear transfer box is bent.	▶ Contact specialist dealer.
	Changing between gears 8 and 14 is not possible or only possible with extreme force.	▶ Contact specialist dealer (reset thread rod).
	Hexagonal peg in the external gear transfer box does not turn freely (due to corrosion or bent).	▶ Contact your specialist dealer.
Twist shifter fails to rotate in subzero temperatures.	Water has penetrated into the twist shifter and has frozen.	▶ Contact specialist dealer (remove the rubber grip. Clean, regrease grip and replace the seal if necessary).
	Water has seeped into the shift cables and has frozen.	▶ Contact specialist dealer (replace shift cables and plastic liner).
	Water has seeped into the cable box and has frozen.	▶ Contact specialist dealer (open cable box, clean and apply a little light grease to the pulley).
Shift cable has come away from the cable clamp.	...	▶ Contact specialist dealer (fit new shift cable).
Male bayonet connector has come away from the hub cable.	...	▶ Contact specialist dealer (fit new shift cable).
Chain ratchets over the sprocket teeth.	Chain defective (stiff chain link).	▶ Contact specialist dealer (new chain).
	Worn sprocket or chain.	▶ Contact specialist dealer (new sprocket).
	Inadequate tension by chain tensioner.	▶ Contact specialist dealer (correct chain length).
Chain springs off the sprocket or chainring.	Chain tensioner is dry and is stiff when turned.	▶ Grease the chain tensioner.
	Chain tensioner spring is defective.	▶ Contact specialist dealer (new chain tensioner).
	Chain guide missing from front chainring.	▶ Contact specialist dealer (fit chain guide).

Table 49: Error solution for limit stop

Symptom	(Possible) cause	Remedy
Oil leaks.	Traces of oil film (no droplets).	Oil can form around the shaft seals, the housing lid gasket and the oil drain screw due to variations in air temperature and pressure. This is not a defect. ▶ You can continue riding with the hub until the next regular oil change (5000 km interval).
	Oil leaks following horizontal transportation or storage.	Pedelecs must be transported and stored in an upright position. Oil will leak out in a horizontal position. ▶ Contact specialist dealer (measure oil level in hub).
	Traces of oil on the quick release axle.	The gears breathe through the inner hole in the gear axle. This is not a defect. ▶ You can continue riding with the hub until the next regular oil change (5000 km interval).
	Oil drops form on quick release hole in the axle spindle.	▶ Contact specialist dealer.
	Oil drops form on the axle ring and axle plate or the gaiters.	▶ Contact specialist dealer.
	Oil drops form on housing lid flange.	▶ Contact specialist dealer.
	Traces of oil on oil drain screw.	▶ Contact specialist dealer.
	Oil drops form on shaft seals (sides of housing smeared in oil).	▶ Contact specialist dealer.
Gear shift no longer works (while touring).	Shift cable broken (shift cable on hub - internal shift control).	▶ Detach axle plate and cable pulley. ▶ Use an 8 mm box/open-end spanner to select a suitable gear (e.g. gear no. 7). ⇒ You can now continue riding using this one gear. ▶ Contact specialist dealer on your return.
	Shift cable broken (internal shift control).	▶ Select a suitable gear by pulling on the hub shift cables. ⇒ You can now continue riding using this one gear. ▶ Contact specialist dealer on your return.
	Bayonet lost or defective (internal shift control).	▶ Replace with screw clamp or shift cable. ▶ Knot the shift cable with binding wire. ▶ Contact specialist dealer on your return.
	Shift cable broken (external shift control).	▶ Detach cable box. ▶ Use an 8 mm box-type/open-end spanner to select a suitable gear. ▶ You can now continue riding using this fixed gear. ▶ Contact specialist dealer on your return.
	Retaining ring (and bolt) lost on quick-release fastener collar clamp.	▶ Replace with M6 screw and nut or fix temporarily with binding wire. ▶ Contact specialist dealer on your return.

Table 49: Error solution for limit stop

9.2.11 Correcting freewheel faults

Symptom	(Possible) cause	Remedy
Freewheel blocked.	Cover forgotten after fitting.	▶ Contact specialist dealer. Check installation correct.
	After installation, socket was compressed by over-tightening the quick-release axle.	▶ Contact specialist dealer. Measure the length of the socket. If the socket is shorter than 15.4 mm, replace socket.
Freewheel slips or does not lock into place.	After maintenance: Too much or wrong grease on the toothed discs.	▶ Contact specialist dealer. Remove hub. Clean and grease toothed disc.
	Toothed discs are worn.	▶ Contact specialist dealer. Replace toothed disc.
	One or both springs were forgotten after fitting.	▶ Contact specialist dealer. Check installation correct.
	One or both toothed discs are fitted the wrong way round after installation.	▶ Contact specialist dealer. Check installation correct.
Hub has axial clearance.	Ball bearings are worn.	▶ Contact specialist dealer. Replace ball bearings.
	One or both toothed discs are fitted the wrong way round after installation.	▶ Contact specialist dealer. Check installation correct.
Hub is stiff when turned.	Ball bearings are worn.	▶ Contact specialist dealer. Replace ball bearings.
	Ball bearings have been driven in too firmly after installation.	▶ Contact specialist dealer. Check installation correct.
	Installation sequence for ball bearings not observed.	▶ Contact specialist dealer. Check installation correct.
Hub makes noise.	Ball bearings are worn.	▶ Contact specialist dealer. Replace ball bearings.
Cassette caused notches on the freewheel body.	Steel cassette is working its way into the aluminium bar on the freewheel body.	▶ Contact specialist dealer. Remove notches on the cassette surface with a file.
Freewheel body is stiff when turned.	Ball bearings in the freewheel body are worn.	▶ Contact specialist dealer. Replace freewheel body.
Freewheel is too loud or too quiet.	Perception of freewheel noise is subjective. Some pedelec riders enjoy a loud freewheel sound while others prefer a quieter one.	▶ This is not a malfunction. The amount of grease between the toothed discs may have an effect on the freewheel noise. Less grease increases freewheel noise but also causes greater wear.

Table 50: Fault solution for freewheel

9.2.12 Correcting lighting faults

Symptom	(Possible) cause	Remedy
The front light or rear light does not go on, even when the switch is pressed.	The default settings in the electric drive system have probably been configured incorrectly. The light is defective.	<ol style="list-style-type: none"> 1 Take pedelec out of service immediately. 2 Contact specialist dealer.

Table 51: Lighting fault solution

9.2.13 Correcting faults in tyres

Symptom	(Possible) cause	Remedy
Valve torn off.	Presta valve used with a sizeable valve hole. The hole's metal edge separates the valve stem from the tube.	► Contact specialist dealer. Fit another type of valve.

Table 52: Fault solution for tyres

9.2.14 Correcting control seat post faults


Symptom	(Possible) cause	Remedy
Seat post clicks or creaks.	Protective layer missing.	► Service seat post (see Section 7.4.9).
Seat post deflects and bobs periodically.	Incorrect pre-tensioning.	<ul style="list-style-type: none"> ► Adjust pre-tensioning so that the suspension seat post does not deflect under the rider's weight when at rest.
Seat post with remote control does not rise or lower.	Bowden cable is not tensioned correctly.	<ul style="list-style-type: none"> ► Adjust the Bowden cable with the setting screw (1) on the remote control.  <p>Figure 221: Remote control with setting screw (1)</p> <ul style="list-style-type: none"> • Reduce sensitivity: turn the setting screw clockwise. • Increase sensitivity: turn setting screw anti-clockwise.

Table 53: Fault solution for the seat post

9.2.15 Correcting other faults and errors

Symptom	(Possible) cause	Remedy
Two beeps will sound if a switch is pressed but the switch cannot be operated.	Pressed switch mode has been deactivated.	▶ This is not a malfunction.
Three beeps are sounded.	A fault or warning has occurred.	▶ This occurs when a warning or an error is shown on the on-board computer. Follow the instructions for the code in Section 6.2 System Messages.
If an electronic gear shift is used, pedal assistance becomes less effective when the gear is changed.	This is because the computer sets the pedal assistance to the optimum level.	▶ This is not a malfunction.
A noise can be heard after switching.		▶ Contact specialist dealer.
It is normal to hear a noise coming from the rear wheel when cycling as normal.	The gear shift setting may not have been made properly.	▶ Contact specialist dealer.
If the pedelec is brought to a stop the pedelec, the gear transmission does not switch to the position pre-configured in the functional feature.	You may have applied too much pressure on the pedals.	▶ Press on the pedals gently only to make it easier to change the transmission.

Table 54: Other drive system errors

9.3 Repairs at the specialist dealer

Expert knowledge and special tools are required for many repairs. For this reason, repairs may only be carried out at a specialist dealer. These include:

- Replacing tyre, tube and spokes,
- Replace brake linings, rims and brake discs
- Replace and tension the chain.

9.3.1 Original parts and lubricants

The individual pedelec parts have been carefully selected and matched to one other.

Only original parts and lubricants must be used for inspection and repair.

The constantly updated accessory approval and parts lists are in Section 11, Documents and Drawings.

- ▶ Follow the operating instructions for the new components.

9.3.2 Repairing the frame

9.3.2.1 Removing paint damage on frame

- 1 Gently sand paintwork damage with 600-grit sandpaper.
- 2 Smooth edges.
- 3 Apply one or two coats of repair paint.

9.3.2.2 Removing damage from impact on the carbon frame

There may be damage to the laminate beneath the paintwork in the case of impact. The frame may break even under light stress.

- 1 Take pedelec out of service.
- 2 Send frame to a fibre composite repair company or purchase new frame as specified in the parts list.

9.3.3 Repairing the suspension fork

9.3.3.1 Removing paint damage on the fork

- 1 Gently sand paintwork damage with 600-grit sandpaper.
- 2 Smooth edges.
- 3 Apply one or two coats of repair paint.

9.3.3.2 Removing damage from impact on the carbon frame

There may be damage to the laminate beneath the paintwork in the case of impact. The fork may break even under light stress.

- ▶ Take pedelec out of service. New fork as specified in the parts list.

⇒ The fork must be free from any defects.

- 4 Clean inside and exterior.
- 5 Grease fork.
- 6 Install fork.

9.3.3.3 Repairing the seat post

Repairing paint damage on the seat post

- 1 Gently sand paintwork damage with 600-grit sandpaper.
- 2 Smooth edges.
- 3 Apply one or two coats of repair paint.

9.3.3.4 Repairing damage from impact on the carbon seat post

There may be damage to the laminate beneath the paintwork in the case of impact. The carbon seat post may break even under light stress.

- 1 Take pedelec out of service.
- 2 New carbon seat post as specified in parts list.

9.3.4 Replacing the riding light

- ▶ Only use components in the corresponding power class when replacing them.

9.3.5 Adjusting the headlight

- ▶ The *headlight* must be positioned so that its light beam shines on the road 10 m in front of the pedelec (see Section 6.4).

9.3.6 Checking suspension fork-tyre clearance

The tyre clearance needs to be checked each time a suspension fork tyre is replaced.

- 1 Release pressure from the suspension fork.
- 2 Press suspension fork together fully.
- 3 Measure the gap between the top of the tyre and the fork crown's lower surface. The gap must not be less than 10 mm. If the tyre is too large, the tyre will touch the lower surface of the fork crown when the suspension fork is fully pressed together.
- 4 Release pressure on the suspension fork and pump it up again if it is an air suspension fork.
- 5 Take into account the fact that the gap will be smaller if there is a guard. Check again to ensure that there is sufficient clearance for the tyre.

9.3.7 Replacing pedelec components if lock function is installed

9.3.7.1 Replacing a smartphone

- 1 Install Bosch eBike connect app on the new smartphone.
 - 2 Log on using the same account which was used to activate the lock function.
 - 3 Connect on-board computer with the smartphone while the on-board computer is in use.
- ⇒ The lock function is shown as set up in the BOSCH eBike Connect app.

9.3.7.2 Replacing the on-board computer

- Connect on-board computer with the smartphone while the on-board computer is in use.
- ⇒ The lock function is shown as set up in the BOSCH eBike Connect app.

9.3.7.3 Activating the lock function after motor replacement

- ✓ The lock function is displayed as deactivated in the eBike Connect app when the motor has been replaced.
- 1 Open the <My eBike> menu item in the eBike Connect app.
 - 2 Push the <Lock function> slider to the right.
- ⇒ The drive unit assistance can now be deactivated by removing the on-board computer.

10 Recycling and disposal



This device is marked according to the European Directive 2012/19/EU on waste electrical and electronic equipment – WEEE and the European Directive 2006/66/EC on accumulators. The

directive provides the framework for returning and recycling used devices across the EU. Consumers are legally required to return all used batteries of any type. It is forbidden to dispose of batteries in domestic waste.



The battery manufacturer is legally obliged to take back used and old batteries free of charge according to Section 9 German Batteries Act. The pedelec frame, battery, motor, on-board computer and charger are recyclable materials. You must dispose of and recycle them separately

from domestic waste in compliance with the applicable statutory regulations. Collecting and recycling items separately safeguards reserves of raw materials and ensures that all the regulations on health and environmental protection are observed when recycling the product and/or the battery.

- ▶ Never dismantle the pedelec, battery or charger for disposal.

The pedelec, the on-board computer, the unopened and undamaged battery and the charger can be returned to any specialist dealer free of charge. Further disposal options may be available, depending on the region.

- ▶ Store the individual parts of the decommissioned pedelec in a dry place, free from frost, where they are protected from direct sunlight.

10.1 Guidelines on removal of waste

Waste type	Disposal
Non-hazardous waste	
Recycling	
Waste paper, cardboard	Return the paper collection bin, paper container and undamaged transport packaging to suppliers
Scrap metal and aluminium	Take to municipal collection points or have collected by waste disposal companies
Tyres, tubes	Tyre manufacturers' collection points, collection forms and fax templates available from tyre manufacturer Otherwise, residual waste bin (grey bin)
Fibre composite components (e.g. carbon, GRP)	Large carbon components such as defective frames and carbon rims can be sent to special collection points for recycling; see www.cfk-recycling.de/index.php?id=57
Dual system sales packaging made of plastic, metal and composite material, lightweight packaging	Collection by waste disposal firm where applicable; return transport packaging to suppliers Plastic waste bin (yellow bin)
CDs, DVDs	Take to municipal collection points since they are made of high-grade plastic and are easy to recycle Otherwise, residual waste bin (grey bin)
Dispose	
Residual waste	Residual waste bin (grey bin)
Biodegradable lubricants Biodegradable oils Cleaning cloths covered in biodegradable oil	Residual waste bin (grey bin)
Filament lamps, halogen lamps	Residual waste bin (grey bin)
Hazardous waste	
Batteries, rechargeable batteries	Return to the battery manufacturer.
Electric devices: Motor On-board computer Display Control panel Wiring	Take to a municipal collection point for electronic waste
Dispose	
Waste oil Cleaning cloths daubed in oil Lubrication oil Gear oil Lubricating grease Cleaning fluids Kerosene White spirit Hydraulic fluid Brake fluid	Never mix different oil fluids. Store in original container Small amounts (mainly <30 kg) Take to municipal collection points for hazardous waste (e.g. mobile toxic waste collection service) Larger quantities (>30 kg) Collection by waste disposal companies
Paints Varnishes Thinners	Take to municipal collection points for hazardous waste (e.g. mobile toxic waste collection service)
Neon lights, energy-saving lamps	Take to municipal collection points for hazardous waste (e.g. mobile toxic waste collection service)

Table 55: Guidelines on waste removal

11 Documents















11.1 Operating instructions for pinion

12 Glossary

Bicycle for young adults

Source: ISO 4210-2: pedelec designed for use on public roads by a young adult whose weight is less than 40 kg, with maximum saddle height of 635 mm or more and less than 750 mm (see ISO 4210).

Brake lever

Source: EN 15194:2017: lever used to apply the brake.

Braking distance

Source: EN 15194:2017: distance travelled by a pedelec between the commencement of braking and the point at which the pedelec comes to rest.

Cargo bike

Source: DIN 79010: pedelec mainly designed to carry goods.

CE marking

Source: Directive on Machinery: the manufacturer uses the CE marking to declare that the pedelec complies with the applicable requirements.

City and trekking bicycle

Source: EN-ISO 4210 - 2: pedelec designed for use on public roads primarily for means of transportation or leisure.

Consumables

Source: EN 82079-1: any part or material that is needed to continue using or maintain the product.

Continuous power rating

Source: ISO 15194:2017: output power specified by the manufacturer at which the motor reaches its thermal equilibrium under the specified ambient conditions.

Decommissioning

Source: DIN 31051: intentional, unlimited interruption in an object's functional capability.

Disc brake

Source: EN 15194:2017: brake in which brake pads are used to grip the lateral faces of a thin disc attached to or incorporated into the wheel hub.

Drive belt

Source: EN 15194:2017: seamless ring belt which is used as a means of transmitting drive force.

Electrical control system

Source: EN 15194:2017: electronic and/or electrical component or an assembly of components provided for installation into a vehicle, together with all electrical connections and associated wiring for the motor electrical power assistance.

Electrically power assisted cycle, pedelec

Source: EN 15194:2017: electrically power assisted cycle pedelec EPAC bicycles, equipped with pedals and an auxiliary electric motor, which cannot be propelled exclusively by means of the auxiliary electric motor, except in start-up assistance mode.

Emergency stop

Source: ISO 13850:2015: to avert arising or reduce existing hazards to persons, damage to machinery or to work in progress; – to be initiated by a single human action.

Fault

Source: EN 13306:2018-02, 6.1: state of an item (4.2.1) characterized by its inability to perform a required function (4.5.1), excluding such inability during preventive maintenance or other scheduled actions or due to lack of external resources.

Folding bicycle

Source: ISO 4210-2: pedelec designed to fold into a compact form, making it easy to transport and store.

Fork steerer

Source: EN 15194:2017: part of a fork that rotates around the steering axis of a pedelec frame head tube. It is normally connected to the fork crown or directly to the fork legs, and is normally the point of connection between the fork and the handlebar stem.

Fracture

Source: EN 15194:2017: unintentional separation into two or more parts.

Maintenance

Source: DIN 31051: maintenance is generally performed at regular intervals and often carried out by trained technical staff. This ensures a maximum service life and low wear and tear for the maintained items. Proper maintenance is often also a pre-requisite for providing a warranty.

Manufacturer

Source: Directive 2006/42/EC on Machinery, 17.05.2006 Any natural or legal person who designs and/or manufactures machinery or partly completed machinery covered by this Directive and is responsible for the conformity of the machinery or the partly completed machinery with this Directive with a view to its being placed on the market, under his own name or trademark or for his own use.

Maximum continuous power rating

Source: ZEG: the maximum continuous power rating is the maximum power for the electric motor output shaft during 30 minutes.

Maximum permitted total weight

Source: EN 15194:2017: weight of the fully assembled pedelec plus the rider and baggage, as specified by the manufacturer.

Maximum saddle height

Source: EN 15194:2017: vertical distance from the ground to the point where the top of the seat surface is intersected by the seat-post axis, measured with the saddle in a horizontal position and with the seat-post set to the minimum insertion-depth mark.

Maximum tyre pressure

Source: EN 15194:2017: maximum tyre pressure recommended by the tyre or rim manufacturer for a safe and efficient performance. If the rim and tyre both indicate a maximum tyre pressure, the maximum inflation pressure is the lower of the two pressures indicated.

Minimum insertion depth

Source: EN 15194:2017: mark indicating the minimum insertion depth of handlebar stem into fork steerer (fork stem) or seat post into frame.

Model year

Source: ZEG: the model year refers to the first production year that the series-manufactured pedelec was manufactured in the version in question and is not always identical with the year of manufacture. The year of manufacture may be before the model year in some cases. If no technical modifications are introduced to the series, production may continue of pedelecs from a previous model year.

Mountain bike, MTB

Source: ISO 4210-2: pedelec designed for use off-road on rough terrain, on public roads, and on public pathways, equipped with a suitably strengthened frame and other components, and, typically, with wide-section tyres with coarse tread patterns and a wide range of transmission gears.

Negative deflection

Negative deflection or sag is fork compression caused by body weight and gear (e.g. a backpack), the rider's position and the frame geometry.

Off-road rough terrain

Source: EN 15194:2017: rough gravel tracks, forest trails and other generally off-road tracks where tree roots and rocks are likely to be encountered.

Operating instructions

Source: ISO/DIS 20607:2018: part of the user information that machine manufacturers provide to machine operators; it contains guidance, instructions and tips related to the use of the machine in all its life cycle phases.

Placing on the market

Source: Directive 2006/42/EC on Machinery, 17.05.2006, Making available for the first time in the Community machinery or partly completed machinery with a view to distribution or use, whether for reward or free of charge.

Pressure point

Source: ZEG: the pressure point on a brake is the point on the brake lever where the brake disc and brake pads respond and the braking process is initiated.

Quick-release device, quick release

Source: EN 15194:2017: lever actuated mechanism that connects, retains or secures a wheel or any other component.

Racing bicycle

Source: ISO 4210-2: bicycle intended for high-speed amateur use on public roads and having a steering assembly with multiple grip positions (allowing for an aerodynamic posture), a multi-speed transmission system, tyre width not greater than 28 mm and a maximum mass of 12 kg for the fully assembled bicycle.

Rebound

The rebound defines the speed at which the fork rebounds after being loaded.

Rechargeable battery, battery

Source: DIN 40729:1985-05: a rechargeable battery is an energy storage device that can store supplied electrical energy as chemical energy (charging) and release it as electrical energy when required (discharging).

Seat post

Source: EN 15194:2017: component that clamps the saddle (with a bolt or assembly) and connects it to the frame.

Shut-off speed

Source: EN 15194:2017: speed reached by the pedelec at the moment the current has dropped to zero or to the no load current value.

Slippage

Source: DIN 75204-1:1992-05: the difference in relation to vehicle speed between the vehicle speed and the speed of its wheels at their circumference.

Spare part

Source: EN 13306:2018-02, 3.5: item intended to replace a corresponding item in order to retain or maintain the original required function of the item.

Suspension fork

Source: EN 15194:2017: front wheel fork incorporating controlled, axial flexibility to reduce the transmission of road-shocks to the rider.

Suspension frame

Source: EN 15194:2017: frame incorporating controlled, vertical flexibility to reduce the transmission of road-shocks to the rider.

Terrain

Source: ISO 4210-1:2023-05, EN 15194:2017: coarse pebble tracks, forest trails and other general off-road tracks where tree roots and rocks are likely to be encountered.

Total deflection

Source: Benny Wilbers, Werner Koch: Neue Fahrwerkstechnik im Detail (New chassis technology in detail): The distance that the wheel travels between an unloaded and a loaded position is called total deflection. When at rest, the vehicle's mass is applied to the springs and reduces the total deflection by the *negative deflection* to the positive deflection.

Wear

Source: DIN 31051: reduction in useful life (4.3.4), caused by chemical and/or physical processes.

Weight of the ready-to-ride pedelec

Source: ZEG: the indicated weight for a ready-to-ride pedelec refers to the weight of a pedelec at the time of sale. The weight of each additional accessory must be added to this weight.

Wheel

Source: ISO 4210-2: unit or combination of hub, rim and spokes or disc, but excluding tyre assembly.

Work environment

Source: EN 9000:2015: set of conditions under which work is performed.

Year of manufacture

Source: ZEG: the year of manufacture is the year in which the pedelec was manufactured. The production period is always from May to July the following year.

13 Appendix

I. Translation of the original EC Declaration of Conformity

Manufacturer

i:SY GmbH Co. KG
 Longericher Str. 2
 50739 Köln, Germany

Authorised representative for documentation*

Janine Otto
 c/o ZEG Zweirad-Einkaufs-Genossenschaft eG
 Longericher Strasse 2
 50739 Köln, Germany

The machine, pedelec types:

H-01	S10 Adventure	City and trekking bicycle
H-02	E5 ZR F CX	City and trekking bicycle
H-03	RE 14 ZR F	City and trekking bicycle
H-04	E5 ZR F CX Century	City and trekking bicycle
H-05	E5 ZR F CX my i:SY	City and trekking bicycle
H-06	N3.8 ZR CX Comfort	City and trekking bicycle
H-07	N3.8 ZR Auto Comfort	City and trekking bicycle
H-08	E5 ZR F Adventure	City and trekking bicycle
J-01	XXL E5 ZR F CX	City and trekking bicycle
J-02	XXL RE 14 ZR F	City and trekking bicycle
J-03	XXL N3.8 ZR CX Comfort	City and trekking bicycle
J-04	XXL N3.8 ZR Auto Comfort	City and trekking bicycle

Year of manufacture 2022 to year of manufacture 2025, complies with the following applicable EU provisions:

- Machinery Directive 2006/42/EC
- RoHS Directive 2011/65/EU Restriction of the use of certain hazardous substances in electrical and electronic equipment
- Electromagnetic Compatibility Directive 2014/30/EU.

The safety objectives in the Low Voltage Directive 2014/35/EU have been met in compliance with Appendix I, No. 1.5.1 of the Machinery Directive 2006/42/EC.

The following harmonised standards have been applied:

- EN 15194:2017 Cycles – Electrically power assisted cycles – EPAC bicycles, **except for Section 6 Instructions for use; harmonised standard EN ISO 20607:2019 is used instead**
- EN ISO 20607: 2019 Safety of machinery – Instruction handbook – General drafting principles.

The following other technical standards have been applied:

- EN 11243:2016-12 Cycles – Pannier racks for bicycles – Requirements and test methods
- EN 17406:2021-11 Classification for bicycles usage
- EN 62133-2:2017-11 Secondary cells and batteries containing alkaline or other non-acid electrolytes. Safety requirements for portable sealed secondary cells, and for batteries made from them, for use in portable applications – Part 2: Lithium.



Cologne, 20.10.2024

.....
 Georg Honkomp, Managing Director of i:SY GmbH Co. KG

* Community member who is authorised to compile the technical documentation

II. Directive declaration of conformity with RED Directive

LED Remote

Robert Bosch GmbH, Bosch eBike Systems,
hereby declares that the LED Remote radio
system type complies with Directive 2014/53/EU.
The complete EU Declaration of Conformity is
available online at:

<https://www.bosch-ebike.com/conformity>

14 Keyword index

A

- Air valve, 56
 - Position, 56
- Articulated shaft,
 - servicing 187

B

- Back-pedal brake, 70
 - braking, 170, 171
- Ball bearing,
 - Position, 67
- Battery housing, 79
- Battery level indicator (battery), 79
- Battery level indicator, 100
- Bead core, 65
 - Position, 63
- Bell,
 - checking 182
 - using 163
- Belt sprocket, 73, 76
- Belt, 73, 76
 - checking for wear 194
 - checking tension 194
 - cleaning, 185
 - Gates Carbon Drive mobile app 195
- Bicycle for young adults, 237
- Bike headset, see Steering headset
- Bowden cable, 68
 - checking, 191
- Brake cable, 68
- Brake calliper, 69
 - Position, 69
- Brake disc,
 - checking, 192
 - cleaning, 185
 - replacing, 226
- Brake lever,
 - adjusting the pressure point, 131
 - cleaning, 185
 - servicing, 188
- Brake linings,
 - checking, 191
 - replacing, 226
 - retracting, 116, 128
- Brake,
 - checking the brake disc 192
 - checking the brake linings 192

- checking the pressure point 191
- checking, 183
- cleaning, 183
- securing during transport 101
- using, 170
- Cable clip, 68
- Cover cap, 68
- hydraulic, 68
- Insert pin, 68
- Knob, 68
- mechanical, 68
- Union nut, 68

- Braking distance, 237
- Break in operation, 103
 - carrying out, 103
 - preparing, 101, 103
- Button,
 - Minus, 83, 166
 - On-off (battery) 79
 - Plus, 83, 144, 166
 - Push assist, 83, 166

C

- Carbon seat post,
 - servicing, 187
- Carcass, 64
 - Position, 63
- Cargo bike, 237
- Cassette,
 - cleaning, 185
- CE marking, 237
- Chain guard, 25
 - cleaning, 185
- Chain wheel, 73, 76
- Chain wheels,
 - cleaning, 185
- Chain, 73, 76
 - checking for wear 193
 - checking tension 192
 - clamping, 226
 - cleaning, 185
 - maintaining, 202
 - replacing, 226
 - servicing, 188
 - Position, 73, 76
- Charger, 78
 - disposing of, 228

- Chassis, 50
- Child seat, 146
- City and trekking bicycles, 237
- Clock,
 - setting 145
- Compression damping, 59, 60
- Consumables, 237
- Continuous power rating, 237
- Control panel,
 - cleaning, 185
- Conventional valve, see Dunlop valve
- Crown, 62

D

- Decommissioning, 237
- Derailleur gears,
 - checking 196
 - using, 171
- Disc brake, 237
- Drive belt, 237
- Drive system, 73, 76
 - switching on, 165, 168
 - Electric, 78
- Dunlop valve, see conventional valve
- Dust seal 62

E

- eBike Flow,
 - registering, 142
- Electrical control system, 237
- Emergency stop, 237

F

- Factory settings,
 - resetting 145
- Fault, 237
- Folding bicycle, 237
- Fork end, 52
 - Position, 52
- Fork leg,
 - Position, 52
- Fork lock,
 - Position 82
- Fork steerer, 52, 62, 238
 - Position, 52
- Fork, 52
 - checking 181
 - servicing, 183
 - Position, 25
 - Spring-loaded, 239

- Fracture, 238
 Frame, 50
 - checking 181
 - cleaning, 183
 - servicing, 183
 Position, 25
 French valve, see Presta valve
 Front derailleur,
 - cleaning, 185
 Front light,
 Position, 25
 Front wheel brake, 70
 - braking, 170, 171
 Front wheel, see Wheel
- G**
 Gear shift,
 - checking 196
 - checking the electric gear shift 196
 - switching, 96, 178
 - using, 171
- H**
 Handbrake, 237
 Handlebars, 51, 82
 - checking, 196
 - cleaning, 183
 - servicing, 186
 - using 163
 Position, 25
 Using bar ends 164
 Using the multi-position handlebars 163
 Handles,
 - checking 182
 - cleaning, 184
 - servicing, 186
 - using leather handles 164
 Headlight,
 - adjusting, 141
 - cleaning, 183
 Headlight, see Front light
 Headset, see Steering headset
 Hub axle,
 Position, 67
 Hub body,
 Position, 67
 Hub gear,
 - checking 197
 Hub, 67
 - adjusting the ROHLOFF 197
 - cleaning, 184
 - maintaining, 201
 - servicing, 187
- Hub, 25
 Position, 63
 Without additional features, 67
 Hydraulic brake system,
 - checking 191
- J**
 Jockey wheel,
 - servicing 187
- K**
 Kickstand,
 - checking stability 197
 - servicing, 186
 Position, 25
- L**
 Language,
 - selecting 145
 Leather handles,
 - cleaning, 184
 - servicing, 187
 Leather saddle,
 - cleaning, 184
 - servicing, 187
 Level of assistance, 84, 88, 100
 - selecting 169
 - selecting, 169
 ECO, 84, 88
 OFF, 84, 88
 TOUR, 84, 88
 TURBO, 84, 89
 Lockout,
 Position 82
- M**
 Maintenance, 238
 Manufacturer, 238
 Mechanical,
 - gear shift, 196
 Minimum insertion depth marking, 112, 121
 Minimum insertion depth, 238
 Minus button, 83, 166
 Model year, 238
 Motor, 78
 Mountain bike, 238
 Mountain bike, see MTB
 MTB, see mountain bike
 Mudguard,
 - checking, 182
 - servicing, 186
 Position, 25
- N**
 Negative deflection, 238
 Nipple holes,
 - checking, 190
 Nipple well,
 - checking, 190
- O**
 Off-road tyres, 64
 On-board computer,
 - attaching, 143
 - charging the battery, 166
 - removing 143
 - removing, 143
 - securing 143
 Operating instructions, 239
- P**
 Pannier rack battery,
 - remove, 159
 Pannier rack,
 - changing, 162
 - checking 182
 - servicing, 186
 - using, 162
 Position, 25
 Patented seat post, 72, 75
 Pedal, 70
 - cleaning, 183
 - servicing, 188
 Pedelec, 237
 - adjusting 110
 - before each ride 158, 181
 - checking, 189
 - cleaning, 183
 - initial inspection 198
 - inspecting (specialist dealer) 198
 - major inspection 199
 - shipping 102
 - using 161
 Placing on the market, 239
 Plus button, 83, 144, 166
 -Position, 25
 Position, 25
 Pressure point, 239
 Puncture protection belt, 65
 Position, 63
 Push assist button, 83, 166
 Push assist,
 - using 168
 - using, 168
- Q**
 Quick release, 239
 - checking 182

- Position, 67
- R**
- Racing bicycle valve, see Presta valve
- Racing bicycle, 239
- Rear derailleur,
- servicing, 187
- Rear frame damper,
- adjust SR SUNTOUR sag, 138
- adjusting the sag, 136
- checking 182
- cleaning, 183
- maintaining, 201
- Rear light, 78
- cleaning, 183
Position, 25
- Rear wheel brake, 70
- Rear wheel, see Wheel
- Rebound adjuster, 56
Position, 56
- Rebound damping, 57
- Rebound, 239
- Rechargeable battery, 79, 239
- disposing of, 228
- remove, 159
- shipping 102
- transporting, 102
- Rechargeable battery, see Battery
- Reflector,
Position, 25
- Reflectors,
- cleaning, 183
Position, 52
- Retainer guard, 79
- Riding light,
- adjusting, 141
- checking, 182
- switching off 167
- switching on 167
- Rim brake locking lever 68
- Rim, 52, 65
- replacing, 226
- servicing, 187
Position, 63
- Road tyres, 64
- Roller brake,
-braking, 170, 171
- S**
- Saddle, 162
- adjusting hardness 119
- changing the seat length, 112, 121
- checking 196
- cleaning, 184
- determining the saddle height, 111, 112, 120, 121
- determining width 119
- selecting hardness 119
- using, 162
Position, 25
- Safety guards 13
- Safety guards,
- checking 181
- Sag setting wheel,
Position, 56
- Sag,
Position of setting wheel 82
Setting wheel, 62
- Sclaverand valve, see Presta valve
- Seat post, 25, 72, 75, 239
- checking 182, 196
- cleaning, 184
- Patented seat post 72, 75
- servicing, 187
- Suspension seat post 72, 75
- Securing hook, 79
- Settings,
- changing 144
- Shifter,
- cleaning, 185
- servicing, 187
- Shut-off speed, 239
- Slicks, 64
- Slippage, 239
- Spare part, 239
- Spoke nipples, 66
- servicing, 187
Position, 63
- Spokes, 66
- checking, 191
- switching, 226
Position, 63
- Start screen, 144
- Steering headset, 50
Position, 25
- Steering system, 50
- Stem, 50
- adjusting 161
- checking, 196
- cleaning, 183
- servicing, 186
Position, 25
- Suspension fork, 54, 239
- cleaning, 183
- servicing, 183, 186
- Suspension seat post, 72, 75
- cleaning, 183
- servicing, 187
- Switching elements,
- cleaning, 184
- T**
- Total deflection 239
- Trailer, 147
- Tread, 64
Position, 63
- Tube,
- switching, 226
- Tyre design types, 63
- Tyre pressure, 63
- changing, 189
- checking, 189
- Tyre size, 63
- Tyres, 63
- checking, 190
- cleaning, 184
Position, 63
- Tyres,- Tube-type tyres 63
- U**
- USB port,
- using, 166
- V**
- Valve, 63
Dunlop valve, 65
Position, 63
- Vehicle,
Technical data 19
- W**
- Wear, 240
- Wheel, 25, 63, 240
- checking wheel concentricity 182
- checking, 189
- Winter break, see Break in operation
- Work environment, 240
- Y**
- Year of manufacture, 240